

CMOS 4-BIT SINGLE CHIP MICROCOMPUTER
S5U1C63000A Manual
S1C63 Family Assembler Package Ver.11

Evaluation board/kit and Development tool important notice

1. *This evaluation board/kit or development tool is designed for use for engineering evaluation, demonstration, or development purposes only. Do not use it for other purposes. It is not intended to meet the requirements of design for finished products.*

2. *This evaluation board/kit or development tool is intended for use by an electronics engineer and is not a consumer product. The user should use it properly and in a safe manner. Seiko Epson does not assume any responsibility or liability of any kind of damage and/or fire caused by the use of it. The user should cease to use it when any abnormal issue occurs even during proper and safe use.*

3. *The part used for this evaluation board/kit or development tool may be changed without any notice.*


NOTICE

No part of this material may be reproduced or duplicated in any form or by any means without the written permission of Seiko Epson. Seiko Epson reserves the right to make changes to this material without notice. Seiko Epson does not assume any liability of any kind arising out of any inaccuracies contained in this material or due to its application or use in any product or circuit and, further, there is no representation that this material is applicable to products requiring high level reliability, such as, medical products. Moreover, no license to any intellectual property rights is granted by implication or otherwise, and there is no representation or warranty that anything made in accordance with this material will be free from any patent or copyright infringement of a third party. When exporting the products or technology described in this material, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You are requested not to use, to resell, to export and/or to otherwise dispose of the products (and any technical information furnished, if any) for the development and/or manufacture of weapon of mass destruction or for other military purposes.


All brands or product names mentioned herein are trademarks and/or registered trademarks of their respective companies.

Configuration of product number

Devices



Development tools



Introduction

This document describes the development procedure from assembling source files to debugging. It also explains how to use each development tool of the "S1C63 Family Assembler Package" common to all the models of the S1C63 Family.

Caution

We are not responsible for any problems involving products you have manufactured using packed data created without the use of the tool contained in this package, or using packed data edited after being created using the tool contained in this package.

How To Read the Manual

This manual was edited particularly for those who are engaged in program development. Therefore, it assumes that the reader already possesses the following fundamental knowledge:

- Basic knowledge about assembler language
- Basic knowledge about the general concept of program development by an assembler
- Basic operating methods for Windows

Before installation

See Chapter 1. Chapter 1 describes the composition of this package, and provides a general outline of each tool.

Installation

Install the tools following the instruction of the installer as described in Chapter 1.

To understand the flow of program development

See the program development flow in Chapter 2.

For coding

See the necessary parts in Chapter 4. Chapter 4 describes the grammar for the assembler language as well as the assembler functions. Also refer to the following manuals when coding:

S1C63xxx Technical Manual

Covers device specifications, and the operation and control method of the peripheral circuits.

S1C63000 Core CPU Manual

Has the instructions and details the functions and operation of the Core CPU.

For debugging

Chapter 8 gives detailed explanation of the debugger. Sections 8.1 to 8.8 give an overview of the functions of the debugger. See Section 8.9 for details of the debug commands. Also refer to the following manuals to understand operations of the In-Circuit Emulator (ICE) and the Peripheral Circuit Board S5U1C63xxxP:

S5U1C63000H Manual (S1C63 Family In-Circuit Emulator)

Explains the functions and handling methods of the ICE.

S5U1C63xxxP Manual (Peripheral Circuit Board for S1C63xxx)

Covers the functions and handling methods of the peripheral circuit board that provides the hardware specifications of each model to the ICE.

For details of each tool

Chapters 3 to 8 explain the details of each tool. Refer to it if necessary.

Once familiar with this package

Refer to the listings of instructions and commands contained in Appendices.

Manual Notations

This manual was prepared by following the notation rules detailed below:

(1) Sample screens

The sample screens provided in the manual are all examples of displays in classic theme. These displays may vary according to the system or fonts used.

(2) Names of each part

The names or designations of the windows, menus and menu commands, buttons, dialog boxes, and keys are annotated in brackets []. Examples: [Command] window, [File | Exit] menu item ([Exit] command in [File] menu), [Key Break] button, [q] key, etc.

(3) Names of instructions and commands

The CPU instructions and the debugger commands that can be written in either uppercase or lowercase characters are annotated in lowercase characters in this manual, except for user-specified symbols.

(4) Notation of numeric values

Numeric values are described as follows:

Decimal numbers: Not accompanied by any prefix or suffix (e. g., 123, 1000).

Hexadecimal numbers: Accompanied by the prefix "0x" (e. g., 0x0110, 0xffff).

Binary numbers: Accompanied by the prefix "0b" (e. g., 0b0001, 0b10).

However, please note that some sample displays may indicate hexadecimal or binary numbers not accompanied by any symbol. Moreover, a hexadecimal number may be expressed as xxxhx, or a binary number as xxxxb, for reasons of convenience of explanation.

(5) Mouse operations

To click: The operation of pressing the left mouse button once, with the cursor (pointer) placed in the intended location, is expressed as "to click". The clicking operation of the right mouse button is expressed as "to right-click".

To double-click: Operations of pressing the left mouse button twice in a row, with the cursor (pointer) placed in the intended location, are all expressed as "to double-click".

To drag: The operation of clicking on a file (icon) with the left mouse button and holding it down while moving the icon to another location on the screen is expressed as "to drag".

To select: The operation of selecting a menu command by clicking is expressed as "to select".

(6) Key operations

The operation of pressing a specific key is expressed as "to enter a key" or "to press a key".

A combination of keys using "+", such as [Ctrl]+[C] keys, denotes the operation of pressing the [C] key while the [Ctrl] key is held down. Sample entries through the keyboard are not indicated in [].

Moreover, the operation of pressing the [Enter] key in sample entries is represented by ".↵".

In this manual, all the operations that can be executed with the mouse are described only as mouse operations. For operating procedures executed through the keyboard, refer to the Windows manual or help screens.

(7) General forms of commands, startup options, and messages

Items given in [] are those to be selected by the user, and they will work without any key entry involved.

An annotation enclosed in < > indicates that a specific name should be placed here. For example, <file name> needs to be replaced with an actual file name.

Items enclosed in { } and separated with | indicate that you should choose an item. For example, {A | B} needs to have either A or B selected.

(8) Development tool name

ICE: Indicates S5U1C63000H (S1C63 Family In-Circuit Emulator).

Contents

CHAPTER 1	GENERAL	1
1.1	Features	1
1.2	Tool Composition	2
1.2.1	Outline of Software Tools	2
1.3	Working Environment	3
1.4	Installation	4
1.5	Directories and Files after Installation	4
CHAPTER 2	SOFTWARE DEVELOPMENT PROCEDURE	6
2.1	Software Development Flow	6
2.2	Development Using Work Bench	7
2.2.1	Starting Up the Work Bench	7
2.2.2	Creating a New Project	8
2.2.3	Editing Source Files	8
2.2.4	Configuration of Tool Options	10
2.2.5	Building an Executable Object	11
2.2.6	Debugging	12
CHAPTER 3	WORK BENCH	13
3.1	Features	13
3.2	Starting Up and Terminating the Work Bench	13
3.3	Work Bench Windows	14
3.3.1	Window Configuration	14
3.3.2	Window Manipulation	15
3.4	Toolbar and Buttons	19
3.4.1	Standard Toolbar	19
3.4.2	Build Toolbar	20
3.4.3	Window Toolbar	20
3.4.4	Toolbar Manipulation	21
3.4.5	[Insert into project] Button on a [Edit] Window	21
3.5	Menus	22
3.5.1	[File] Menu	22
3.5.2	[Edit] Menu	23
3.5.3	[View] Menu	23
3.5.4	[Insert] Menu	24
3.5.5	[Build] Menu	24
3.5.6	[Tools] Menu	25
3.5.7	[Window] Menu	25
3.5.8	[Help] Menu	25
3.6	Project and Work Space	26
3.6.1	Creating a New Project	26
3.6.2	Inserting Sources into a Project	27
3.6.3	[Project] Window	28
3.6.4	Opening and Closing a Project	28
3.6.5	Files in the Work Space Folder	29
3.7	Source Editor	30
3.7.1	Creating a New Source or Header File	30
3.7.2	Loading and Saving Files	31
3.7.3	Edit Function	32
3.7.4	Tag Jump Function	35
3.7.5	Printing	36

3.8 *Build Task* 36
 3.8.1 *Preparing a Build Task* 36
 3.8.2 *Building an Executable Object* 36
 3.8.3 *Debugging* 37
 3.8.4 *Executing Other Tools* 38
 3.9 *Tool Option Settings* 40
 3.9.1 *Assembler Options* 40
 3.9.2 *Linker Options* 41
 3.9.3 *Debugger Options* 43
 3.9.4 *HEX Converter Options* 43
 3.10 *Work Bench Options* 44
 3.11 *Short-Cut Key List* 45
 3.12 *Error Messages* 45
 3.13 *Precautions* 46

CHAPTER 4 ASSEMBLER 47

4.1 *Functions* 47
 4.2 *Input/Output Files* 47
 4.2.1 *Input File* 47
 4.2.2 *Output Files* 48
 4.3 *Starting Method* 49
 4.4 *Messages* 50
 4.5 *Grammar of Assembly Source* 51
 4.5.1 *Statements* 51
 4.5.2 *Instructions (Mnemonics and Pseudo-instructions)* 53
 4.5.3 *Symbols (Labels)* 54
 4.5.4 *Comments* 56
 4.5.5 *Blank Lines* 56
 4.5.6 *Register Names* 57
 4.5.7 *Numerical Notations* 57
 4.5.8 *Operators* 58
 4.5.9 *Location Counter Symbol "\$"* 60
 4.5.10 *Optimization Branch Instructions for Old Preprocessor* 60
 4.6 *Section Management* 61
 4.6.1 *Definition of Sections* 61
 4.6.2 *Absolute and Relocatable Sections* 61
 4.6.3 *Sample Definition of Sections* 62
 4.7 *Assembler Pseudo-Instructions* 63
 4.7.1 *Include Instruction (#include)* 64
 4.7.2 *Define Instruction (#define)* 65
 4.7.3 *Numeric Define Instruction (#defnum)* 67
 4.7.4 *Macro Instructions (#macro ... #endm)* 68
 4.7.5 *Conditional Assembly Instructions*
 (*#ifdef ... #else ... #endif, #ifndef... #else ... #endif*) 70
 4.7.6 *Section Defining Pseudo-Instructions (.code, .data, .bss)* 72
 4.7.7 *Location Defining Pseudo-Instructions (.org, .align)* 74
 4.7.8 *Absolute Assembling Pseudo-Instruction (.abs)* 77
 4.7.9 *Symbol Defining Pseudo-Instruction (.set)* 78
 4.7.10 *Data Defining Pseudo-Instructions (.codeword, .word)* 79
 4.7.11 *Area Securing Pseudo-Instructions (.comm, .lcomm)* 80
 4.7.12 *Global Declaration Pseudo-Instruction (.global)* 81
 4.7.13 *List Control Pseudo-Instructions (.list, .nolist)* 81
 4.7.14 *Source Debugging Information Pseudo-Instructions (.stabs, .stabn)* 81
 4.7.15 *Comment Adding Function* 82
 4.7.16 *Priority of Pseudo-Instructions* 82

4.8	Relocatable List File	83
4.9	Sample Executions	84
4.10	Error/Warning Messages	87
4.10.1	Errors	87
4.10.2	Warning	88
4.11	Precautions	88
CHAPTER 5	LINKER	89
5.1	Functions	89
5.2	Input/Output Files	89
5.2.1	Input Files	89
5.2.2	Output Files	90
5.3	Starting Method	91
5.4	Messages	94
5.5	Linker Command File	95
5.6	Link Map File	96
5.7	Symbol File	97
5.8	Absolute List File	98
5.9	Cross Reference File	99
5.10	Linking	100
5.11	Branch Optimization Function	102
5.12	Error/Warning Messages	103
5.12.1	Errors	103
5.12.2	Warning	103
5.13	Precautions	104
CHAPTER 6	HEX CONVERTER	105
6.1	Functions	105
6.2	Input/Output Files	105
6.2.1	Input Files	105
6.2.2	Output Files	105
6.3	Starting Method	106
6.4	Messages	107
6.5	Output Hex Files	108
6.5.1	Hex File Configuration	108
6.5.2	Motorola-S Format	108
6.5.3	Intel-HEX Format	109
6.5.4	Conversion Range	109
6.6	Error/Warning Messages	110
6.6.1	Errors	110
6.6.2	Warning	110
6.7	Precautions	110
CHAPTER 7	DISASSEMBLER	111
7.1	Functions	111
7.2	Input/Output Files	111
7.2.1	Input Files	111
7.2.2	Output Files	111

7.3 Starting Method 112

7.4 Messages 113

7.5 Disassembling Output 114

7.6 Error/Warning Messages 117

 7.6.1 Errors 117

 7.6.2 Warning 117

7.7 Precautions 117

CHAPTER 8 DEBUGGER 118

8.1 Features 118

8.2 Input/Output Files 118

 8.2.1 Input Files 118

 8.2.2 Output Files 119

8.3 Starting Method 120

 8.3.1 Start-up Format 120

 8.3.2 Start-up Options 120

 8.3.3 Start-up Messages 121

 8.3.4 Hardware Check at Start-up 121

 8.3.5 Method of Termination 123

8.4 Windows 124

 8.4.1 Basic Structure of Window 124

 8.4.2 [Command] Window 126

 8.4.3 [Source] Window 127

 8.4.4 [Data] Window 129

 8.4.5 [Register] Window 129

 8.4.6 [Trace] Window 130

8.5 Tool Bar 131

 8.5.1 Tool Bar Structure 131

 8.5.2 [Key Break] Button 131

 8.5.3 [Load File] and [Load Option] Buttons 131

 8.5.4 [Source], [Mix], and [Unassemble] Buttons 131

 8.5.5 [Go], [Go to Cursor], [Go from Reset], [Step], [Next],
 and [Reset] Buttons 131

 8.5.6 [Break] Button 132

8.6 Menu 133

 8.6.1 Menu Structure 133

 8.6.2 [File] Menu 133

 8.6.3 [Run] Menu 133

 8.6.4 [Break] Menu 134

 8.6.5 [Trace] Menu 134

 8.6.6 [View] Menu 135

 8.6.7 [Option] Menu 135

 8.6.8 [Windows] Menu 135

 8.6.9 [Help] Menu 135

8.7 Method for Executing Commands 136

 8.7.1 Entering Commands from Keyboard 136

 8.7.2 Executing from Menu or Tool Bar 138

 8.7.3 Executing from a Command File 139

 8.7.4 Log File 140

8.8 Debug Functions 141

 8.8.1 Loading Program and Data Files 141

 8.8.2 Source Display and Symbolic Debugging Function 142

 8.8.3 Displaying and Modifying Program, Data, Option Data and Register 144

 8.8.4 Executing Program 146

8.8.5 Break Functions	149
8.8.6 Trace Functions	152
8.8.7 Operation of Flash Memory	155
8.8.8 Coverage	156
8.8.9 Writing Data to the FPGA on the Standard Peripheral Circuit Board	156
8.9 Command Reference	157
8.9.1 Command List	157
8.9.2 Reference for Each Command	158
8.9.3 Program Memory Operation	159
<i>a / as</i> (assemble mnemonic)	159
<i>pe</i> (program memory enter)	161
<i>pf</i> (program memory fill)	162
<i>pm</i> (program memory move)	163
8.9.4 Data Memory Operation	164
<i>dd</i> (data memory dump)	164
<i>de</i> (data memory enter)	166
<i>df</i> (data memory fill)	168
<i>dm</i> (data memory move)	169
<i>dw</i> (data memory watch)	170
8.9.5 Command to Display Option Information	172
<i>od</i> (option data dump)	172
8.9.6 Register Operation	174
<i>rd</i> (register display)	174
<i>rs</i> (register set)	175
8.9.7 Program Execution	177
<i>g</i> (<i>go</i>)	177
<i>gr</i> (<i>go after reset CPU</i>)	179
<i>s</i> (<i>step</i>)	180
<i>n</i> (<i>next</i>)	182
8.9.8 CPU Reset	183
<i>rst</i> (<i>reset CPU</i>)	183
8.9.9 Break	184
<i>bp</i> (<i>break point set</i>)	184
<i>bc / bpc</i> (<i>break point clear</i>)	186
<i>bd</i> (<i>data break</i>)	187
<i>bdc</i> (<i>data break clear</i>)	189
<i>br</i> (<i>register break</i>)	190
<i>brc</i> (<i>register break clear</i>)	192
<i>bs</i> (<i>sequential break</i>)	193
<i>bsc</i> (<i>sequential break clear</i>)	195
<i>bsp</i> (<i>break stack pointer</i>)	196
<i>bl</i> (<i>break point list</i>)	198
<i>bac</i> (<i>break all clear</i>)	199
8.9.10 Program Display	200
<i>u</i> (<i>unassemble</i>)	200
<i>sc</i> (<i>source code</i>)	202
<i>m</i> (<i>mix</i>)	204
8.9.11 Symbol Information	206
<i>sy</i> (<i>symbol list</i>)	206
8.9.12 Load File	207
<i>lf</i> (<i>load file</i>)	207
<i>lo</i> (<i>load option</i>)	208
8.9.13 Flash Memory Operation	209
<i>lfl</i> (<i>load from flash memory</i>)	209
<i>sfl</i> (<i>save to flash memory</i>)	211
<i>efl</i> (<i>erase flash memory</i>)	213
8.9.14 Trace	214
<i>tm</i> (<i>trace mode display/set</i>)	214
<i>td</i> (<i>trace data display</i>)	216
<i>ts</i> (<i>trace search</i>)	219

<i>tf</i> (trace file)	221
8.9.15 Coverage	222
<i>cv</i> (coverage)	222
<i>cvc</i> (coverage clear)	223
8.9.16 Command File	224
<i>com</i> (execute command file)	224
<i>cmw</i> (execute command file with wait)	225
<i>rec</i> (record commands to a file)	226
8.9.17 log	227
<i>log</i> (log)	227
8.9.18 Map Information	228
<i>ma</i> (map information)	228
8.9.19 Mode Setting	229
<i>md</i> (mode)	229
8.9.20 FPGA Operation	232
<i>xfer/xfers</i> (xilinx fpga data erase)	232
<i>xfwr/xfwrs</i> (xilinx fpga data write)	233
<i>xfcp/xfcps</i> (xilinx fpga data compare)	234
<i>xdp/xdps</i> (xilinx fpga data dump)	235
8.9.21 Quit	236
<i>q</i> (quit)	236
8.9.22 Help	237
<i>?</i> (help)	237
8.10 Status/Error/Warning Messages	238
8.11 Precautions	239

CHAPTER 9 FUNCTION OPTION GENERATOR 240

9.1 Outline of the Function Option Generator <i>winfog</i>	240
9.2 Input/output Files	240
9.3 Using <i>winfog</i>	241
9.3.1 Starting Up	241
9.3.2 Window	242
9.3.3 Menus and Toolbar Buttons	243
9.3.4 Operation Procedure	244
9.4 Error Messages	247
9.5 Precautions	247
9.6 Example Output Files	248

CHAPTER 10 SEGMENT OPTION GENERATOR 249

10.1 Outline of Segment Option Generator <i>winsog</i>	249
10.2 Input/output Files	249
10.3 Using <i>winsog</i>	250
10.3.1 Starting Up	250
10.3.2 Window	252
10.3.3 Menus and Toolbar Buttons	253
10.3.4 Option Selection Buttons	254
10.3.5 Operation Procedure	254
10.4 Error Messages	260
10.5 Precautions	260
10.6 Example Output Files	261

CHAPTER 11 MASK DATA CHECKER	262
11.1 Outline of the Mask Data Checker winmdc	262
11.2 Input/Output Files	262
11.3 Using winmdc	263
11.3.1 Starting Up	263
11.3.2 Menus and Toolbar Buttons	264
11.3.3 Operation Procedure	265
11.4 Error Messages	268
11.5 Precautions	268
11.6 Example Output File	269
APPENDIX QUICK REFERENCE	

CHAPTER 1 GENERAL

1.1 Features

The S1C63 Family Assembler Package contains software development tools that are common to all the models of the S1C63 Family. The package comes as an efficient working environment for development tasks, ranging from source program assembly to debugging.

Its principal features are as follows:

Simple composition

A task from assembly to debugging can be made with minimal tools.

Integrated working environment

A Windows-based integrated environment allows the tool chain to be used on its Windows GUI interface <Workbench wb63>.

Modular programming

The relocatable assembler lets you develop a program which is made up of multiple sources. This makes it possible to keep a common part independently and to use it as a part or a basis for the next program.

Source debugging

A debugger can display an assembler source to show its execution status and allow debugging operations on it. This makes debugging much easier to perform.

Common to all S1C63 chips

The tools included in this package are common to all S1C63 Family models except for several chip dependent masking tools ("Dev" tools). The chip dependent information is read from the ICE parameter file for each chip.

Complete compatibility with old syntax sources

By supporting old syntax, existing sources written for old 63 tools are available with these new tools.

1.2 Tool Composition

1.2.1 Outline of Software Tools

The following shows the outlines of the software tools included in the package:

Assembler (as63.exe)

Converts the mnemonic of the source files into object codes (machine language) of the S1C63000. The results are output in a relocatable object file. This assembler includes preprocessing functions such as macro definition/call, conditional assembly, and file-include functions.

Linker (lk63.exe)

Links the relocatable objects created by the assembler by fixing the memory locations, and creates executable absolute object codes. The linker also provides an auto EXT insertion/correction function allowing the programmer to create sources without having to know branch destination ranges.

Hex converter (hx63.exe)

Converts an absolute object in IEEE-695 format output from the linker into ROM-image data in Motorola-S format or Intel-HEX format. This conversion is needed when making the ROM or when creating mask data using the mask data checker.

Disassembler (ds63.exe)

Disassembles an absolute object file in IEEE-695 format or a hex file in Motorola-S format, and restores it to a source format file. The restored source file can be processed in the assembler/linker/hex converter to obtain the same object or hex file.

Debugger (db63.exe)

This software performs debugging by controlling the ICE hardware tool. Commands that are used frequently, such as break and step, are registered on the tool bar, minimizing the necessary keyboard operations. Moreover, sources, registers, and command execution results can be displayed in multiple windows, with resultant increased efficiency in the debugging tasks.

Work Bench (wb63.exe)

This software provides an integrated development environment with Windows GUI. Creating/editing source files, selecting files and major start-up options, and the start-up of each tool can be made with simple Windows operations.

The tools listed below are Windows GUI applications for creating mask data. A device information definition file (s1c63xxx.ini) is required to run these tools. The CD-ROM contains the device information definition files for the models supported with the following tools. For unsupported models, model specific Development Tools are provided.

Function option generator (winfog.exe)

This tool creates an ICE function option setup file after selecting the mask options of the S1C63xxx and the function option document file that is necessary to generate IC mask patterns. You can create function option data by selecting the appropriate item using the check boxes.

Segment option generator (winsog.exe)

This tool creates an ICE segment option setup file after selecting the segment options of the S1C63xxx and the segment option document file that is necessary to generate IC mask patterns. You can create segment assignment data by merely clicking on the display memory map and segment decode table shown on the window. The winsog is used only for the model that has segment options.

Mask data checker (winmdc.exe)

This tool checks the data in development-completed program ROM/data ROM files and option document files to create the mask data file that will be presented to Seiko Epson.

1.3 Working Environment

To use the S1C63 Family Assembler Package, the following conditions are necessary:

Personal computer

An IBM PC/AT or a compatible machine which is equipped with a CPU equal to or better than a Pentium 75 MHz, and 32MB or more of memory is recommended.

To use the optional In-Circuit Emulator ICE, the personal computer also requires a serial port (with a D-sub 9 pin).

Display

A display unit capable of displaying 800 × 600 dots or more is necessary.

Hard disk

To install the S1C63 Family Assembler Package, a hard disk drive is required.

Mouse

A mouse is necessary to operate the tools.

System software

The S1C63 Family Assembler Package supports Windows. (Refer to Readme_E.txt of S5U1C63000A for details.)

Other development tools

To debug the target program, the optional In-Circuit Emulator and a Peripheral Circuit Board S5U1C63xxxP are needed as the hardware tools.

The S5U1C63xxxP board is prepared for each S1C63 model.

1.4 Installation

To install the tools by the installer (Setup.exe).

To install the tools, start up the "Setup.exe" and follow the instructions in the dialog boxes that will be appeared.

1.5 Directories and Files after Installation

The installer copies the following files in the specified directory (default is "C:\EPSON\S1C63\");

[EPSON\S1C63]	
README_E.TXT	... ReadMe document (English)
README_J.TXT	... ReadMe document (Japanese)
[\BIN]	... S1C63 Family Assembler Package Tool
WB63.EXE	... Work bench
AS63.EXE	... Assembler
LK63.EXE	... Linker
HX63.EXE	... Hex converter
DS63.EXE	... Disassembler
DB63.EXE	... Debugger
...	... Other related files
[\DRIVER]	... ICE USB driver files
[\DEV]	
[\BIN]	... S1C63 Family Development Tool for Windows
WINFOG.EXE	... Function option generator
WINSOG.EXE	... Segment option generator
WINMDC.EXE	... Mask data checker
[\63xxx]	... Model-dependent files
S1C63xxx.INI	... Device information definition file
PAR63xxx.PAR	... Parameter file
C63xxx.FSA	... Sample function option HEX file (for ICE configuration)
C63xxx.SSA	... Sample segment option HEX file (for ICE configuration)
:	
[\WRITER]	
[\OBPW]	
OBPW63.EXE	... On Board Writer Control Software
RW6xxxx.INI	... Device information setup file
[\DRIVER]	
FTDIBUS.INF	... USB driver definition file for USB-Serial On Board Writer
FTDIPOINT.INF	... Serial port driver definition file for On Board Writer
:	* Refer to the technical manual for details of the ROM Writer II and On Board Writer.

```

[\ICE]
  [\FPGA]
    C63xxx.MOT      ... FPGA data to configure standard peripheral circuit board
    :
[\DOC]
  [\ENGLISH]       ... Document folder (English)
    REL_xxxx_E.TXT  ... Tool release note
    s5u1c63000a_xxJ.pdf... This manual in PDF format
  [\JAPANESE]     ... Document folder (Japanese)
    REL_xxxx_J.TXT  ... Tool release note
    s5u1c63000a_xxE.pdf... This manual in PDF format

```

Online manual in PDF format

The online manuals are provided in PDF format, so Adobe Acrobat Reader Ver. 5.0 or later is needed to read it.

Files for future release models

The files for future models may be provided at release. Refer to the Readme file for installation.

CHAPTER 2 SOFTWARE DEVELOPMENT PROCEDURE

This chapter outlines a basic development procedure.

2.1 Software Development Flow

Figure 2.1.1 represents a flow of software development work.




Fig. 2.1.1 Software development flow

The work bench provides an integrated development environment from source editing to debugging. Tools such as the assembler and linker can be invoked from the work bench. The tools can also be invoked individually from the command prompt.


Refer to the respective chapter for details of each tool.

Some models provide other development tools (fog63xxx, sog63xxx, etc.) instead of the "S1C63xxx Development Tool" shown above. Those model dependent tools are not covered in this manual. For details, refer to the tool manual associated with each specific model.


2.2 Development Using Work Bench

This section shows a basic development procedure using the work bench wb63. Refer to Chapter 3, "Work Bench", for operation details.

2.2.1 Starting Up the Work Bench



Start up the work bench by choosing "WorkBench63" from the program menu.




2.2.2 Creating a New Project

The work bench manages necessary file and tool setting information as a project. First a new project file should be created.

1. Select [New] from the [File] menu (or click the [New] button).




The [New] dialog box appears.



2. Select [EPSON Project File] and click [OK].

The [Project] dialog box appears.




3. Enter a project name, select an ICE parameter file and select a directory, then click [OK].

* The [ICE parameter file:] box lists the parameter files that exist in the "dev63" directory.

The work bench creates a folder (directory) with the specified project name as a work space, and puts the project file (.epj) into the folder.

The specified project name will also be used for the absolute object and other files.



Created project [Project] window


2.2.3 Editing Source Files

The work bench has an editor function. This makes it possible to edit source files without another editor. To create a new source file:

1. Select [New] from the [File] menu (or click the [New] button).




The [New] dialog box appears.




2. Select [EPSON Assembly Source File] and click [OK].

A new edit window appears.

[Edit] window



3. Enter source codes in the [Edit] window.



4. Save the source in a file by selecting [Save] from the [File] menu (or clicking the [Save] button).



[Save] button

- Click the [Insert into project] button on the [Edit] window.



The created source file is added in the project.

To add existing source files, use [Files into project...] in the [Insert] menu. It can also be done by dragging source files from Windows Explorer to the project window.

Create necessary source files and add them into the project.



The added source files are listed in the project window. Double-clicking a listed source file name opens the edit window.

2.2.4 Configuration of Tool Options


The work bench supports all the start up options of each tool and they can be selected in a dialog box. A make process for generating an executable object will be configured based on the settings.

In addition to option selection, command files for the linker and debugger can be configured here.

To set tool options:


- Select [Setting...] from the [Build] menu.

A dialog box appears.



- Configure options if necessary.

Check box items can be selected by clicking. Items in the list can be toggled or entered by double-clicking.



Refer to Chapter 3, "Work Bench", for details of the [Settings] dialog box.

2.2.5 Building an Executable Object


To make an executable object file:

1. Select [Build] from the [Build] menu (or click the [Build] button).




[Build] button

This will invoke the assembler and linker to create an executable object file. If a HEX file format (Intel HEX or Motorola S) is selected by the [Output format] box, the HEX converter will be invoked after linking. By default, an absolute object file in IEEE-695 format will be created.



[Output format] box

Messages delivered from each executed tool are displayed in the [Output] window. The work bench has a tag-jump function that jumps to the source line in which an error has occurred by double-clicking a source syntax error message that appears in the [Output] window. It opens the corresponding source window if it is closed.



[Output] window

In the build task, a general make process is executed to update the least necessary files. To rebuild all the files without the make function, select [Rebuild All] from the [Build] menu (or click the [Rebuild All] button).



[Rebuild All] button

To invoke the assembler only to correct syntax errors, select [Assemble] in the [Build] menu (or click the [Assemble] button).



[Assemble] button

2.2.6 Debugging

To debug the executable object:


1. Select [Debug] from the [Build] menu (or click the [Debug] button).



[Debug] button

The debugger starts up with the specified ICE parameter file and then loads the executable object file.

Note: Make sure that the ICE is ready to debug before invoking the debugger. Refer to the ICE hardware manual for settings and startup method of the ICE.



For the debugging functions and operations, refer to Chapter 8, "Debugger".

CHAPTER 3 WORK BENCH

This chapter describes the functions and operating method of the Work Bench wb63.

3.1 Features

The Work Bench wb63 provides an integrated operating environment ranging from editing source files to debugging. Its functions and features are summarized below:

- Source edit function that supports copy/paste, find/replace, print, label jump and tag jump from error messages.
- Allows simple management of all necessary files and information as a project.
- General make process to invoke necessary tools and to update the least necessary files.
- Supports all options of the assembler, linker, HEX converter, disassembler and debugger.
- Windows GUI interface for simple operation.

3.2 Starting Up and Terminating the Work Bench


To start up the work bench



Choose "WorkBench63" from the [Program] menu to start up the work bench.

* If "WorkBench63" is not registered in the [Program] menu, it means that the installation was not successful. Therefore, reinstall the tools .

When the work bench starts up, the window shown below appears.




To terminate the work bench

Select [Exit] from the [File] menu.

3.3 Work Bench Windows

3.3.1 Window Configuration



The work bench has three types of windows: [Edit] window, [Project] window and [Output] window.

[Edit] window

This window is used for editing a source file. A standard text file can also be displayed in this window. Two or more windows can be opened in the edit window area.

When an assembly source file is opened, the source is displayed with in colors according to the contents. The default colors are shown below.

- S1C63 instructions: Black
- Preprocess (#) pseudo-instructions: Dark brown
- Assemble (.) pseudo-instructions: Blue
- Labels: Light brown
- Comments: Green

These colors can be changed by the [Tools | Options] menu command (refer to Section 3.10).

[Project] window

This window shows the currently opened work space folder and lists all the source files in the project, with a structure similar to Windows Explorer.

Double-clicking a source file icon opens the source file in the [Edit] window.

[Output] window

This window displays the messages delivered from the executed tools in a build or assemble process. Double-clicking a syntax error message with a source line number displayed in this window activates or opens the [Edit] window of the corresponding source so that the source line in which the error has occurred can be viewed.

Menu bar

Refer to Section 3.5.

Toolbar

Refer to Section 3.3.

Status bar


Shows help messages when the mouse cursor is placed on a menu item or a button.

It also indicates the cursor position in the [Edit] window and Key lock status (Num lock, Caps lock, Scroll lock).

3.3.2 Window Manipulation

Resizing the windows


Each window area can be resized by dragging the window boundary. The size information is saved when the work bench is terminated. So the same window layout will appear at the next time the work bench starts up.



Double click

Floating and docking the [Project] and [Output] window

The [Project] window and the [Output] window can be made a floating window by double-clicking the window boundary and the floating window can be moved and resized in the work bench window. The floating window will be restored to a docking window by double clicking the window's title bar or dragging the title bar towards an edge of the work bench window.



Closing the [Project] and [Output] window

The [Project] window and the [Output] window can be closed by selecting [Project Window] and [Output Window] from the [View] menu, respectively. To open them, select the menu items again.

Maximizing the [Edit] window area

```

Goto Label:
1 |; main.s
2 |; ASM63 test program (main routine)
3 |
4 |
5 |***** INITIAL SP1 & SP2 ADDRESS DEFINITION *****
6 |
7 |#ifdef SMALL_RAM
8 |    .set SP1_INIT_ADDR 0xb      ;SP1 init addr = 0x2c
9 |#else
10 |    .set SP1_INIT_ADDR 0x4b     ;SP1 init addr = 0x12c
11 |#endif
12 |
13 |    .set SP2_INIT_ADDR 0x1f     ;SP2 init addr = 0x1f
14 |
15 |
16 |***** NMI & BOOT, LOOP *****
17 |
18 |    .global INIT_RAM_BLK1      ; subroutine in sub.s
19 |    .global INC_RAM_BLK1      ; subroutine in sub.s
20 |
21 |    .org 0x100
22 |NMI:    calr  INIT_RAM_BLK1     ; initialize RAM block 1
23 |        reti                  ; in NMI(watchdog timer)
24 |
25 |
26 |    .org 0x110
27 |BOOT:
28 |    ldb  %ba,SP1_INIT_ADDR
29 |    ldb  %sp1,%ba              ; set SP1
30 |    ldb  %ba,SP2_INIT_ADDR
31 |    ldb  %sp2,%ba              ; set SP2
32 |    calr INIT_RAM_BLK1        ; initialize RAM block 1
33 |
34 |LOOP:   calr  INC_RAM_BLK1     ; increment RAM block 1
35 |        jr   LOOP            ; infinity loop
36 |
37 |***** RAM block *****
    
```

The [Edit] window area can be maximized to the full screen size by selecting [Full Screen] from the [View] menu. All other windows and toolbars are hidden behind the [Edit] window area. To return it to the normal display, click the button that appears on the screen. This button can be moved anywhere in the screen by dragging its title bar. Pressing the [ESC] key also returns the window to the normal display.

Opening/Closing [Edit] windows

An [Edit] window opens when a source file (text file) is loaded using a menu, button or a file icon in the [Project] window, or when a new source is created.

[Edit] windows close by clicking the [Close] box of each window or selecting [Close] from the [File] menu.

When a project file is saved, the [Edit] window information (files opened, size and location) is also saved. So the next time the project opens, editing can begin in the saved condition.

Arrangement of the [Edit] windows


The [Edit] windows being opened can be arranged similar to standard Windows applications.

1 Cascade windows

Select [Cascade] from the [Window] menu or click the [Cascade Windows] button.




[Cascade Windows] button



2 Tile windows

To tile windows vertically, select [Tile Vertically] from the [Window] menu or click the [Tile Vertically] button.

 [Tile Vertically] button




```

main.s
-----
1  ; main.s
2  ; AS63 test program (main routine)
3  ;
4  ;
5  ;***** INITIAL SP1 & SP2 ADDRESS DEFINITION *****
6  ;
7  #ifdef SMALL_RAM
8      .set SP1_INIT_ADDR, SP1_INIT_ADDR
9  #else
10     .set SP1_INIT_ADDR, SP1_INIT_ADDR
11 #endif
12
13     .set SP2_INIT_ADDR, SP2_INIT_ADDR
14

sub.s
-----
1  ; sub.s
2  ; AS63 test program (subroutine)
3  ;
4  ;
5  ;***** RAM block 1 initialization *****
6  ;
7  ;
8  .global INIT_RAM_BLK1
9  INIT_RAM_BLK1:
10     ldb    %ext, RAM_BLK1
11     ldb    %x1, RAM_BLK1
12     ld     [%x]+, 0x0
13     ld     [%x]+, 0x0
14     ld     [%x]+, 0x0
  
```

To tile windows horizontally, select [Tile Horizontally] from the [Window] menu or click the [Tile Horizontally] button.

 [Tile Horizontally] button



```

main.s
-----
1  ; main.s
2  ; ASM63 test program (main routine)
3  ;
4  ;
5  ;***** INITIAL SP1 & SP2 ADDRESS DEFINITION *****

sub.s
-----
1  ; sub.s
2  ; ASM63 test program (subroutine)
3  ;
4  ;
5  ;
6  ;
7  .global RAM_BLK1
  
```

3 Maximizing an [Edit] window

Click the [Maximize] button on the window title bar. The window will be maximized to the [Edit] window area size and other [Edit] windows will be hidden behind the active window.

```

1 ; main.s
2 ; ASM63 test program (main routine)
3 ;
4 ;
5 ;***** INITIAL SP1 & SP2 ADDRESS DEFINITION *****
6 ;
7 #ifdef SMALL_RAM
8     .set SP1_INIT_ADDR 0xb           ;SP1 init addr = 0x2c
9 #else
10    .set SP1_INIT_ADDR 0x4b          ;SP1 init addr = 0x12c
11 #endif
12 ;
13     .set SP2_INIT_ADDR 0x1f         ;SP2 init addr = 0x1f
14 ;
15 ;
16 ;***** NMI & BOOT, LOOP *****
17 ;
    
```

4 Minimizing an [Edit] window

Click the [Minimize] button on the window title bar. The window will be minimized as a window icon. The minimized icons can be arranged at the bottom of the [Edit] window area by selecting [Arrange Icons] from the [Window] menu.



5 Moving and resizing an [Edit] window

The [Edit] window allows changing of its location and its size in the same way as the standard Windows applications if it is not maximized.

Switching active [Edit] window

Click the window to be activated if it can be viewed. Otherwise, select the window name (source file name) from the currently-opened window list in the [Window] menu.

Scrolling display contents

A standard scroll bar appears if the display contents exceed the display size of a window. Use it to scroll the display contents. The arrow keys can also be used.

Showing and hiding the status bar

The status bar can be shown or hidden by selecting [Status Bar] from the [View] menu.

3.4 Toolbar and Buttons

Three types of toolbars have been implemented in the work bench: standard toolbar, build toolbar and window toolbar.



3.4.1 Standard Toolbar

This toolbar has the following standard buttons:

- 
[New] button
 Creates a new document. A dialog box will appear allowing selection from among three document types: assembly source, assembly header and project.
- 
[Open] button
 Opens a document. A dialog box will appear allowing selection of the file to be opened.
- 
[Save] button
 Saves the document in the active [Edit] window to the file. The file will be overwritten. This button becomes inactive if no [Edit] window is opened.
- 
[Save All] button
 Saves the documents of all [Edit] windows and the project information to the respective files.
- 
[Cut] button
 Cuts the selected text in the [Edit] window to the clipboard.
- 
[Copy] button
 Copies the selected text in the [Edit] window to the clipboard.
- 
[Paste] button
 Pastes the text copied on the clipboard to the current cursor position in the [Edit] window or replaces the selected text with the copied text.
- 
[Find] button
 Finds the specified word in the active [Edit] window. A dialog box will appear allowing specification of the word to be found and a search condition.
- 
[Find Next] button
 Finds next target word towards the end of the file.
- 
[Find Previous] button
 Finds next target word towards the beginning of the file.
- 
[Print] button
 Prints the document in the active [Edit] window. A standard print dialog will appear allowing a specific print condition.
- 
[Help] button
 Displays the help window.

3.4.2 Build Toolbar

This tool bar has the following buttons and list boxes used to build a project:



[Assemble] button

Assembles the assembly source in the active [Edit] window. This button becomes active only when the active [Edit] window shows an assembly source file.



[Build] button

Builds the currently opened project using a general make process.



[Rebuild All] button

Builds the currently opened project. All the source files will be assembled regardless of whether they are updated or not.




[Stop Build] button

Stops the build process being executed. This button becomes active only while a build process is being executed.



[ICE Parameter] pull-down list box

Selects the ICE parameter file for the model being developed. In this box, all the ICE parameter files that exist in the "Dev63" directory are listed.



[Output Format] pull-down list box

Selects an executable object file format. Three types of formats are available: IEEE-695 absolute object format, Intel HEX format and Motorola S format. The build process will generate an executable object in the format selected here.



[HEX Convert] button

Invokes the HEX converter to convert an absolute object into an Intel HEX object or a Motorola S object. A dialog box will appear allowing selection of an absolute object and options of the HEX converter.



[Disassemble] button

Invokes the disassembler to disassemble an absolute object. A dialog box will appear allowing selection of an absolute object and options of the disassembler.



[Debug] button

Invokes the debugger with the specified ICE parameter file.

3.4.3 Window Toolbar

This tool bar has the following buttons used in window manipulation:



[Cascade] button

Cascades the opened [Edit] windows.



[Tile Horizontally] button

Tiles the opened [Edit] window horizontally.



[Tile Vertically] button

Tiles the opened [Edit] window vertically.

3.4.4 *Toolbar Manipulation*

Hiding and showing toolbars

Each toolbar can be hidden if not needed. Select the toolbar name from the [View] menu. This operation toggles between hiding and showing the toolbar.

Changing the toolbar location

Toolbars can be moved to another location in the toolbar area by dragging them. If a toolbar is moved out of the toolbar area, it will be changed to a window.

3.4.5 *[Insert into project] Button on a [Edit] Window*



[Insert into project] button

When a source file (.s or .ms) is opened, the [Insert into project] button appears on the [Edit] window. It can be used to insert the source file into the current opened project.

For other file types, the [Edit] window opens without the [Insert into project] button.

3.5 Menus

File Edit View Insert Build Tools Window Help

3.5.1 [File] Menu

File	
New...	Ctrl+N
Open...	Ctrl+O
Close	
Open Workspace...	
Close Workspace	
Save	Ctrl+S
Save As...	
Save All	
Print...	Ctrl+P
Print Preview	
Page Setup...	
1 sub.s	
2 main.s	
5 test.epj	
Exit	

The file names listed in this menu are recently used source and project files. Selecting one opens the file.

The number of files to be listed can be selected by the [Tools | Options] menu command.

[New...] ([Ctrl]+[N])

Creates a new document. A dialog box will appear allowing selection from among three document types: assembly source, assembly header and project.

[Open...] ([Ctrl]+[O])

Opens a document. A dialog box will appear allowing selection of the file to be opened.

[Close]

Closes the active [Edit] window. This menu item appears when an [Edit] window becomes active.

[Open Workspace...]

Opens a project. A dialog box will appear allowing selection of the project to be opened.

[Close Workspace]

Closes the currently opened project. This menu item becomes inactive if no project is opened.

[Save] ([Ctrl]+[S])

Saves the document in the active [Edit] window to the file. The file will be overwritten. This menu item appears when an [Edit] window becomes active.

[Save As...]

Saves the document in the active [Edit] window with another file name. A dialog box will appear allowing specification of a save location and a file name. This menu item appears when an [Edit] window becomes active.

[Save All]

Saves the documents of all [Edit] windows and the project information to the respective files.

[Print...] ([Ctrl]+[P])

Prints the document in the active [Edit] window. A standard [print] dialog box will appear allowing a specific print condition. This menu item appears when an [Edit] window becomes active.

[Print Preview]

Displays a print image of the document in the active [Edit] window. This menu item appears when an [Edit] window becomes active.

[Page Setup...]

Displays a dialog box for selecting paper and printer.

3.5.2 [Edit] Menu

Edit	
U <u>ndo</u>	Ctrl+Z
C <u>u</u> t	Ctrl+X
C <u>o</u> py	Ctrl+C
P <u>a</u> ste	Ctrl+V
S <u>e</u> lect A <u>l</u> l	Ctrl+A
<hr/>	
F <u>i</u> nd...	Ctrl+F
R <u>e</u> place	Ctrl+H
G <u>o</u> To	Ctrl+G

[Undo] ([Ctrl]+[Z])

Undoes the previous executed operation in the [Edit] window.

[Cut] ([Ctrl]+[X])

Cuts the selected text in the [Edit] window to the clipboard.

[Copy] ([Ctrl]+[C])

Copies the selected text in the [Edit] window to the clipboard.

[Paste] ([Ctrl]+[V])

Pastes the text copied on the clipboard to the current cursor position in the [Edit] window or replaces the selected text with the copied text.

[Select All] ([Ctrl]+[A])

Selects all text in the active [Edit] window.

[Find...] ([Ctrl]+[F])

Finds the specified word in the active [Edit] window. A dialog box will appear allowing specification of the word to be found and a search condition.

[Replace] ([Ctrl]+[H])

Replaces the specified words in the active [Edit] window with one another. A dialog box will appear allowing specification of the words.

[Go To] ([Ctrl]+[G])

Jumps to the specified line or label in the active [Edit] window. A dialog box will appear allowing specification of a line number or a label name.

3.5.3 [View] Menu

View	
✓ Standard Bar	
✓ S <u>t</u> atus Bar	
✓ O <u>u</u> tput Window	
✓ P <u>r</u> oject Window	
✓ B <u>i</u> ld Bar	
✓ W <u>i</u> ndow Bar	
<hr/>	
Full Screen	

[Standard Bar]

Shows or hides the standard toolbar.

[Status Bar]

Shows or hides the status bar located at the bottom of the work bench window.

[Output Window]

Opens or closes the [Output] window.

[Project Window]

Opens or closes the [Project] window.

[Build Bar]

Shows or hides the build toolbar.

[Window Bar]

Shows or hides the window toolbar.

[Full Screen]

Maximizes the [Edit] window area to the full screen size.

3.5.4 [Insert] Menu




[File...]

Inserts the specified file to the current cursor position in the [Edit] window or replaces the selected text with the contents of the specified file. A dialog box will appear allowing selection of the file to be inserted.

[Files into project...]

Adds the specified source file in the currently opened project. A dialog box will appear allowing selection of the file to be added.

3.5.5 [Build] Menu



[Assemble] ([Ctrl]+[F7])

Assembles the assembly source in the active [Edit] window. This menu item becomes active only when the active [Edit] window shows an assembly source file.

[Build] ([F7])

Builds the currently opened project using a general make process.

[Rebuild All]

Builds the currently opened project. All the source files will be assembled regardless of whether they are updated or not.

[Stop Build] ([Ctrl]+[Break])

Stops the build process being executed. This button become active only while a build process is being executed.

[Debug] ([F5])

Invokes the debugger with the specified ICE parameter file.

[Settings...] ([Alt]+[F7])

Displays a dialog box for selecting tool options.

[ICE parameter file...]

Displays a dialog box for selecting an ICE parameter file.

[Output Format...]

Displays a dialog box for selecting an executable object file format. Three types of formats are available: IEEE-695 absolute object format, Intel HEX format and Motorola S format. The build process will generate an executable object in the format selected here.

3.5.6 [Tools] Menu



[HEX Converter...]

Invokes the HEX converter to convert an absolute object into an Intel HEX object or Motorola S object. A dialog box will appear allowing selection of an absolute object and options for the HEX converter.

[Disassembler...]

Invokes the disassembler to disassemble an absolute object. A dialog box will appear allowing selection of an absolute object and options for the disassembler.

[WinFOG]

Invokes the function option generator winfog.

[WinSOG]

Invokes the segment option generator winsog.

[WinMDC]

Invokes the mask data checker winmdc.


[OBPW63]

Invokes the On Board Writer control software.

[Options...]

Displays a dialog box for selecting work bench options such as character colors in the [Edit] window and a printing font.

3.5.7 [Window] Menu



This menu appears when an [Edit] window is opened.

[Cascade]

Cascades the opened [Edit] windows.

[Tile Horizontally]

Tiles the opened [Edit] window horizontally.

[Tile Vertically]

Tiles the opened [Edit] window vertically.


[Arrange Icons]

Arranges the minimized [Edit] window icons at the bottom of the [Edit] window area.

[Close All]

Closes all the [Edit] windows opened.

3.5.8 [Help] Menu



[About WB63...]

Displays a dialog box showing the version of the work bench.

3.6 Project and Work Space

The work bench manages a program development task using a work space folder and a project file that contains file and other information necessary for invoking the development tools.


3.6.1 Creating a New Project

A new project file can be created by the following procedure:

1. Select [New] from the [File] menu or click the [New] button.




The [New] dialog box appears.



2. Select [EPSON Project File] and click [OK].

The [Project] dialog box appears.



3. Enter a project name, select an ICE parameter file and select a directory, then click [OK].

* The [ICE parameter file:] box lists the parameter files that exist in the "dev" directory.

The work bench creates a folder (directory) with the specified project name as a work space, and puts the project file (.epj) into the folder.

If a folder which has the same name as that of a specified one already exists in the specified location, the work bench uses the folder as the work space. Thus you can specify a folder in which sources are created. The specified project name will also be used for the absolute object and other files.


3.6.2 Inserting Sources into a Project

The sources created must be inserted into the project.

To insert a source into a project, use one of the four methods shown below:

1. [Insert | Files into project...] menu item

A dialog box appears when this menu item is selected.




Choose a source file from the list box and then click [Open].

Note: When selecting multiple source files at the same time, ensure the total number of characters in the file name does not exceed 256.

2. [File | Open...] menu item or [Open] button




A dialog box appears when this menu item or button is selected.



Choose a source file from the list box and select the [Into project] button, then click [Open].

3. [Insert into project] button on the [Edit] window



When the source file has been opened, click the [Insert into project] button on the [Edit] window. Do not forget to save the source to the file before inserting into the project.

4. Dragging source files on the [Project] window

Drag source files from Windows Explorer to the [Project] window. These files will be added to the current project.

When a source file is inserted into the project, the source file name appears in the [Project] window.

Removing a source from the project


To remove a source file from the project, select the source in the [Project] window and then press the [Delete] key. This removes only the source information, and does not delete the actual source file.

3.6.3 [Project] Window

The [Project] window shows the work space folder and the source files included in the project that has been opened.




When a source file icon is double-clicked, the source file will be opened or the corresponding [Edit] window will be activated.



Shortcut menu in the [Project] window

When the folder icon or a source file icon is clicked with the right mouse button, a shortcut menu including the available build menu items appears.


[Properties...] shows the source file information as follows:



Note: Note that the list in the [Project] window is not the actual directory structure. Sources of the project in other folders than the work space folder are also listed as they exist in the work space folder.

3.6.4 Opening and Closing a Project

To open a project, select [Open WorkSpace...] from the [File] menu. A dialog box appears allowing selection of a project file.



The work bench allows only one project to be opened at a time. So if a project has been opened, it will be closed when another project is opened. At this time, a dialog box appears to select whether the current project file is to be saved or not if it has not already been saved after a modification.

The project file can also be opened by selecting [Open] from the [File] menu or clicking the [Open] button. In this case, choose the file type as Project Files (*.epj) in the file open dialog box.

To close the currently opened project file, select [Close WorkSpace] from the [File] menu. At this time, a dialog box appears to select whether the current project file is to be saved or not if it has not already been saved after a modification. If [Yes] (save) is selected in this dialog box, all the modification items including sources, tool settings and window configuration will be saved.

3.6.5 Files in the Work Space Folder

The work bench generates the following files in the work space folder:

<file>.epj Project file

This file contains the project information.

<file>.cm Linker command file

This file is generated when a build task is started, and is used by the linker to generate an absolute object file.

Example:

```
; S1C WorkBench Generated
; Thursday, November 05, 1998

"C:\EPSON\S1C63\DEV\63A08\PAR63A08.PAR"          ;ICE parameter file
-o "test.abs"          ;output file : absolute object

; linked object file(s)
"sub.o"
"main.o"
```

The contents vary according to the source files included in the project and the linker option setting.

<file>.cmd Debugger startup command file

This file is generated when a build task is started, and is used by the debugger to execute the command in this file when it is started up.

Example:

```
lf "test.abs"
```

The work bench generates this file so that the executable file according to the format selection is loaded when the debugger starts up.

<file>.mak "make" file for build task

This file is generated when a build task is started, and is used for the build process in the work bench.

Example:

```
# S1C WorkBench Generated
# Thursday, November 05, 1998

ASM = as63.exe
LINK = lk63.exe
HEX = hx63.exe
ASM_FLG = -g
LINK_FLG = -g
HEX_FLG =

ALL : test.abs

test.abs : test.cm sub.o main.o
          $(LINK) $(LINK_FLG) test.cm

sub.o : C:\EPSON\S1C63\Test\sub.s
        $(ASM) $(ASM_FLG) C:\EPSON\S1C63\Test\sub.s

main.o : C:\EPSON\S1C63\Test\main.s
        $(ASM) $(ASM_FLG) C:\EPSON\S1C63\Test\main.s
```

This is a generic make file that contains macro setting and dependency list.

The following files are generated by the development tools during a build process:

<file>.o	Relocatable object files (generated by the assembler)
<file>.abs	Absolute object file (generated by the linker)
<file>.hsa, <file>.lsa, <file>.csa	Motorola S files (generated by the HEX converter when this format is specified in the work bench)
<file>.h.hex, <file>.l.hex, <file>.c.hex	Intel HEX files (generated by the Hex converter when this format is specified in the work bench)

3.7 Source Editor

The work bench has a source editor function. Sources can be created and modified in the [Edit] window.


3.7.1 Creating a New Source or Header File

To create a new source file:

1. Select [New] from the [File] menu or click the [New] button.




The [New] dialog box appears.



2. Select [EPSON Assembly Source File] and click [OK].

An [Edit] window appears.



Enter source codes in this window.

The [New] dialog box allows selection of the [EPSON Header File]. Select it when creating a header file for constant definitions.


3.7.2 Loading and Saving Files

To load a source file:


1. Select [Open...] from the [File] menu or click the [Open] button.



The [Open] dialog box appears.



2. Choose a source file to be opened after selecting the file type, "Assembly Source Files (*.s, *.ms)", and click [OK]. An [Edit] window opens and shows the contents of the source file.




To save the source:

1. Activate the [Edit] window of the source to be saved.
2. Select [Save as...] from the [File] menu.
The [Save As] dialog box appears.



3. Enter the file name and then click [OK].

When overwriting the source on the existing file, select [Save] from the [File] menu or click the [Save] button.



[Save] button

To save all the source files opened and the project file, use the [File | Save All] menu item or the [Save All] button.



[Save All] button

3.7.3 Edit Function

The source editor has general text editing functions similar to standard Windows applications.

Editing text

Basic text editing function is the same as general Windows applications.

Cut, copy and paste are supported in the [Edit] menu and with the toolbar buttons. These commands are available only in the [Edit] window.

Undo can be selected from the [Edit] menu.

The tab stops are set at every 8 characters.

Find, replace and go to

Any words can be searched in the active [Edit] window.

Find

To find a word, select [Find...] from the [Edit] menu or click the [Find] button.



[Find] button

The [Find] dialog box appears.



The controls in the dialog are as follows:

[Find what:] text box

Enter the word to be found in this text box. The specified word is maintained as the finding word even if this dialog box is closed.

[Match whole word only] check box

If this option is selected, the work bench searches only the words that are completely matched with the specified word. If not, only the part of word that matches the specified word will be searched.

[Match case] check box

If this option is specified, a case-sensitive search is performed. If not, a case-insensitive search is performed.

[Direction] option

If the [Up] radio button is selected, the specified word is searched toward to the beginning of the file. If the [Down] radio button is selected, a search is performed toward to the end of the file.

[Find Next] button

Clicking this button starts searching the specified word. If the specified word is found, the [Edit] window refreshes the display and highlights the word found.

[Cancel] button

Clicking this button closes the dialog box.

Once a word to be found is specified in the [Find] dialog box, the [Find Next] and [Find Previous] buttons on the toolbar can be used for a forward or backward search.




[Find Next] button



[Find Previous] button

Replace

To replace a word with another one, select [Replace] from the [Edit] menu. The [Replace] dialog box appears.



The controls in the dialog are as follows:

[Find what:] text box

Enter the word to be found in this text box. If a word has been specified in the [Find] dialog box, it appears in this box.

[Replace with:] text box

Enter the substitute word in this box.

[Match whole word only] check box

If this option is selected, the work bench searches only the words that are completely matched with the specified word. If not, only the part of word that matches the specified word will be searched.

[Match case] check box

If this option is specified, a case-sensitive search is performed. If not, a case-insensitive search is performed.

[Find Next] button

Clicking this button starts searching the specified word. If the specified word is found, the [Edit] window refreshes the display and highlights the word found.

[Replace] button

By clicking this button after the specified word is found, it is replaced with the substitute word. Then the work bench searches the next.

[Replace All] button

Replaces all the specified found words with the substitute word. Note that undo function cannot be performed for this operation except for the last replaced word.

[Cancel] button


Clicking this button closes the dialog box.

Go to

You can go to any source line or any label position quickly.

To do this, select [Go To] from the [Edit] menu.

The [Go To] dialog box appears.




Going to a source line

1. Select "Line" in the [Go to what:] list box.
2. Type a line number in the [Enter Line Number] box and then click the [Go To] button.

Going to a label position

1. Select "Label" in the [Go to what:] list box.
The [Enter Line Number] box changes to the [Select Label] list box.



2. Select a label from the [Select Label] box and then click the [Go To] button.

The [Select Label] list box has a pull-down menu that contains the list of labels defined in the current source file.

The [Edit] windows for source files (*.s, *.ms) have the [Go To Label] list box similar to the [Select Label] list box in the [Go To] dialog box. You can also go to a label position using this box.




Inserting a file

To insert a file such as a header file and another source at the cursor position of the current source, select [File...] from the [Insert] menu.

A dialog box will appear allowing selection of the file to be inserted.

Shortcut menu


The [Edit] window supports a short cut menu that appears by clicking the right mouse button on the [Edit] window. It can also be done by pressing the [Short cut menu] key while the [Edit] window is active if the key is available on the keyboard. It contains the editing menu items described above, so you can select an edit command using this menu.



3.7.4 Tag Jump Function

When assembler syntax errors occur during assembling, their error messages are displayed in the [Output] window. In this case, you can go to the source line in which an error has occurred by double-clicking the error message in the [Output] window.

However, this function is available only when the error message contains a source line number.



3.7.5 Printing

The document in the [Edit] window can be printed out.

The [Print...], [Print Preview] and [Page Setup...] commands are provided in the [File] menu. The [Print] button can also be used. They have the same function as those of standard Windows application.

Select one after activating the [Edit] window of the document to be printed.

3.8 Build Task

By using the [Build] menu or [Build] toolbar, the assembler, linker, debugger, HEX converter and disassembler can be executed from the work bench.

In the work bench, process to generate an executable object from the source files is called a build task.

For details of each development tool, refer to the respective chapter.

3.8.1 Preparing a Build Task

Before starting a build task, necessary source files should be prepared and tool options should be configured.

1. Create a new project. (Refer to Section 3.6.1.)
2. Select an ICE parameter file. (Refer to Section 3.6.1.)
3. Create source files and add them into the project. (Refer to Sections 3.7 and 3.6.2.)
4. Select tool options (Refer to Section 3.9.)

3.8.2 Building an Executable Object

To generate an executable object:

1. Open the project file.
2. Select an output format (absolute, Intel HEX or Motorola S) using the [Output Format] list box.



3. Select [Build] from the [Build] menu or click the [Build] button.



[Build] button

The work bench generates a make file according to the source files in the project and the tool options set by the user. This file is used to control invocation of tools.

First, the make process invokes the assembler for each source file to be assembled. If the latest relocatable object file exists in the work space, the corresponding source file is not assembled to reduce process time. Next, the linker is invoked to generate an absolute object file. The linker command file used in this phase is automatically generated.

If absolute object has been selected as the output format, the build task is completed at this phase. If Intel HEX or Motorola S has been selected, the HEX converter will be invoked to generate an object in the specified format.

To rebuild all files including the latest relocatable object files, select [Rebuild All] from the [Build] menu or click the [Rebuild All] button.




[Rebuild All] button

The build task can be suspended by selecting [Stop Build] from the [Build] menu or clicking the [Stop Build] button.



[Stop Build] button

To invoke only the assembler, select [Assemble] from the [Build] menu or click the [Assemble] button after activating the [Edit] window of the source to be assembled.



[Assemble] button

3.8.3 Debugging

To debug the generated executable file, select [Debug] from the [Build] menu or click the [Debug] button.




[Debug] button

The debugger starts up with the specified ICE parameter file and then loads the executable object by the command file generated from the work bench.

This command file contains the command to load the specified type of an executable object to the debugger. The contents of the command file can be edited in the [Settings] dialog box explained in Section 3.9.

* When the building process is performed again after invoking the debugger, the debugger will reload the object file if its window can be activated.




Refer to Chapter 8, "Debugger", for operating the debugger.

3.8.4 Executing Other Tools


The HEX converter and disassembler can be invoked independently. The mask data creation tools can also be invoked from wb63.

HEX converter

To invoke the HEX converter, select [HEX converter...] from the [Tools] menu or click the [HEX convert] button.



Then select an absolute object file to be converted in the [Hex data convert] dialog box.



This dialog box allows selection of the HEX converter options.

[ICE Parameter file:] list box

Select an ICE parameter file from the pull-down list.

[Output Format:] list box

Select an output format from between Intel HEX and Motorola S.

[Output error log file] check box

Select this option to generate the error log file of the HEX converter.

[Do not fill room with 0xFF] check box

Select this option when not filling the unused program area with 0xFF.


After selecting an absolute object and options, click the [Open] button. The HEX converter starts up and converts the selected object into the specified format. The messages delivered from the HEX converter are displayed in the [Output] window.

Disassembler

To invoke the disassembler, select [Disassembler...] from the [Tools] menu or click the [Disassemble] button.

 [Disassemble] button

Then select the executable object file to be disassembled in the [Disassemble] dialog box.



This dialog box allows selection of the disassembler options.

[Output error log file] check box

Select this option to generate the error log file of the disassembler.

[Output Option]

Select a character case option using the radio buttons.

When [Default] is selected, the disassembled source will be made with all labels in upper-case characters and instructions in lower-case characters.

When [Upper case] is selected, the source will be made with upper-case characters only.

When [Lower case] is selected, the source will be made with lower-case characters only.

After selecting an executable object and options, click the [Open] button. The disassembler starts up and converts the selected object into the source file. The messages delivered from the disassembler are displayed in the [Output] window.

Function option generator, segment option generator, mask data checker and On Board Writer control software

The [Tools] menu allows invocation of the following tools:


- [WinFOG] Function option generator winfog (Chapter 9)
- [WinSOG] Segment option generator winsog (Chapter 10)
- [WinMDC] Mask data checker winmdc (Chapter 11)
- [OBPW63] On Board Writer control software (See technical manual.)

Refer to the respective chapter or technical manual for how to use each tool.

Note: These tools do not support some models (no device information definition file is provided). In this case, other tools are provided for each model. However those tools cannot be invoked from the [Tools] menu.

3.9 Tool Option Settings

The development tools have startup options that can be specified when invoking them. These settings can be made in the [Settings] dialog box that appears by selecting [Settings...] from the [Build] menu.




Click the tool name tab to view option settings of each tool.

Clicking the [OK] button updates option setting information in the project and then closes the dialog box. To continue to select other tool options, click the [Apply] button. This does not close the dialog box.

Clicking the [Cancel] button closes the dialog box.

3.9.1 Assembler Options



In this dialog, the following four assembler options can be selected.

- [Error file] Output of an error file (No: Not output, Yes: Output)
- [Debug info] Addition of debugging information to the relocatable object (No: Not added, Yes: Added)
- [List file] Output of the relocatable list file (No: Not output, Yes: Output)
- [Defines] Name definition for conditional assembly (Enter a define name.)

The edit box shows the default setting ([Default]) and the list of source files in the project. The default setting applies to all the sources excluding ones that are specified independently. To select options of a specific source, select the check box at the front of the source file name.

Check here → sub.s No No No

Each of the [Error file], [Debug info] and [List file] options is set to either "No" or "Yes" and it toggles by double-clicking. For example, to change the default [List file] option from "No" to "Yes", double click "No" in the [Default] line. It changes to "Yes".

Source	Error file	Debug info	List file	Defines
[Default]	No	Yes	No	← Double-click here. It will be changed to Yes.


To define a name for conditional assembly, double-clicking the [Defines] part.

Source	Error file	Debug info	List file	Defines
[Default]	No	Yes	No	← Double-click here, then type a define name.

An text box appears. Type a name in the box. If two or more names are to be entered, separate each name with a comma (,).

Refer to Chapter 4, "Assembler", for details of the assembler options.

3.9.2 Linker Options



In this dialog, section allocation, symbol definition and other linker options can be specified. The work bench generates a linker command file including these specifications, and specifies it when invoking the linker.

Specifying section allocation

This option is set by default as all the sections will be allocated from the memory start address. To specify a section start address, double click the cell and then enter the address.

Source	BSS	CODE	DATA
<input type="checkbox"/> [Default]			

← Double-click here to change default CODE section start address, then type an address.

Source	BSS	CODE	DATA
<input checked="" type="checkbox"/> [Default]		0x100	

The edit box shows the default setting ([Default]) and the list of source files in the project. The default setting applies to all the sections excluding those of the source specified. To set a specific source independently, select the check box at the front of the source file name.

Check here → sub.s 0x200

Symbol definition

To define a symbol, click the [New] button and then enter the symbol name and address in the edit box.

Symbol Addr
[] [] ← Enter a symbol name and the address.

To modify a symbol name or address, double click the name or the address in the edit box and then enter a new name or address.

Symbol Addr
TEST 0x0000 ← Double-click to modify.

To delete a symbol, highlight the symbol line by clicking and then click the [Delete] button.

Other option selections

[Disable all branch optimization] check box
Select this option if extension code insertions, deletions and corrections are not necessary.

[Disable insertion of branch extension] check box
Select this option if extension code insertions are not necessary.

[Output Error log file] check box
Select this option to generate the error log file of the linker.

[Disable removal branch optimization] check box
Select this option if extension code deletions are not necessary.

[Add source debug information] check box
Select this option to add the debugging information. If this option is not specified, the sources cannot be displayed in debugging.

[Output absolute list file] check box
Select this option to generate the absolute list file.


[Output Map file] check box
Select this option to generate the link map file.

[Output Symbol file] check box
Select this option to generate the symbol file.

[Output cross reference file] check box
Select this option to generate the cross reference file.

Refer to Chapter 5, "Linker", for details of the linker options.

3.9.3 Debugger Options



[COM Port:] list box

Set up the personal computer to connect with the ICE. Select COM when the ICE is connected via the RS-232C interface. Select USB when the ICE is connected via the USB interface. USB is selected by default.

[bps:] list box


Select a baud rate to communicate with the ICE when it is connected via the RS-232C interface. It is not necessary to select a baud rate when USB is selected from the [COM Port:] list box.

[Initial Command:] edit box

This box is used to edit the debugger commands to be executed when the debugger starts up. The work bench generates a command file with the commands entered in this box and specifies it when invoking the debugger. A load command is initially set so that the debugger can load the object at start up.

Refer to Chapter 8, "Debugger", for details of the debugger options.

3.9.4 HEX Converter Options



[Output Format:] list box

An output format of the executable object to be generated by the build task can be selected.

When "Absolute Object" is selected, the build task will be terminated after linking has completed. The HEX converter will not be invoked. When "Intel Hex" or "Motorola S" is selected, the HEX converter will be invoked after linking has completed. Other HEX converter options become selectable when one of them is selected.

[Do not fill room with 0xFF] check box

Select this option when not filling the unused program area with 0xFF.


[Output error log file] check box

Select this option to generate the error log file of the HEX converter.

Refer to Chapter 6, "HEX Converter", for details of the HEX converter options.

3.10 Work Bench Options

[Options...] in the [Tools] menu allows selection of some options for customizing the work bench. When this menu item is selected, a dialog box appears.



File menu options

[MRU Files:] box

This option allows selection of a number of recently used files to be listed in the [File] menu. The selectable range is 0 to 9.

[MRU Projects:] box

This option allows selection of a number of recently used project files to be listed in the [File] menu. The selectable range is 0 to 9.

Print options

[Unit:] radio button

This option allows selection of a unit used for specifying the margins of the printing sheet. Either "inch" or "mm" can be selected. This selection affects the margin setup field in the [Page Setup...] dialog box.

[Font:] list box

This option allows selection of a font used for printing the document in the [Edit] window.

Editor options

[Auto Save:] box

This option sets an auto-save interval for the temporary file of the document to be edited in the [Edit] window. The range able to be selected is 0 to 999 seconds. The document being edited will be automatically saved while it is being assembled or built, or when the work bench is terminated. When 0 is selected, the temporary file will not be automatically saved.

[Line No.] check box

This option enables or disables the line number display in the [Edit] window.

Color selection list box

These list boxes allow selection of colors used to display the document in the [Edit] window. Text (mnemonics), comments, assembler pseudo-instructions, preprocessor pseudo-instructions, labels and line numbers are displayed with different colors selected here.

3.11 Short-Cut Key List

Key operation	Function
Ctrl + N	Creates a new document
Ctrl + O	Opens an existing document
Ctrl + F12	Opens an existing document
Ctrl + S	Saves the document
Ctrl + P	Print the active document
Ctrl + Shift + F12	Print the active document
Ctrl + Z	Undoes the last action
Alt + BackSpace	Undoes the last action
Ctrl + X	Cuts the selection and puts it on the clipboard
Shift + Delete	Cuts the selection and puts it on the clipboard
Ctrl + C	Copies the selection to the clipboard
Ctrl + Insert	Copies the selection to the clipboard
Ctrl + V	Inserts the clipboard contents at the insertion point
Shift + Insert	Inserts the clipboard contents at the insertion point
Ctrl + A	Selects the entire document
Ctrl + F	Finds the specified text
F3	Finds next
Shift + F3	Finds previous
Ctrl + H	Replaces the specified text with different text
Ctrl + G	Moves to the specified location
Ctrl + F7	Assembles the file
F7	Builds the project
Ctrl + Break	Stops the build
F5	Debugs the project
Alt + F7	Edits the project build and debug settings
Ctrl + Tab	Next MDI Window
Short-cut-key	Opens the popup menu
Shift + F10	Opens the popup menu

3.12 Error Messages

The work bench error messages are given below.

Error message	Description
<filename> is changed by another editor. Reopen this file?	The currently opened file is modified by another editor.
Cannot create file: <filename>	The file (linker command file, debugger command file, etc.) cannot be created.
Cannot find file: <filename>	The source file cannot be found.
Cannot find ICE parameter file	The ICE parameter file cannot be found.
Cannot open file: <filename>	The source file cannot be opened.
You cannot close workspace while a build is in progress. Select the Stop Build command before closing.	The project close command or work bench terminate command is specified while the build task is being processed.
Would you like to build it?	The debugger invoke command is specified when the build task has not already been completed.

3.13 Precautions

- (1) The source file that can be displayed and edited in the work bench is limited to 16M byte size.
- (2) The label search and coloring function of the work bench does not support labels that have not ended with a colon (:).
- (3) The work bench can create a make, linker command and debugger command files, note, however, that these files or settings created with another editor cannot be input into the work bench.
- (4) The work bench does not support Japanese (2-byte) characters. Do not use Japanese characters for path or file names.

For the restrictions, support functions and bug information of the latest version, refer to rel_workb_E.txt of S5U1C63000A.

For the models supported by the latest version, refer to Readme_E.txt of S5U1C63000A.

CHAPTER 4 ASSEMBLER

This chapter describes the functions of the assembler as63 and grammar involved with the creation of assembly source files.

4.1 Functions

The assembler as63 is a tool that constitutes the core of this software package. It assembles (translates) assembly source files and creates object files in the machine language.

The functions and features of the assembler are summarized below:

- Allows absolute and relocatable sections mixed in one source.
- Allows to develop programs in multiple sources by creating relocatable object files that can be combined by the linker.
- Can add source debugging information for source debugging on the debugger.
- Upper compatible with the old S1C63 preprocessor and assembler.

The assembler provides the following additional functions as well as the basic assembly functions:

- Macro definition and macro invocation
- Definition of Define name
- Operators
- Insertion of other file
- Conditional assembly

The assembler processes source files in two stages: preprocessing stage and assembling stage. The preprocessing stage expands the additional function part described in the source file to mnemonics that can be assembled, and delivers them to a temporary file (preprocessed file). The assembling stage assemble the preprocessed file to convert the source codes into the machine codes.

4.2 Input/Output Files




Fig. 4.2.1 Flow chart

4.2.1 Input File

Assembly source file

File format: Text file

File name: <File name>.s

<File name>.ms (A preprocessed source file created by the assembler or disassembler.)

Description: File in which a source program is described. If the file extension is omitted, the assembler finds a source file that has the specified file name and an extension ".s".

Note: When a ".s" source file is specified, it will be processed in the preprocessing stage and then the assembling stage. When a ".ms" source file is specified, it will be processed only in the assembling stage. Therefore, ".ms" files cannot include preprocessor instructions.

4.2.2 Output Files

Object file

File format: Binary file in relocatable IEEE-695 format

File name: <file name>.o (The <file name> is the same as that of the input file, unless otherwise specified with the -o option.)

Output destination: Current directory

Description: File in which machine language codes are stored in a relocatable form available for the linker to link with other modules and to generate an executable absolute object.

Relocatable list file

File format: Text file

File name: <file name>.lst (The <file name> is the same as that of the input file, unless otherwise specified with the -o option.)

Output destination: Current directory

Description: File in which offset locations, machine language codes and source codes are stored in plain text.

Preprocessed file

File format: Text file

File name: <file name>.ms (The <file name> is the same as that of the input file, unless otherwise specified with the -o option.)

Output destination: Current directory

Description: File in which instructions for preprocessing (e.g. conditional assembly and macro instructions) are expanded into an assembling format.

Error file

File format: Text file

File name: <file name>.err (The <file name> is the same as that of the input file, unless otherwise specified with the -o option.)

Output destination: Current directory

Description: The file is created if the -e option is specified. It records error messages and other information which the assembler delivers via the Standard Output (stdout).

4.3 Starting Method

General form of command line

as63 ^ [options] ^ [<source file name>]

^ denotes a space.

[] indicates the possibility to omit.

Source file name

In the command line, only one assembly source file can be specified at a time. Therefore, you will have to process multiple files by executing the assembler the number of times equal to the number of files to be processed.

A long file name supported in Windows and a path name can be specified. When including spaces in the file name, enclose the file name with double quotation marks ("").

Options

The assembler comes provided with the following six start-up options:

-d <define name>

Function: Definition of Define name

Explanation: • Works in the same manner as you describe "#define <define name>" at top of the source. It is an option to control the conditional assembly at the start-up.
• One or more spaces are necessary between -d and the <define name>.
• To define two or more Define names, repeat the specification of "-d <define name>".

-g

Function: Addition of debugging information

Explanation: • Creates an output file containing symbolic/source debugging information.
• Always specify this function when you perform symbolic/source debugging.

Default: If this option is not specified, no debugging information will be added to the relocatable object file.

-o <file name>

Function: Specification of output path/file name

Explanation: • Specifies an output path/file name without extension or with an extension ".o". If no extension is specified, ".o" will be supplemented at the end of the specified output path/file name.

Default: The input file name is used for the output file names.

-c

Function: Ignore character case of symbols

Explanation: • Allows description of symbols in case insensitive.

Default: If this option is not specified, symbol names will be case sensitive.

-l

Function: Output of relocatable list file

Explanation: • Outputs a relocatable list file.

Default: If this option is not specified, no relocatable list file will be output.

-e

Function: Output of error file

Explanation: • Creates an .err file which contains the information that the assembler outputs to the Standard Output (stdout), such as error messages.

Default: If this option is not specified, no error file will be created.

When entering an option in the command line, you need to place one or more spaces before and after the option. The options can be specified in any order. It is also possible to enter options after the source file name.

Example: `c:\epson\s1c63\bin\as63 -g -e -l -d TEST1 -d TEST2 test.s`

4.4 Messages

The assembler delivers all its messages through the Standard Output (stdout).

Start-up message

The assembler outputs only the following message when it starts up.

```
Assembler 63 Ver x.xx
Copyright (C) SEIKO EPSON CORP. 1998-2001
```

End message

The assembler outputs the following messages to indicate which files have been created when it ends normally.

```
Created preprocessed source file <FILENAME.MS>
Created relocatable object file <FILENAME.O>
Created relocatable list file <FILENAME.LST>
Created error log file <FILENAME.ERR>

Assembly 0 error(s) 0 warning(s)
```

Usage output

If no file name was specified or the option was not specified correctly, the assembler ends after delivering the following message concerning the usage:

```
Usage: as63 [options] <file name>
Options: -d <symbol>      Add preprocess definition
         -e                Output error log file (.ERR)
         -g                Add source debug information in object
         -l                Output relocatable list file (.LST)
         -c                Ignore character case of symbols
         -o <file name>   Specify output file name

File name: Source file name (.S or .MS)
```

When error/warning occurs

If an error is produced, an error message will appear before the end message shows up.

Example:

```
TEST.S(5) Error: Illegal syntax
Assembly 1 error(s) 0 warning(s)
```

In the case of an error, the assembler ends without creating an output file. If an error occurs at the preprocessing stage in the assembler, the assembler stops processing and outputs preprocess-level errors only.

If a warning is issued, a warning message will appear before the end message shows up.

Example:

```
TEST.S(6) Warning: Expression out of range
Assembly 0 error(s) 1 warning(s)
```

In the case of a warning, the assembler ends after creating an output file.

The source file name that was specified in the command line will appear at the beginning of the error and warning messages.

For details on errors and warnings, refer to Section 4.10, "Error/Warning Messages".

4.5 Grammar of Assembly Source

Assembly source files should be created on a general-purpose editor or the source editor of the work bench. Save sources as standard text files. For the file name, a long file name supported in Windows can be specified.

This section explains the rules and grammar involved with the creation of assembly source files.

4.5.1 Statements

Each individual instruction or definition of an assembly source is called a statement. The basic composition of a statement is as follows:

Syntax pattern

(1) Mnemonic	Operand	(;comment)
(2) Assembler pseudo-instruction	Parameter	(;comment)
(3) Label:		(;comment)
(4) ;comment		

Example:	<Statement>	<Syntax Pattern>
#include	"define.h"	(2)
	.set IO1, 0xffff1	(2)
;	TEXT SECTION (ROM, 13bit width)	(4)
	.org 0x100	(2)
NMI:		(3)
	reti	(1)
	nop	(1)
	nop	(1)
	jr NMI	(1)
	.org 0x110	(2)
BOOT:		(3)
	ld %f, 0x4	(1)
	ld %a, 0	(1)
	ld %a, 0	(1)
	ldb %ext, 0 ; clear memory 0 to 3	(1)
	:	:

The example given above is an ordinary source description method. For increased visibility, the elements composing each statement are aligned with tabs and spaces.

Restrictions

- Only one statement can be described in one line. A description containing more than two instructions in one line will result in an error. However, a comment or a label may be described in the same line with an instruction.

Example:

```

;OK
BOOT:      ld    %f, 0x4

;Error
BOOT:      ld    %f, 0x4          ld    %a, 0x0
    
```

- One statement cannot be described in more than one line. A statement that cannot complete in one line will result in an error.

Example:

```

.word      0x0, 0x1, 0x2, 0x3 ... OK
.word      0xa, 0xb, 0xc, 0xd ... OK

.word      0x0, 0x1, 0x2, 0x3
           0xa, 0xb, 0xc, 0xd ... Error
    
```

- The maximum describable number of characters in one line is 259 (ASCII characters). If this number is exceeded, an error will result.
- The usable characters are limited to ASCII characters (alphanumeric symbols), except for use in comments. Also, the usable symbols have certain limitations (details below).
- The reserved words such as mnemonics and pseudo-instructions are all not case sensitive, while the user defined items such as labels and symbols are all case sensitive if the -c option is not specified. Therefore, mnemonics and pseudo-instructions can be written in uppercase (A-Z) characters, lowercase (a-z) characters, or both. For example, "ld", "LD", and "Ld" are all accepted as "ld" instructions. For purposes of discrimination from symbols, this manual uses lowercase characters for the reserved words.

4.5.2 Instructions (*Mnemonics and Pseudo-instructions*)

The assembler supports all the mnemonics of the S1C63000 instruction set and the assembler pseudo-instructions. The following shows how to describe the instructions.

Mnemonics

An instruction is generally composed of [mnemonic] + [operand]. Some instructions do not contain an operand.

General notation forms of instructions

General forms: <Mnemonic>
 <Mnemonic> tab or space <Operand>
 <Mnemonic> tab or space <Operand1>, <Operand2>
 <Mnemonic> tab or space <Operand1>, <Operand2>, <Operand3>

Examples: nop
 jr NMI
 ld %f, 0x4

There is no restriction as to where the description of a mnemonic should begin in a line. A tab or space preceding a mnemonic is ignored.

An instruction containing an operand needs to be separated into the mnemonic and the operand with one or more tabs or spaces. If an instruction requires multiple operands, the operands must be separated from each other with one comma (.). Space between operands is ignored.

The elements of operands will be described further below.

Types of mnemonics

The following 39 types of mnemonics can be used in the S1C63 Family:

add adc and bit calr calz clr cmp dec ex halt inc int jp jr jrc jrnc jrnz
 jrz ld ldb nop or pop push ret retd reti rets rl rr sbc set sll slp srl sub
 tst xor

For details on instructions, refer to the "S1C63000 Core CPU Manual".

Note

The assembler is commonly used for all the S1C63 Family models, so all the instructions can be accepted. Be aware that no error will occur in the assembler even if instructions or operands unavailable for the model are described. They will be checked in the linker.

Assembler pseudo-instructions

The assembler pseudo-instructions are not converted to execution codes, but they are designed to control the assembler or to set data.

For discrimination from other instructions, all the assembler pseudo-instructions begin with a sharp (#) or a period (.).

General notation forms of pseudo-instructions

General forms: <Pseudo-instruction>
 <Pseudo-instruction> tab or space <Parameter>
 <Pseudo-instruction> tab or space <Parameter1> tab, space or comma <Parameter2> ...

Examples: #define SW1 1
 .org 0x100
 .comm BUF 4

There is no restriction as to where the description of an instruction may begin in a line.

An instruction containing a parameter needs to be separated into the instruction and the parameter with one or more tabs or spaces. If an instruction requires multiple parameters, they are separated from each other with an appropriate delimiter.

Types of pseudo-instructions

The following 25 types of pseudo-instructions are available:

```
#include #define #macro #endm #ifdef #ifndef #else #endif #defnum
.abs .align .org .code .data .bss .codeword .word .comm .lcomm
.global .set .list .nolist .stabs .stabn
```

For details of each pseudo-instruction and its functionality, refer to Section 4.7, "Assembler Pseudo-Instructions".

Restriction

The mnemonics and pseudo-instructions are all not case sensitive. Therefore, they can be written in uppercase (A–Z) characters, lowercase (a–z) characters, or both. For example, "ld", "LD", and "Ld" are all accepted as "ld" instructions. However, the user defined symbols used in the operands or parameters are case sensitive. They must be the same with the defined characters. When assembling with the "-c" option, all symbols are case insensitive.

4.5.3 Symbols (Labels)

A symbol (label) is an identifier designed to refer to an arbitrary address in the program. It is possible to refer to a branch destination of a program or a data memory address using the defined symbol.

Definition of a symbol

Usable symbols are defined as 16-bit values by any of the following methods:

1. <Symbol>:

Example: LABEL1:

... LABEL1 is a label that indicates the address of a described location.

Preceding spaces and tabs are ignored. It is a general practice to describe from the top of a line.

2. Definition using the **.set** pseudo-instruction

Example: .set ADDR1 0xff00

... ADDR1 is a symbol that represents absolute address 0xff00.

3. Definition using the **.comm** or **.lcomm** pseudo-instruction

Example: .comm BUF1 4

... BUF1 is a label that represents a RAM address.

The **.comm** and **.lcomm** pseudo instructions can define labels only in bss sections (data memory such as RAM). Program memory addresses cannot be defined.

Reference with symbols

A defined symbol denotes an address.

The actual address value should be determined in the linking process, except in the case of absolute sections.

Examples: LABEL1:

```

                :
                jr      LABEL1      ... jumps to the LABEL1 location.

.set   IO_M     0xffff0
.org   0x0000
.bss
.comm  COUNT1  1

.code
ldb   %ext, IO_M@h
ldb   %x1, IO_M@l  ... 0xffff0 is loaded to X-register. (@h and @l are symbol masks.)
inc   [COUNT1]   ... Regarded as inc [0x0000].
```

Scope

The scope is a reference range of a symbol (label). It is called local if the symbol is to be referenced within the same file, and it is called global if the symbol is to be referenced from other files.

Any defined symbol's scope is local in default. To make a symbol's scope global, use the *.global* pseudo-instruction both in the file in which the symbol is defined and in the file that references the symbol.

A double definition of local symbols will be an error at the assembly stage, while a double definition of global symbols will be an error at the link stage.

Example:

File in which global symbol is defined (file1)

```
.global SYMBOL      ... Global declaration of a symbol which is to be defined in this file.
SYMBOL:
:
LABEL:              ... Local symbol
:                  (Can be referenced to only in this file)
```

File in which a global symbol is referenced to (file2)

```
.global SYMBOL      ... Global declaration of a symbol defined in other source file.
call SYMBOL        ... Symbol externally referenced to.
:
LABEL:            ... Local symbol
:                (Treated as a different symbol from LABEL of file1)
```

The assembler regards those symbols as those of undefined addresses in the assembling, and includes that information in the object file it delivers. Those addresses are finally determined by the processing of the linker.

- * When a symbol is defined by the *.comm* pseudo-instruction, that symbol will be a global symbol. Therefore, in a defined file, no global declaration needs to be made using the *.global* pseudo-instruction. On the contrary, in a file to be referenced, the global declaration is necessary prior to the reference.

Symbol masks

Symbol masks are designed to acquire the upper 8-bit address and the lower 8-bit address from a symbol representing a 16-bit address.

The following 5 types of symbol masks can be used:

@l or @L	Acquires the lower 8 bits of an absolute address.
@h or @H	Acquires the upper 8 bits of an absolute address.
@rl or @RL	Acquires the lower 8 bits of a relative address.
@rh or @RH	Acquires the upper 8 bits of a relative address.
@xh or @XH	Acquires the upper 8 bits of an absolute address by inverting them (Used exclusively for the "ldb" instruction combined with the "cmp" instruction).

Sample uses:

```
ldb    %ext, ADDR@h
ldb    %x1, ADDR@l      ... Functions as "ld %x, ADDR (16-bit)"

ldb    %ext, NUM@h
add    %x, NUM@l      ... Functions as "add %x, NUM (16-bit)"

ldb    %ext, LABEL@rh
calr   LABEL@rl      ... Functions as "calr LABEL (16-bit)"

ldb    %ext, DATA@xh
cmp    %x, DATA@l   ... Functions as "cmp %x, DATA (16-bit)"

.set   IO_ADDR 0xff12
ldb    %ext, IO_ADDR@l
ld     %a, [%y]      ... Functions as "ld %a, [IO_ADDR]"
```

Restrictions

- The maximum number of characters of a symbol is 259 (not including colon). If this number is exceeded, an error will result.
- Only the following characters can be used:
A-Z a-z _ 0-9 ?

- A symbol cannot begin with a numeral.

```
Examples: ;OK ;Error
          FOO: llabel:
          L1: L 1:
          .set IO 0xffff .set #IO 0xffff
          .comm BUF 4 .lcomm 1st_BUF 2
```

- Since symbols are case sensitive by default, uppercase and lowercase are discriminated. When referring a defined symbol, use the characters exactly the same as the defined symbol.

```
Examples: _Abcd:
          :
          jr _ABCD ... Does not jump to _Abcd
```

However, symbols will be case insensitive if the -c option is specified.

- The symbol masks are effective only on the defined symbols. If a symbol mask is applied to a numeric value, an error will result.
- If a symbol mask is omitted, the lower bits effective for that instruction will be used. However, if the bit value does not fall within the instruction range, an error or warning will be issued.
- Symbols and symbol masks cannot be used on 4-bit immediate values.

4.5.4 Comments

Comments are used to describe a series of routines, or the meaning of each statement. Comments cannot comprise part of coding.

Definition of comment

A character string beginning with a semicolon (;) and ending with a line feed code (LF) is interpreted as a comment. Not only ASCII characters, but also other non-ASCII characters can be used to describe a comment.

```
Examples: ;This line is a comment line.
          LABEL: ;This is the comment for LABEL.
          ld %a,%b ;This is the comment for the instruction on the left.
```

Restrictions

- A comment is allowed up to 259 characters, including a semicolon (;), spaces before, after and inside the comment, and a return/line feed code.
- When a comment extends to several lines, each line must begin with a semicolon.

```
Examples: ;These are
          comment lines. ... The second line will not be regarded as a comment. An error will
          result.
          ;These are
          ; comment lines. ... Both lines will be regarded as comments.
```

4.5.5 Blank Lines

This assembler also allows a blank line containing only a return/line feed code. It need not be made into a comment line using a semicolon.

4.5.6 Register Names

The CPU register names may be written in either uppercase or lowercase letters.

Table 4.5.6.1 Notations of register names

Register		Notation
A	Data register A	%a, %A, a or A
B	Data register B	%b, %B, b or B
BA	BA-register pair	%ba, %BA, ba or BA
X	Index register X	%x, %X, x or X
XH	Upper 8 bits of X-register	%xh, %XH, xh or XH
XL	Lower 8 bits of X-register	%xl, %XL, xl or XL
Y	Index register Y	%y, %Y, y or Y
YH	Upper 8 bits of Y-register	%yh, %YH, yh or YH
YL	Lower 8 bits of Y-register	%yl, %YL, yl or YL
F	Flag register F	%f, %F, f or F
EXT	Extension register EXT	%ext, %EXT, ext or EXT
SP1	Stack pointer SP1	%sp1, %SP1, sp1 or SP1
SP2	Stack pointer SP2	%sp2, %SP2, sp2 or SP2

Note: "%" can be omitted. These symbols are reserved words, therefore they cannot be used as user-defined symbol names.

4.5.7 Numerical Notations

This Assembler supports three kinds of numerical notations: decimal, hexadecimal, and binary.

Decimal notations of values

Notations represented with 0–9 only will be regarded as decimal numbers. To specify a negative value, put a minus sign (-) before the value.

Examples: 1 255 -3

Characters other than 0–9 and the sign (-) cannot be used.

Hexadecimal notations of values

To specify a hexadecimal number, place "0x" before the value.

Examples: 0x1a 0xff00

"0x" cannot be followed by characters other than 0–9, a–f, and A–F.

Binary notations of values

To specify a binary number, place "0b" before the value.

Examples: 0b1001 0b1001100

"0b" cannot be followed by characters other than 0 or 1.

Specified ranges of values

The size (specified range) of immediate data varies with each instruction.

The specifiable ranges of different immediate data are given below.

Table 4.5.7.1 Types of immediate data and their specifiable ranges

Symbol	Type	Decimal	Hexadecimal	Binary
imm2	2-bit immediate data	0–3	0x0–0x3	0b0–0b11
imm4	4-bit immediate data	0–15	0x0–0xf	0b0–0b1111
imm6	Software vectored interrupt address	0–64	0x0–0x3f	0b0–0b1111111
imm8	8-bit immediate data	0–255	0x0–0xff	0b0–0b11111111
n4	4-bit n-ary specified data	1–16	0x1–0x10	0b0–0b10000
sign8	Signed 8-bit immediate data	-128–127	0x0–0xff	0b0–0b11111111
add6	6-bit address	0–64	0x0–0x3f	0b0–0b1111111

Other numerical notations

The following numerical notations can also be used:

- nnnnB: Binary numbers
- nnnnO: Octal numbers
- nnnnQ: Octal numbers
- nnnnH: Hexadecimal numbers

"nnnnB" (binary numbers) and "nnnnH" (hexadecimal numbers) are converted into the new format ("0bnnnn" and "0xnnnn") in the preprocessing stage.

"nnnnO" and "nnnnQ" (octal numbers) are converted into hexadecimal numbers ("0xnnnn") in the preprocessing stage.

ASCII to HEX conversion

One or two ASCII characters (enclosed with ' ') can be described in source files unless converting into numbers. The numeric operators can also be used. The described characters are converted into ASCII codes and delivered to the output relocatable object file.

```
Examples: retd '1'      → (retd 0x31)
          retd '23'     → (retd 0x3233)
          retd '4'+1    → (retd 0x35)
```

*Note: Three or more characters and the following characters cannot be described:
Control codes (0x0 to 0x1f) space @ [] ; ,*

4.5.8 Operators

An expression that consists of operators, numbers and/or defined symbols (including labels) can be used for specifying a number or defining a Define name (only for number definition).

The preprocess in the assembler handles expressions in signed 16-bit data and expands them as hexadecimal numbers.

Types of operators

Arithmetic operators	Examples
+ Addition, Plus sign	+0xff, 1+2
- Subtraction, Minus sign	-1+2, 0xff-0b111
* Multiplication	0xf*5
/ Division	0x123/0x56
% Residue	0x123%0x56 (%% is also be supported.)
>> Shifting to right	1>>2
<<< Shifting to left	0x113<<<3
^H Acquires upper 8 bits	0x1234^H
^L Acquires lower 8 bits	0x1234^L
() Parenthesis	1+(1+2*5)

The arithmetic operator returns the result of arithmetic operation on the specified terms.

Logical operators	Examples
& Bit AND	0b1101&0b111
Bit OR	0b123 0xff
^ Bit XOR	12^35
~ Bit inversion	~0x1234

The logical operator returns the result of logic operation on the specified terms.

Relational operators	Examples
== Equal	SW==0
!= Not equal	SW!=0
< Less than	ABC<5
<= Less than or equal	ABC<=5
> Greater than	ABC>5
>= Greater than or equal	ABC>=5
&& AND	ABC&&0xf
OR	ABC 0b1010

The relational operator returns 1 if the expression is true, otherwise it returns 0.

Priority

The operators have the priority shown below. If there are two or more operators with the same priority in an expression, the assembler calculates the expression from the left.

- | | |
|-------------------------------------|---------------|
| 1. () | High priority |
| 2. + (plus sign), - (minus sign), ~ | ↑ |
| 3. ^H, ^L | |
| 4. *, /, % (%%) | |
| 5. + (addition), - (subtraction) | |
| 6. <<, >> | |
| 7. ==, !=, <, <=, >, >= | |
| 8. & | |
| 9. ^ | |
| 10. | |
| 11. && | ↓ |
| 12. | Low priority |

Examples

```
#defnum BLK_HEADER_SIZE 4
#defnum BLK_START 0x30+BLK_HEADER_SIZE*2
#defnum BLK_END BLK_START+4*2

#macro ADD_X ADDR
    ldb    %ext, (ADDR*2)^H           ... Can be used in macros.
    add    %x, (ADDR*2)^L
#endm

    ldb    %ext, BLK_START^H ; %x=BLK_START
    ldb    %x1, BLK_START^L
    ld     [%x], 0b11&0x110
    ldb    %ext, ~BLK_END^H ; cmp %x, BLK_END
    cmp    %x, BLK_END^L
    ADD_X (0x1200+0x34)*2 ; %x+=0x1234*2
```

Precautions

- Minus numbers -1 to -32768 are handled as 0xffff to 0x8000.
- The assembler handles expressions as 16-bit data. Pay attention to the data size when using it as 4-bit immediate data, especially when it has a minus value.

Example:

```
ld %a, -2+1      ... NG. It will be expanded as "ld a,0xffff".
ld %a, (-2+1)&0xf ... OK. It will be expanded as "ld a,0xf".
```

- Expressions are calculated with a sign (like a signed short in C language). Pay attention to the calculation results of the >>, / and % operators using hexadecimal numbers.

Example:

```
.set NUM1 0xffffe/2 ... -2/2 = -1 (0xffff)
                        The / and % operators can only be used within the range of +32767 to -32768.
.set NUM2 0xffffe>>1 ... -2>>1 = -1 (0xffff)
                        Mask as (0xffffe>>1)&0x7fff.
```

- When using an expression in a #define statement, it will be expanded as is. Pay attention when a number is defined using the #define pseudo-instruction.

Example:

```
#define NUM1 1+1
ld %a, NUM1*2      ... This will be expanded as "ld %a, 1+1*2" (=3).
#define NUM2 (1+1)
ld %a, NUM2*2      ... This will be expanded as "ld %a, (1+1)*2" (=4).
```

- Do not insert a space or a tab between an operator and a term.

4.5.9 Location Counter Symbol "\$"

The address of each instruction code is set in the 16-bit location counter when a statement is assembled. It can be referred using a symbol "\$" as well as labels. "\$" indicates the current location, thus it can be used for relative branch operation. The operators can be used with this symbol similar to labels.

Example:

```
jr $              ... Jumps to this address (means endless loop).
jr $+2           ... Jumps to two words after this address.
jr $-10          ... Jumps to 10 words before this address.
jr $+16+(16*(BLK>16)) ... Operators and defined symbols can be used.
```

Precaution

When the address referred to relatively with "\$" is in another section, it should be noted if the intended section resides at the addressed place, because if the section is relocatable, the absolute address is not fixed until the linking is completed.

4.5.10 Optimization Branch Instructions for Old Preprocessor

The old version of the S1C63 preprocessor has optimization branch instructions for optimizing the extension code. Since this function is supported by the linker in the current version, they are expanded without an extension code in the assembler. The relative distance to the label does not affect this expansion.

<u>Optimization Branch Instruction</u>			<u>Mnemonic after Expansion</u>
xjr LABEL	→	jr	LABEL
xjrc LABEL	→	jrc	LABEL
xjrnc LABEL	→	jrnc	LABEL
xjrz LABEL	→	jrz	LABEL
xjrnz LABEL	→	jrnz	LABEL
xcalr LABEL	→	calr	LABEL

4.6 Section Management

4.6.1 Definition of Sections

The memory configuration of the S1C63 Family microcomputer is divided into a code ROM that contains programs written, and data memories such as data RAM and I/O memory. Moreover, some models carry a data ROM that holds static data written.

A section refers to an area where codes are written (or to be mapped), and there are three types of sections in correspondence with the memories:

1. **CODE section** Area located within a code ROM.
2. **DATA section** Area located within a data ROM.
3. **BSS section** Denotes a RAM area.

To allow to specify these sections in a source file, the assembler comes provided with pseudo-instructions.

CODE section

The *.code* pseudo-instruction defines a CODE section. Statements from this instruction to another section defining instruction will be regarded as program codes, and will be so processed as to be mapped in the code ROM. The source file will be regarded as a CODE section by default. Therefore, the part that goes from top of the file, to another section will be processed as a CODE section. Because this section is of 13 bits/word, 4-bit data cannot be defined.

DATA section

The *.data* pseudo-instruction defines a DATA section. Statements from this instruction to another section defining instruction will be regarded as 4-bit data, and will be so processed as to be mapped in the data ROM. Therefore, nothing else can be described in this area other than the symbols for referring to the address of the data ROM, the 4-bit data defining pseudo-instruction (*.word*), and comments. This section is applied only to models having a data ROM.

BSS section

The *.bss* pseudo-instruction defines a BSS section. Statements from this instruction to another section defining instruction will be regarded as 4-bit data, and will be so processed as to be mapped in the data memory (RAM). Therefore, nothing else can be described in this area other than the symbols for referring to the address of the data memory, the area securing pseudo-instructions (*.comm* and *.lcomm*).

The *.comm* pseudo-instruction and the *.lcomm* pseudo-instruction are designed to define the symbol and size of a data area. Although the BSS section basically consists in a RAM area, it can as well be used as a data memory area, such as display memory and I/O memory. Since code definition in this area is meaningless in embedded type microcomputers, such as those of the S1C63 Family, nothing else can be described other than the two instructions and comments.

4.6.2 Absolute and Relocatable Sections

The assembler is a relocatable assembler that always generates an relocatable object and needs the linker to make it into an executable absolute object. However, each section in one source can be absolute or relocatable depending on how they are described. The section whose absolute address is specified with the *.org* pseudo-instruction in the source is an absolute section, while the section whose absolute address is not specified is an relocatable section. Absolute addresses of relocatable sections will be fixed by the linker. Both types of sections can be included in one source.

4.6.3 Sample Definition of Sections

```

:
CODE1 (Relocatable program)
:
.data
:
DATA1 (Relocatable data definition)
:
.bss
:
BSS1 (Relocatable RAM area definition)
:
.code
.org 0x0      ... If this specification is omitted, a CODE section begins from the address following CODE1.
:
CODE2 (Absolute program)
:
.bss
.org 0x0      ... If this specification is omitted, a BSS section begins from the address following BSS1.
:
BSS2 (Absolute RAM area definition)
:
.code
:
CODE3 (Relocatable program)
:
.data
.org 0x8000   ... If this specification is omitted, a DATA section begins from the address following DATA1.
:
DATA2 (Absolute data definition)
:

```

In the section definition shown above, absolute sections and relocatable sections are mixed in one source. Absolute sections are sections whose absolute addresses are specified with the *.org* pseudo-instructions. CODE2, BSS2 and DATA2 are absolute sections. Absolute sections will be located at the place specified.

Other sections are relocatable in the sense that the absolute location addresses are not fixed at the assembly stage and will be fixed later at the linking stage.

Precautions

When there appears in a section a statement which is designed for other section, a warning will be issued and a new section will be started according to the statement.

Examples: `.code`
`.comm BUF 16` ... Warning; A new bss section begins
`.bss`
`ld %a, %b` ... Warning; A new code section begins

4.7 Assembler Pseudo-Instructions

The assembler pseudo-instructions are not converted to execution codes, but they are designed to control the assembler or to set data.

For discrimination from other instructions, all the assembler pseudo-instructions begin with a character "#" or ".". The instructions that begin with "#" are preprocessed pseudo-instructions and they are expanded into forms that can be assembled. The expanded results are delivered in the preprocessed file (.ms). The original statements of the pseudo-instructions (#) are changed as comments by attaching a ";" before delivering to the file. The instruction that begins with "." are used for section and data definitions. They are not converted at the preprocessing stage.

All the pseudo-instruction characters are not case sensitive.

The following pseudo-instructions are available in the assembler:

Pseudo-instruction	Function
#include	Includes another source.
#define	Defines a constant string.
#defnum	Defines a constant number. (*1)
#macro-#endm	Defines a macro.
#ifdef-#else-#endif	Defines an assemble condition.
#ifndef-#else-#endif	Defines an assemble condition.
.abs	Specifies absolute assembling. (*1)
.align	Sets alignment of a section.
.org	Sets an absolute address.
.code	Declares a CODE section (mapping to the built-in code ROM).
.data	Declares a DATA section (mapping to the built-in data ROM).
.bss	Declares a BSS section (mapping to the built-in RAM).
.codeword	Defines data in the CODE section.
.word	Defines data in the DATA section.
.comm	Secures a global area in the BSS section.
.lcomm	Secures a local area in the BSS section.
.global	Defines an external reference symbol.
.set	Defines an absolute address symbol.
.list	Controls assembly list output.
.nolist	Controls assembly list output.
.stabs	Debugging information (source name).
.stabn	Debugging information (line number).

*1: Maintained only for compatibility with the older assembler.

4.7.1 Include Instruction (*#include*)

The include instruction inserts the contents of a file in any location of a source file. It is useful when the same source is shared in common among several source files.

Instruction format

#include "<File name>"

- A drive name or path name can as well be specified as the file name.
- One or more spaces are necessary between the instruction and the "<File name>".
- Character case is ignored for both *#include* itself and "<File name>".

Sample descriptions:

```
#include      "sample.def"  
#include      "c:\EPSON\S1C63\header\common.h"
```

Expansion rule

The specified file is inserted in the location where *#include* was described.

Precautions

- Only files created in text file format can be inserted.
- The *#include* instruction can be used in the including files. However, nesting is limited up to 10 levels. If this limit is surpassed, an error will result.

4.7.2 Define Instruction (*#define*)

Any substitute character string can be left defined as a Define name by the define instruction (*#define*), and the details of that definition can be referred to from various parts of the program using the Define name.

Instruction format

```
#define <Define name> [<Substitute character string>]
```

<Define name>:

- The first character is limited to a-z, A-Z, ? and _.
- The second and the subsequent characters can use a-z, A-Z, 0-9, ? and _.
- Uppercase and lowercase characters are discriminated. (*#define* itself is case insensitive.)
When assembling with the "-c" option, all symbols are case insensitive.
- One or more spaces or tabs are necessary between the instruction and the Define name.

<Substitute character string>:

- When writing all characters can be used, but a semicolon (;) is interpreted as the start of a comment.
- Uppercase and lowercase characters are discriminated.
- One or more spaces or tabs are necessary between the Define name and the substitute character string.
- The substitute character string can be omitted. In that case, NULL is defined in lieu of the substitute character string. It can be used for the conditional assembly instruction.

Sample definitions:

```
#define    TYPE1
#define    L1        LABEL_01
#define    Xreg      %x
#define    CONST    (DATA1+DATA2) *2
```

Expansion rule

If a Define name defined appears in the source, the assembler substitutes a defined character string for that Define name.

Sample expansion:

```
#define INT_F1        0xffff0
#define INT_F1_1     0
:
set    [INT_F1], INT_F1_1    ... Expanded to "set [0xffff0],0".
:
```

Precautions

- The assembler only permits backward reference of a Define name. Therefore the name definition must precede the use of it.
- Once a Define name is defined, it cannot be canceled. However, redefinition can be made using another Define name.

Example:

```
#define XL %xl
#define Xlow XL
ldb [Xlow], %ba ... Expanded to "ldb [%xl],%ba".
```

- When the same Define name is defined duplicatedly, a warning message will appear. Until it is redefined, it is expanded with the original content, and once it is redefined, it is expanded with the new content.
- No other characters than delimiters (space, tab, line feed, and comma) can be added before and after a Define name in the source, unless they are enclosed in [] or []+. However, an operator or a symbol mask (@.) can be added to a Define name string without delimiters.

Examples:

```
#define INT_F 0xfff
tst [INT_F1], 0 ;tst [0xffff1], 0? ... Specification like this is invalid.

#define L LABEL
ldb %ext, L@h ... Replaced with "ldb %ext,LABEL@h".
ldb %xl, L@l ... Replaced with "ldb %xl,LABEL@l".
```

- When using an expression in a #define statement, it will be expanded as is. Pay attention when a number is defined using the #define pseudo-instruction.

Examples:

```
#define NUM1 1+1
ld %a, NUM1*2 ... Expanded as "ld %a, 1+1*2" (=3).

#define NUM2 (1+1)
ld %a, NUM2*2 ... Expanded as "ld %a, (1+1)*2" (=4).
```

- The internal preprocess part of the assembler does not check the validity of a statement as the result of the replacement of the character string.

4.7.3 Numeric Define Instruction (*#defnum*)

Instruction format

#defnum <Numeric Define name> <Number>

Function

The *#defnum* pseudo-instruction is provided for compatibility with the older assembler. In the older assembler, *#defnum* is required to define a numeric constant, while *#define* is for defining a string. In the new assembler, there is no need to differentiate between a numeric constant and a string. Therefore the new assembler should use the *#define* instruction.

4.7.4 Macro Instructions (*#macro ... #endm*)

Any statement string can be left defined as a macro using the macro instruction (*#macro*), and the content of that definition can be invoked from different parts of the program with the macro name. Unlike a subroutine, the part that is invoking a macro is replaced with the content of the definition.

Instruction format

```
#macro <Macro name>    [<Dummy parameter>] [,<Dummy parameter>] ...
                    <Statement string>
#endm
```

<Macro name>:

- The first character is limited to a-z, A-Z, ? and _.
- The second and the subsequent characters can use a-z, A-Z, 0-9, ? and _.
- Uppercase and lowercase characters are discriminated. (*#macro* itself is case insensitive.)
When assembling with the "-c" option, all symbols are case insensitive.
- One or more spaces or tabs are necessary between the instruction and the macro name.

<Dummy parameter>:

- Dummy parameter symbols for macro definition. They are described when a macro to be defined needs parameters.
- One or more spaces or tabs are necessary between the macro name and the first parameter symbol.
When describing multiple parameters, a comma (,) is necessary between one parameter and another.
- The same symbols as for a macro name are available.
- The number of parameters are limited according to the free memory space.

<Statement string>:

- The following statements can be described:
 - Basic instruction (mnemonic and operand)
 - Conditional assembly instruction
 - Internal branch label*
 - Comments
- The following statements cannot be described:
 - Assembler pseudo-instructions (excluding conditional assembly instruction)
 - Other labels than internal branch labels
 - Macro invocation

* *Internal branch label*

A macro is spread over to several locations in the source. Therefore, if you describe a label in a macro, a double definition will result, with an error issued. So, use internal branch labels which are only valid within a macro.

- The number of internal-branch labels are limited according to the free memory space.
- The same symbols as for a macro name are available.

Sample definition:

```
#define C_RESET    0b1101
#macro  WAIT      COUNT
        ld        %a,COUNT
        and       %f,C_RESET
LOOP:
        nop
        jr        LOOP
#endm
```

Expansion rules

When a defined macro name appears in the source, the assembler inserts a statement string defined in that location.

If there are actual parameters described in that process, the dummy parameters will be replaced with the actual parameters in the same order as the latter are arranged.

The internal branch labels are replaced, respectively, with `__L0001` ... from top of the source in the same order as they appear.

Sample expansion:

When the macro `WAIT` shown above is defined:

Macro invocation

```

:
WAIT 15
:
```

After expansion

```

:
;WAIT 15
ld %a,15
and %f,0b1101
__L0001:
nop
jr __L0001
```

("__L0001" denotes the case where an internal branch label is expanded for the first time in the source.)

Precautions

- The assembler only permits backward reference of a macro invocation. Therefore the macro definition must precede the use of it.
- Once a defined macro name is defined, it cannot be canceled. If the same macro name is defined duplicatedly, a warning message will appear. Until it is redefined, it is expanded with the original content, and once it is redefined, it is expanded with the new content. Definition should be done with distinct names, although the program operation will not be affected.
- No other characters than delimiters (space, tab, line feed, and commas) can be added before and after a dummy parameter in a statement.
- The same character string as that of the define instruction cannot be used as a macro name.
- When the number of dummy parameters differs from that of actual parameters, an error will result.
- The maximum number of parameters and internal branch labels are limited according to the free memory space.
- "__Lnnnn" used for the internal branch labels should not be employed as other label or symbol.

4.7.5 Conditional Assembly Instructions (*#ifdef ... #else ... #endif, #ifndef... #else ... #endif*)

A conditional assembly instruction determines whether assembling should be performed within the specified range, dependent on whether the specified name (Define name) is defined or not.

Instruction formats

Format 1) **#ifdef** **<Name>**
 <Statement string 1>
 [#else
 <Statement string 2>]
 #endif

If the name is defined, <Statement string 1> will be subjected to the assembling.

If the name is not defined, and #else ... <Statement string 2> is described, then <Statement string 2> will be subjected to the assembling. #else ... <Statement string 2> can be omitted.

Format 2) **#ifndef** **<Name>**
 <Statement string 1>
 [#else
 <Statement string 2>]
 #endif

If the name is not defined, <Statement string 1> will be subjected to the assembling.

If the name is defined, and #else ... <Statement string 2> is described, <Statement string 2> will be subjected to the assembling. #else ... <Statement string 2> can be omitted.

<Name>:

Conforms to the restrictions on Define name. (See *#define*.)

<Statement string>:

All statements, excluding conditional assembly instructions, can be described.

Sample description:

```
#ifdef TYPE1
    ld    %x, 0x12
#else
    ld    %x, 0x13
#endif

#ifndef SMALL
#define STACK1 0x31
#endif
```

Name definition

Name definition needs to have been completed by either of the following methods, prior to the execution of a conditional assembly instruction:

(1) Definition using the start-up option (-d) of the assembler.

Example: `as63 -d TYPE1 sample.s`

(2) Definition in the source file using the *#define* instruction.

Example: `#define TYPE1`

The *#define* statement is valid even in a file to be included, provided that it goes before the conditional assembly instruction that uses its Define name. A name defined after a conditional assembly instruction will be regarded as undefined.

When a name is going to be used only in conditional assembly, no substitute character string needs to be specified.

Expansion rule

A statement string subjected to the assembling is expanded according to the expansion rule of the other preprocessing pseudo-instructions. (If no preprocessing pseudo-instruction is contained, the statement will be output in a file as is.)

Precaution

A name specified in the condition is evaluated with discrimination between uppercase and lowercase. When assembling with the "-c" option, all symbols are case insensitive. The condition is deemed to be satisfied only when there is the same Define name defined.

4.7.6 Section Defining Pseudo-Instructions (*.code*, *.data*, *.bss*)

The section defining pseudo-instructions define one related group of codes or data and make it possible to relocate by the groups at the later linking stage. Even if these section defining pseudo-instructions are not used, the section kind will be automatically judged by its contents (however, a warning occurs). If the new codes or data without section definition are different from the previous code or data kind, they will be taken as another new section.

.code pseudo-instruction

Instruction format

.code

Function

Declares the start of a CODE section. Statements following this instruction are assembled as those to be mapped in the code ROM, until another section is declared.

The CODE section is set by default in the assembler. Therefore, the *.code* pseudo-instruction can be omitted at top of a source file. Always describe it when you change a section to a CODE section.

Precautions

- A CODE section can be divided among multiple locations of a source file for purpose of definition (describing the *.code* pseudo-instruction in the respective start positions).
- A CODE section is relocatable by default unless its location is specified with the *.org* pseudo-instruction or more loosely with the *.align* pseudo-instruction.

.data pseudo-instruction

Instruction format

.data

Function

Declares the start of a DATA section. Statements following this instruction are assembled as those to be mapped in the data ROM, until another section is declared.

Precautions

- The DATA section is a static data area, and effective only for models with data ROM installed.
- In a DATA section, nothing other than the *.org* and *.word* pseudo-instructions, symbols, and comments can be described.
- A DATA section can be divided among multiple locations of a source file for purpose of definition (describing the *.data* pseudo-instruction in the respective start positions).
- A DATA section is relocatable by default unless its location is specified with the *.org* pseudo-instruction or more loosely with the *.align* pseudo-instruction.

.bss pseudo-instruction

Instruction format

.bss

Function

Declares the start of a BSS section. Statements following this instruction are assembled as those to be mapped in the RAM, until another section is declared.

Precautions

- In a BSS section, nothing else other than the *.comm*, *.lcomm*, and *.org* pseudo-instructions, symbols, and comments can be described.
- A BSS section can be divided among multiple locations of a source file for purpose of definition (describing the *.bss* pseudo-instruction in the respective start positions).
- A BSS section is relocatable by default unless its location is specified with the *.org* pseudo-instruction or more loosely with the *.align* pseudo-instruction.

4.7.7 Location Defining Pseudo-Instructions (.org, .align)

The absolute addressing pseudo-instructions (.align and .org) work to specify absolute location of a section in different precision such as 2ⁿ words alignment level and complete absolute address level.

.org pseudo-instruction

Instruction format

```
.org    <Address>
```

<Address>:

Absolute address specification

- Only decimal, binary and hexadecimal numbers can be described.
- The addresses that can be specified are from 0 to 65,535 (0xffff).
- One or more spaces or tabs are necessary between the instruction and the address.

Sample description:

```
.code
.org    0x0100
```

Function

Specifies an absolute address location of a CODE, DATA or BSS section in an assembly source file. The section with the .org pseudo-instruction is taken as an absolute section.

Precautions

- If an overlap occurs as the result of specifying absolute locations with the .org pseudo-instruction, an error will result.

Examples:

```
.bss
.org    0x00
.comm  RAM0  4  ... RAM secured area (0x00–0x03)
.org    0x01
.comm  RAM1  4  ... Error (because the area of 0x01–0x03 is overlapped)
```

- When the .org pseudo-instruction appears in a section, a new absolute section starts at that point. The section type does not change. The .org pseudo-instruction keeps its effect only in that section until the next section definer (.code, .data or .bss) or the next location definer (.org or .align) appears.

Example:

```
:
.code          ... The latest relocatable section definition.
:
.org 0x100     ... Starts new absolute CODE section from address 0x100.
:
.bss          ... This section is relocatable not affected by the ".org" pseudo-instruction.
:
.code          ... This section is also relocatable not affected by the ".org" pseudo-instruction.
:
```

- If the .org pseudo-instruction is defined immediately after a section definer (.code, .data or .bss), the section definer does not start a new section. But .org starts a new section with the attribute of the section definer.

Example:

```
.code          ... This does not start a new CODE section.
.org 0x100     ... This starts an absolute CODE section.
:
```

- If the *.org* pseudo-instruction is defined immediately before a section definer (*.code*, *.data* or *.bss*), it does not start a new section and makes no effect to the following sections.

Example:

```

.code          ... The latest relocatable section definition.
:
.org 0x100    ... This does not start a new absolute section and makes no effect.
.bss         ... The another kind (BSS) of section which is not affected by the
:           previous ".org" pseudo-instruction in the CODE section.
.code       ... This will be an relocatable CODE section not affected by the
:           previous ".org" pseudo-instruction.

```

.align pseudo-instruction**Instruction format**

.align <Alignment number>

<Alignment number>:

Word alignment in 2ⁿ value

- Only decimal, binary and hexadecimal numbers can be described.
- The alignment that can be specified is a 2ⁿ value.
- One or more spaces or tabs are necessary between the instruction and the alignment number.

Sample description:

```
.code
.align 32    ... Sets the location to the next 32-word boundary address.
```

Function

Specifies location alignment in words of a CODE, DATA or BSS section in an assembly source file. The section with the *.align* pseudo-instruction can be taken as a loosely absolute section in the sense that its location is partially defined.

Precautions

- When the *.align* pseudo-instruction appears in a section, a new absolute section starts at that point. The section type does not change. The *.align* pseudo-instruction keeps its effect only in that section until the next section definer (*.code*, *.data* or *.bss*) or the next location definer (*.org* or *.align*) appears.

Example:

```
:
.code          ... The latest relocatable section definition.
:
.align 32     ... Starts new loosely absolute CODE section from the next 32-word boundary address.
:
.bss         ... This section is relocatable not affected by the ".align" pseudo-instruction.
:
.code        ... This section is also relocatable not affected by the ".align" pseudo-instruction.
:
```

- If the *.align* pseudo-instruction is defined immediately after a section definer (*.code*, *.data* or *.bss*), the section definer does not start a new section. But *.align* starts a new section with the attribute of the section definer.

Example:

```
.code          ... This does not start a new CODE section.
.align 32     ... This starts a loosely absolute CODE section.
:
```

- If the *.align* pseudo-instruction is defined immediately before a section definer (*.code*, *.data* or *.bss*), it does not start a new section and makes no effect to the following sections.

Example:

```
.code          ... The latest relocatable section definition.
:
.align 32     ... This does not start a new absolute section and makes no effect.
.bss         ... The another kind (BSS) of section which is not affected by the
:              previous ".align" pseudo-instruction in the CODE section.
.code        ... This will be an relocatable CODE section not affected by the
:              previous ".align" pseudo-instruction.
```

4.7.8 Absolute Assembling Pseudo-Instruction (*.abs*)

Instruction format

.abs

Function

The *.abs* pseudo-instruction is provided for compatibility with the older assembler. In the older assembler, this pseudo-instruction is required to specify that a source file uses absolute sections as opposed to relocatable sections. It is not necessary to use this instruction in the new assembler, because the new assembler allows the use of absolute and relocatable sections in one source file. Use the *.org* or *.align* pseudo-instruction for defining absolute sections.

4.7.9 Symbol Defining Pseudo-Instruction (.set)

Instruction format

```
.set <Symbol>[,] <Value>
```

<Symbol>:

Symbols for value reference

- The 1st character is limited to a-z, A-Z, ? and _.
- The 2nd and the subsequent character can use a-z, A-Z, 0-9, ? and _.
- Uppercase and lowercase are discriminated.

When assembling with the "-c" option, all symbols are case insensitive.

- One or more spaces, or tabs are necessary between the instruction and the symbol.

<Value>:

Value specification

- Only decimal, binary, and hexadecimal numbers can be described.
- The values that can grammatically be specified are from 0 to 65,535 (0xffff).
- One or more spaces, tabs, or a comma (,) are necessary between the instruction and the value.

Sample description:

```
.set DATA1 0x20
.set STACK1 0x100
```

Function

Defines a symbol for a value such as an absolute address.

Precaution

When the defined symbol is used as an operand, the defined value is referred as is. Therefore, if the value exceeds the valid range of the operand, a warning will result.

Example:

```
.set DATA1 0xff00
ldb %ext,DATA1@h ... OK
ldb %x1,DATA1@l ... OK
ld %a,DATA1 ... Warning
```

4.7.10 Data Defining Pseudo-Instructions (*.codeword*, *.word*)

.codeword pseudo-instruction

Instruction format

```
.codeword    <Data>[,<Data> ...,<Data>]
```

<Data>:

13-bit data

- Only decimal, binary and hexadecimal numbers can be described.
- The data that can be specified are from 0 to 8,191 (0x1fff).
- One or more spaces or tabs are necessary between the instruction and the first data.
- A comma (,) is necessary between one data and another.

Sample description:

```
.code
.codeword    0xa, 0xa40, 0xff3
```

Function

Defines 13-bit data to be written to the code ROM.

Precaution

The *.codeword* pseudo-instruction can be used only in CODE sections.

.word pseudo-instruction

Instruction format

```
.word    <Data>[,<Data> ...,<Data>]
```

<Data>:

4-bit data

- Only decimal, binary and hexadecimal numbers can be described.
- The data that can be specified are from 0 to 15 (0xf).
- One or more spaces or tabs are necessary between the instruction and the first data.
- A comma (,) is necessary between one data and another.

Sample description:

```
.data
.word    0xa, 0xb, 0xc, 0xd
```

Function

Defines 4-bit data to be written to the data ROM.

Precaution

The *.word* pseudo-instruction can be used only in DATA sections.

4.7.11 Area Securing Pseudo-Instructions (*.comm*, *.lcomm*)

Instruction format

```
.comm  <Symbol>[,] <Size>
.lcomm <Symbol>[,] <Size>
```

<Symbol>:

Symbols for data memory access (address reference)

- The 1st character is limited to a–z, A–Z, ? and _.
- The 2nd and the subsequent character can use a–z, A–Z, 0–9, ? and _.
- Uppercase and lowercase are discriminated.
When assembling with the "-c" option, all symbols are case insensitive.
- One or more spaces or tabs are necessary between instruction and symbol.

<Size>:

Number of words of the area to be secured (4 bits/word)

- Only decimal, binary and hexadecimal numbers can be described.
- The size that can grammatically be specified is from 0 to 65,534.
- One or more spaces, tabs or a comma (,) are necessary between symbol and size.

Sample description:

```
.bss
.comm  RAM0 4
.lcomm BUF, 1
```

Function

Sets an area of the specified size in the BSS section (RAM and other data memory), and creates a symbol indicating its top address with the specified name. By using this symbol, you can describe an instruction to access the RAM.

Difference between *.comm* and *.lcomm*

The *.comm* pseudo-instruction and the *.lcomm* pseudo-instruction are exactly the same in function, but they do differ from each other in the scope of the symbols they create. The symbols created by the *.comm* pseudo-instruction become global symbols, which can be referred to externally from other modules (however, the file to be referred to needs to be specified by the *.global* pseudo-instruction.) The symbols created by the *.lcomm* pseudo-instruction are local symbols, which cannot be referred to from other modules.

Precaution

The *.comm* and *.lcomm* pseudo-instructions can only be described in BSS sections.

4.7.12 Global Declaration Pseudo-Instruction (*.global*)

Instruction format

.global <Symbol>

<Symbol>:

Symbol to be defined in the current file, or symbol already defined in other module

- One or more spaces or tabs are necessary between the instruction and the symbol.

Sample description:

```
.global GENERAL_SUB1
```

Function

Makes global declaration of a symbol. The declaration made in a file with a symbol defined converts that symbol to a global symbol which can be referred to from other modules. Prior to making reference, declaration has to be made by this instruction on the side of the file that is going to make the reference.

4.7.13 List Control Pseudo-Instructions (*.list*, *.nolist*)

Instruction format

.list
.nolist

Function

Controls output to the relocatable list file.

The *.nolist* pseudo-instruction stops output to the relocatable list file after it is issued.

The *.list* pseudo-instruction resumes from there the output which was stopped by the *.nolist* pseudo-instruction.

Precaution

The assembler delivers relocatable list files only when it is started up with the -l option specified.

Therefore, these instructions are invalid, if the -l option was not specified.

4.7.14 Source Debugging Information Pseudo-Instructions (*.stabs*, *.stabn*)

Instruction formats

- (1) *.stabs* "<File name>", FileName
- (2) *.stabn* 0, FileEnd
- (3) *.stabn* <Line number>, LineInfo

Function

The assembler outputs object files in IEEE-695 format, including source debugging information conforming to these instructions. This debugging information is necessary to perform debugging by Debugger db63, with the assembly source displayed.

Format (1) delivers information on the start position of a file.

Format (2) delivers information on the end position of a file.

Format (3) delivers information on the line No. of an instruction in a source file.

Insertion of debugging information

When the -g option is specified as a start option, the preprocess stage of the assembler will insert debugging pseudo-instructions in the preprocessed file. Therefore, you do not have to describe these pseudo-instructions in creating source files.

4.7.15 Comment Adding Function

The preprocessing pseudo-instructions that begin with "#" are all expanded to codes that can be assembled, and delivered in the preprocessed file. Even after that, those instructions are rewritten with comments beginning with a semicolon (;), so that the original instructions can be identified. However, note that the replacements of Define names will not subsist as comments.

The comment is added to the first line following the expansion. In case the original statement is accompanied by a comment, that comment is also added.

A macro definition should have a semicolon (;) placed at top of the line.

Example:

- Before expansion

```
#define   Areg       %a

#macro   ADDX2Y     VALUE
        ld         Areg, VALUE
        add        Areg, [%x]
        ld         [%y], Areg
#endm

        ADDX2Y     10h   ; MX + 10h -> MY
```

- After expansion (no debugging information)

```
 ;#define   Areg       %a

 ;#macro   ADDX2Y     VALUE
 ;        ld         Areg, VALUE
 ;        add        Areg, [%x]
 ;        ld         [%y], Areg
 ;#endm

 ;ADDX2Y     10h   ; MX + 10h -> MY
 ld         %a, 0x10
 add        %a, [%x]
 ld         [%y], %a
```

4.7.16 Priority of Pseudo-Instructions

Some remarks concerning the priority among the preprocessing pseudo-instructions will be given below:

1. The conditional assembly instructions (*#ifdef*, *#ifndef*) have the first priority. Nesting cannot be made of those instructions.
2. Define instruction (*#define*), include instruction (*#include*), or macro instruction (*#macro*) can be described within a conditional assembly instruction.
3. Define instruction (*#define*), include instruction (*#include*), and macro instruction (*#macro*) cannot be described within a macro definition.
4. Define name definitions are expanded with priority over macro definitions.

4.8 Relocatable List File

The relocatable list file is an assembly source file that carries assembled results (offset addresses and object codes) added to the first half of each line. It is delivered only when the start-up option (-l) is specified.

Its file format is a text file, and the file name, <File name>.lst. (The <File name> is the same as that of the input source file.)

The format of each line of the assembly list file is as follows:

Line No.: Address Code Source statement

Example

```

Assembler 63 ver x.xx Relocatable List File MAIN.LST Mon Jan 15 12:40:41 2001

1:                ; main.s
2:                ; AS63 test program (main routine)
3:                ;
                    :
25:
26:                .org    0x110
27: BOOT:
28: 0110 0900      ldb    %ba,SP1_INIT_ADDR
29: 0111 1fc4      ldb    %sp1,%ba          ; set SP1
30: 0112 0900      ldb    %ba,SP2_INIT_ADDR
31: 0113 1fc6      ldb    %sp2,%ba          ; set SP2
32: 0114 0200      calr   INIT_RAM_BLK1    ; initialize RAM block 1
33: LOOP:
34: 0115 0200      calr   INC_RAM_BLK1      ; increment RAM block 1
35: 0116 0000      jr     LOOP              ; infinity loop
36:
37:
38:                ;***** RAM block *****
39:
40:                .org    0x0
41:                .bss
42: 0000 00        .comm  RAM_BLK0, 4
43: 0004 00        .comm  RAM_BLK1, 4

```

Content of line No.

The source line number from top of the file will be delivered.

Content of address

In the case of an absolute section, an absolute address will be delivered in hexadecimal number.

In the case of a relocatable section, a relative address will be delivered in hexadecimal number from top of the file.

Content of code

CODE section: The instruction (machine language) codes are delivered in hexadecimal numbers. One address corresponds with one instruction. The assembler sets the operand (immediate data) of the code that refers to unresolved address to 0. The immediate data will be decided by the linker.

DATA section: The 4-bit data defined by the *.word* pseudo-instruction are delivered. One address corresponds with one data.

BSS section: Irrespective of the size of the secured area, 00 is always delivered here. Only the address defined for a symbol (top address of the secured area) is delivered as the address of the BSS section.

4.9 Sample Executions

Command line

```
C:\EPSON\S1C63\bin\as63 -g -e -l main.s
```

Assembly source file

```
; main.s
; AS63 test program (main routine)
;

;***** INITIAL SP1 & SP2 ADDRESS DEFINITION *****

#ifdef SMALL_RAM
.set SP1_INIT_ADDR 0xb           ;SP1 init addr = 0x2c
#else
.set SP1_INIT_ADDR 0x4b         ;SP1 init addr = 0x12c
#endif

.set SP2_INIT_ADDR 0x1f         ;SP2 init addr = 0x1f

;***** NMI & BOOT, LOOP *****

.global INIT_RAM_BLK1           ; subroutine in sub.s
.global INC_RAM_BLK1           ; subroutine in sub.s

.org 0x100
NMI:
    calr    INIT_RAM_BLK1       ; initialize RAM block 1
    reti    ; in NMI(watchdog timer)

.org 0x110
BOOT:
    ldb     %ba,SP1_INIT_ADDR
    ldb     %sp1,%ba            ; set SP1
    ldb     %ba,SP2_INIT_ADDR
    ldb     %sp2,%ba            ; set SP2
    calr    INIT_RAM_BLK1       ; initialize RAM block 1

LOOP:
    calr    INC_RAM_BLK1        ; increment RAM block 1
    jr     LOOP                 ; infinity loop

;***** RAM block *****

.org 0x0
.bss
.comm RAM_BLK0, 4
.comm RAM_BLK1, 4
```

Preprocessed file

```

.stabs "C:\EPSON\S1C63\Test\main.s", FileName
; main.s
; AS63 test program (main routine)
;

;***** INITIAL SP1 & SP2 ADDRESS DEFINITION *****

#ifdef SMALL_RAM
; .set SP1_INIT_ADDR 0xb          ;SP1 init addr = 0x2c
#else
.set SP1_INIT_ADDR 0x4b          ;SP1 init addr = 0x12c
#endif

.set SP2_INIT_ADDR 0x1f          ;SP2 init addr = 0x1f

;***** NMI & BOOT, LOOP *****

.global INIT_RAM_BLK1           ; subroutine in sub.s
.global INC_RAM_BLK1            ; subroutine in sub.s

.org 0x100
NMI:
.stabn 23, LineInfo
    calr    INIT_RAM_BLK1        ; initialize RAM block 1
.stabn 24, LineInfo
    reti    ; in NMI (watchdog timer)

.org 0x110
BOOT:
.stabn 28, LineInfo
    ldb     %ba,SP1_INIT_ADDR
.stabn 29, LineInfo
    ldb     %sp1,%ba             ; set SP1
.stabn 30, LineInfo
    ldb     %ba,SP2_INIT_ADDR
.stabn 31, LineInfo
    ldb     %sp2,%ba             ; set SP2
.stabn 32, LineInfo
    calr    INIT_RAM_BLK1        ; initialize RAM block 1
LOOP:
.stabn 34, LineInfo
    calr    INC_RAM_BLK1         ; increment RAM block 1
.stabn 35, LineInfo
    jr     LOOP                  ; infinity loop

;***** RAM block *****

.org 0x0
.bss
.comm    RAM_BLK0, 4
.comm    RAM_BLK1, 4
.stabn 0, FileEnd

```

Assembly list file

Assembler 63 ver x.xx Relocatable List File MAIN.LST Mon Jan 15 12:40:41 2001

```

1:          ; main.s
2:          ; ASM63 test program (main routine)
3:          ;
4:
5:          ;***** INITIAL SP1 & SP2 ADDRESS DEFINITION *****
6:
7:          #ifdef SMALL_RAM
8:             .set SP1_INIT_ADDR 0xb          ;SP1 init addr = 0x2c
9:          #else
10:             .set SP1_INIT_ADDR 0x4b        ;SP1 init addr = 0x12c
11:          #endif
12:
13:             .set SP2_INIT_ADDR 0x1f        ;SP2 init addr = 0x1f
14:
15:
16:          ;***** NMI & BOOT, LOOP *****
17:
18:             .global INIT_RAM_BLK1          ; subroutine in sub.s
19:             .global INC_RAM_BLK1          ; subroutine in sub.s
20:
21:             .org 0x100
22:          NMI:
23: 0100 0200    calr    INIT_RAM_BLK1          ; initialize RAM block 1
24: 0101 1ff9    reti                                ; in NMI(watchdog timer)
25:
26:             .org 0x110
27:          BOOT:
28: 0110 0900    ldb     %ba,SP1_INIT_ADDR
29: 0111 1fc4    ldb     %sp1,%ba                ; set SP1
30: 0112 0900    ldb     %ba,SP2_INIT_ADDR
31: 0113 1fc6    ldb     %sp2,%ba                ; set SP2
32: 0114 0200    calr    INIT_RAM_BLK1          ; initialize RAM block 1
33:          LOOP:
34: 0115 0200    calr    INC_RAM_BLK1          ; increment RAM block 1
35: 0116 0000    jr     LOOP                    ; infinity loop
36:
37:
38:          ;***** RAM block *****
39:
40:             .org 0x0
41:             .bss
42: 0000 00      .comm  RAM_BLK0, 4
43: 0004 00      .comm  RAM_BLK1, 4

```

Error file

Assembler 63 Ver x.xx Error log file MAIN.ERR Mon Jan 15 12:40:41 2001

Assembler 63 Ver x.xx
 Copyright (C) SEIKO EPSON CORP. 1998-2001

Created preprocessed source file MAIN.MS
 Created relocatable list file MAIN.LST
 Created error log file MAIN.ERR
 Created relocatable object file MAIN.O

Assembly 0 error(s) 0 warning(s)

4.10 Error/Warning Messages

4.10.1 Errors

When an error occurs, no object file will be generated.

The assembler error messages are delivered/displayed in the following format:

<Source file name> (<Line number>) Error : <Error message>

Example: TEST.S(431) Error: Illegal syntax

* Some error messages are displayed without a line number.

The assembler error messages are given below:

Error message	Description
Address out of range	The specified address is out of range.
Cannot open <file kind> file <FILE NAME>	The specified file cannot be opened.
Cannot read <file kind> file <FILE NAME>	The specified file cannot be read.
Cannot write <file kind> file <FILE NAME>	Data cannot be written to the file.
Directory path length limit <directory path length limit> exceeded	The path name length has exceeded the limit.
Division by zero	The divisor in the expression is 0.
File name length limit <file name length limit> exceeded	The file name length has exceeded the limit.
Illegal macro label <label>	The internal branch label in macro definition is incorrect.
Illegal macro parameter <parameter>	The macro parameter is illegal.
Illegal syntax	The statement has a syntax error.
Line length limit <line length limit> exceeded	The number of characters in one line has exceeded the limit.
Macro parameter range <macro parameter range> exceeded	The number of macro parameters has exceeded the limit.
Memory mapping conflict	The address is already used.
Multiple statements on the same line	Two or more statements were described on one line.
Nesting level limit <nesting level limit> exceeded	Nesting of #include has exceeded the limit.
Number of macro labels limit <number of macro label limit> exceeded	The number of internal branch labels has exceeded the limit.
Out of memory	Cannot secure memory space.
Second definition of label <label>	The label is already defined.
Second definition of symbol <symbol>	The symbol is already defined.
Symbol name length limit <symbol name length limit> exceeded	The symbol name length has exceeded the limit.
Token length limit <token length limit> exceeded	The token length has exceeded the limit.
Unexpected character <name>	An invalid character has been used.
Unknown label <label>	Reference was made to an undefined label.
Unknown mnemonic <name>	A nonexistent instruction was used.
Unknown register <name>	A nonexistent register name was used.
Unknown symbol <name>	A reference to an undefined symbol was made.
Unknown symbol mask <name>	The symbol mask has a description error.
Unsupported directive <directive>	A nonexistent pseudo-instruction was used.

4.10.2 Warning

When a warning occurs, the assembler will keep on processing, and terminates the processing after displaying a warning message, unless an error is produced.

The warning message is delivered / displayed in the following formats:

<Source file name> (<Line number>) Warning : <Warning message>

Example: TEST.S(41) : Warning : Expression out of range

The warning messages are given below:

Warning message	Description
Expression out of range	The result of the expression is out of the effective range.
Invalid symbol mask	The symbol mask is not defined correctly.
Second definition of define symbol <symbol>	The symbol is already defined.
Section activation expected, use <.code/.bss>	There is no section definition.
Missing Delimiter	A comma is necessary between operands.

4.11 Precautions

- (1) Nesting of the *#include* pseudo instruction is limited to a maximum 10 levels. If this limit is surpassed, an error will result.
- (2) A maximum of 64 internal branch labels can be specified per macro and maximum 9999 internal branch labels can be expanded within one source file. If these limits are exceeded, an error will result.
- (3) Other limitations such as the number of sections depend on the free memory space.

For the restrictions, support functions and bug information of the latest version, refer to rel_asm_E.txt of S5U1C63000A.

CHAPTER 5 LINKER

This chapter describes the functions of the linker, lk63.

5.1 Functions

The linker lk63 is a software that generates executable object files. It provides the following functions:

- Puts together multiple object modules to create one executable object file.
- Resolves external reference from one module to another.
- Relocates relative addresses to absolute addresses.
- Delivers debugging information, such as line numbers and symbol information, in the object file created after linking.
- Capable of outputting a link map file, symbol file, absolute list file and a cross reference file.
- Automatic page correction function (insertion/removal/correction of the "ldb %ext, imm8" branch extension instruction) for branch instructions.

5.2 Input/Output Files




Fig. 5.2.1 Flow chart

5.2.1 Input Files

Relocatable object file * This file must always be specified in either a command line or a link command file.

File format: Binary file in IEEE-695 format

File name: <File name>.o (A path can also be specified.)

Description: Object file of individual modules created by the assembler.

Linker command file

File format: Text file

File name: <File name>.cm (A path can also be specified.)

Description: File to specify the linker options. This makes it possible to reduce typing in a command line. This file is dispensable if all start-up options can be input in a command line.

ICE parameter file * This file must always be specified in either a command line or a link command file.

File format: Binary file

File name: <File name>.par (A path can also be specified.)

Description: File to specify the memory mapping and unsupported instruction information of each S1C63 Family model. This file is provided for each model and commonly used with the debugger and HEX converter.

5.2.2 Output Files

An output file name can be specified in the command line or command file using the `-o` start-up option. If no output file name is specified, the same name as that of the relocatable object file to be linked first is used.

Absolute object file

File format: Binary file in IEEE-695 format

File name: <File name>.abs

Output destination: Current directory

Description: Object file in executable format that can be input to the debugger. All the modules comprising one program are linked together in the file, and the absolute addresses that all the codes will map are determined. It also contains the necessary debugging information in IEEE-695 format.

Link map file

File format: Text file

File name: <File name>.map

Output destination: Current directory

Description: Mapping information file showing from which address of a section each input file was mapped. This file is output when the `-m` start-up option is specified.

Symbol file

File format: Text file

File name: <File name>.sym

Output destination: Current directory

Description: Symbols defined in all the modules and their address information are delivered to this file. This file is delivered when the `-s` start-up option is specified.

Cross reference file

File format: Text file

File name: <File name>.xrf

Output destination: Current directory

Description: Labels defined in all the modules and their defined and referred addresses are delivered in this file. This file is delivered when the `-x` start-up option is specified.

Absolute list file

File format: Text file

File name: <File name>.als

Output destination: Current directory

Description: File delivered when the `-l` start-up option is specified. The file contents are similar to the relocatable list file output by the assembler except that the location addresses are absolute and takes the form of an integrated single file.

Error file

File format: Text file

File name: lk63.err

Output destination: Current directory

Description: The file is created if the `-e` start-up option is specified. It records the information which the linker outputs to the Standard Output (stdout), such as error messages. The file name is "lk63.err" by default, but it can be changed using the `-o` start-up option.

5.3 Starting Method

General form of command line

lk63 ^ [Options] ^ [<Relocatable object files>] ^ [<Linker command file>] ^ <ICE parameter file>

^ denotes a space.

[] indicates the possibility to omit.

The order of options and file names can be arbitrary.

File names

Files are identified with their extensions. Therefore, an appropriate extension should be included in each file name. However, the extension ".o" of the relocatable object file can be omitted.

Relocatable object files: <File name.o>

Linker command file: <File name.cm>

ICE parameter file: <File name.par>

When using a linker command file, options, relocatable object file names, an ICE parameter file name and an output file name can be described in the linker command file. If all the items to be specified are entered in a command line, the linker command file is not necessary.

When linking multiple relocatable object files from a command line, one or more spaces should be placed between the file names.

For the output file name, specify an absolute object file name (.abs). The file name will be used for other output files. If no absolute object file name is specified, the same name as that of the relocatable object file to be linked first is used as the output file name.

The ICE parameter file cannot be omitted.

A long file name supported in Windows and a path name can be specified. When including spaces in the file name, enclose the file name with double quotation marks ("").

Options

The linker comes with the following options:

-d

Function: Disable full branch optimization

Explanation: Disables automatic insertion/deletion/correction of the extension codes (ldb %ext, imm8) for branch instructions (jumps and calls).

Default: If this option is not specified, the branch optimization function will be enabled.

-di

Function: Disable insertion of branch extension

Explanation: Disables extension code insertion when the branch optimization function (insertion/deletion/correction) is enabled.

Default: If this option is not specified, necessary extension codes will be inserted when the full branch optimization function is specified.

-dr

Function: Disable removal branch optimization

Explanation: Disables extension code deletion when the branch optimization function (insertion/deletion/correction) is enabled. This will be needed when at least the existing extension codes should not be removed.

Default: If this option is not specified, unnecessary extension codes will be removed when the full branch optimization function is specified.

-e

Function: Output of error file
 Explanation: Creates an .err file which contains the information that the linker outputs to the Standard Output (stdout), such as error messages.
 Default: If this option is not specified, no error file will be created.

-g

Function: Addition of debugging information
 Explanation:

- Creates an absolute object file containing debugging information.
- Always specify this function when you perform source display or use the symbolic debugging facility of the debugger.

 Default: If this option is not specified, no debugging information will be added to the absolute object file.

-l

Function: Output of absolute list file
 Explanation: Outputs an absolute list file.
 Default: If this option is not specified, no absolute list file will be output.

-m

Function: Output of link map file
 Explanation: Outputs a link map file.
 Default: If this option is not specified, no link map file will be output.

-o <file name>

Function: Specification of output path/file name
 Explanation: Specifies an output path/file name without extension or with an extension ".abs". If no extension is specified, ".abs" will be supplemented at the end of the specified output path/file name.
 Default: The 1st input file name is used for the output file names.

-s

Function: Output of symbol file
 Explanation: Outputs a symbol file.
 Default: If this option is not specified, no symbol file will be output.

-x

Function: Output of cross reference file
 Explanation: Outputs a cross reference file.
 Default: If this option is not specified, no cross reference file will be output.

-code <address>

Function: Set up of a relocatable CODE section start address
 Explanation:

- Sets the absolute start address of a relocatable CODE section. Absolute sections remain unaffected.
- CODE sections are mapped in succession from this address, unless otherwise specified.
- One or more spaces or tabs are necessary between -code and <address>.
- The address should be described in hexadecimal format (0xnrrrr).

 Default: If this option is not specified, the CODE section will begin from the code ROM physical start address specified with the ICE parameter file.

Sample description: `-code 0x100`

-data <address>

Function: Set up of a relocatable DATA section start address
 Explanation:

- Sets the absolute start address of a relocatable DATA section. Absolute sections remain unaffected.
- DATA sections are mapped in succession from this address, unless otherwise specified.
- One or more spaces or tabs are necessary between -data and <address>.
- The address should be described in hexadecimal format (0xnrrrr).

 Default: If this option is not specified, the DATA section will begin from the data ROM physical start address specified with the ICE parameter file.

Sample description: `-data 0x8000`

-bss <address>

Function: Set up of a relocatable BSS section start address

- Explanation:
- Sets the absolute start address of a relocatable BSS section. Absolute sections remain unaffected.
 - BSS sections are mapped in succession from this address, unless otherwise specified.
 - One or more spaces or tabs are necessary between `-bss` and `<address>`.
 - The address should be described in hexadecimal format (0xnnnn).

Default: If this option is not specified, the BSS section will begin from the RAM physical start address specified with the ICE parameter file.

Sample description: `-bss 0x000`

-rcode <file name>=<address>

Function: Set up of the file-specific CODE section start address

- Explanation:
- Sets the absolute address to map the CODE section of the specified module. This command serves to specify a module having a code to be fixed at a specific address, such as the interrupt vector. Absolute sections in the specified file remain unaffected.
 - One or more spaces or tabs are necessary between `-rcode` and `<file name>`.
 - The address should be described in hexadecimal format (0xnnnn).

Default: If this option is not specified, the CODE section of each module is mapped continuously from the address that was set by the `-code` option.

Sample description: `-rcode test1.o = 0x0110`

-rdata <file name>=<address>

Function: Set up of the file-specific DATA section start address

- Explanation:
- Sets the absolute address to map the DATA section of the specified module. This command serves to specify a module having data to be fixed at a specific address of the data ROM. Absolute sections in the specified file remain unaffected.
 - One or more spaces or tabs are necessary between `-rdata` and `<file name>`.
 - The address should be described in hexadecimal format (0xnnnn).

Default: If this option is not specified, the DATA section of each module is mapped continuously from the address that was set by the `-data` option.

Sample description: `-rdata test1.o = 0x8100`

-rbss <file name>=<address>

Function: Set up of the file-specific BSS section start address

- Explanation:
- Sets the absolute address to map the BSS section of the specified module. This command serves to specify a module having a symbol to be fixed at a specific address of the RAM. Absolute sections in the specified file remain unaffected.
 - One or more spaces or tabs are necessary between `-rbss` and `<file name>`.
 - The address should be described in hexadecimal format (0xnnnn).

Default: If this option is not specified, the BSS section of each module is mapped continuously from the address that was set by the `-bss` option.

Sample description: `-rbss test1.o = 0x100`

-defsym <symbol name>=<address>

Function: Specification of a global symbol address

- Explanation:
- The absolute address of a global symbol is given for the referencing side.
 - The symbols to be specified with this option should not be defined in the source as an actual address label that can be referred to.
 - One or more spaces or tabs are necessary between `-defsym` and `<symbol name>`.

Sample description: `-defsym BOOT = 0x100`

When inputting an option in the command line, one or more spaces are necessary before and after the option.

Examples: `c:\epson\s1c63\bin\lk63 -defsym INIT=0x200 test.cm par63xxx.par`
`c:\epson\s1c63\bin\lk63 -g -e -s -m test1.o test2.o -o test.abs par63xxx.par`

5.4 Messages

The linker delivers all its messages to the Standard Output (stdout).

Start-up message

The linker outputs only the following message when it starts up.

```
Linker 63 Ver x.xx
Copyright (C) SEIKO EPSON CORP. 1998-2001
```

End message

The linker outputs the following messages to indicate which files has been created when it ends normally.

```
Created absolute object file <FILENAME.ABS>
Created absolute list file <FILENAME.ALS>
Created map file <FILENAME.MAP>
Created symbol file <FILENAME.SYM>
Created cross reference file <FILENAME.XRF>
Created error log file <FILENAME.ERR>

Link 0 error(s) 0 warning(s)
```

Usage output

If no file name was specified or an option was not specified correctly, the linker ends after delivering the following message concerning the usage:

```
Usage: lk63 [options] <file names>
Options: -d          Disable full branch optimization
         -dr         Disable removal branch optimization
         -e          Output error log file (.ERR)
         -g          Add source debug information
         -l          Output absolute list file (.ALS)
         -m          Output map file (.MAP)
         -o <file name> Specify output file name
         -s          Output symbol file (.SYM)
         -x          Output cross reference file (.XRF)
         -code <address> Specify CODE start address
         -data <address> Specify DATA start address
         -bss <address> Specify BSS start address
         -rcode <file name>=<address> Specify CODE start address of the file
         -rdata <file name>=<address> Specify DATA start address of the file
         -rbss <file name>=<address> Specify BSS start address of the file
         -defsym <symbol>=<address> Define symbol address

File names: Relocatable object file (.O)
            Command parameter file (.CM)
            ICE parameter file (.PAR)
```

When error/warning occurs

If an error takes place, an error message will appear before the end message shows up.

Example:

```
Error: Cannot create absolute list file TEST.ABS
Link 1 error(s) 0 warning(s)
```

In the case of an error, the linker ends without creating an output file.

If a warning is issued, a warning message will appear before the end message shows up.

Example:

```
Warning: No debug information in TEST.O
Link 0 error(s) 1 warning(s)
```

In the case of a warning, the linker ends after creating an output file, but the result cannot be guaranteed.

For details on errors and warnings, refer to Section 5.12, "Error/Warning Messages".

5.5 Linker Command File

To simplify the keystroke in the command line at the time of start up, execute the link processing through the linker by inputting a linker command file (.cm) that holds the necessary specifications (any options and file names) described.

Sample linker command file

```

-e                ; Generate error file
-g                ; Add debug information
-code 0x0100      ; Fix CODE section start address
-rcode test2.o = 0x0110 ; Fix CODE section start position of test2.o
-data 0x8000      ; Fix DATA section start address
-bss 0x00e0       ; Fix BSS section start address

-defsym IO = 0xFF00 ; Set global symbol

-o test.abs       ; Specify output file name
test1.o           ; Specify input file 1
test2.o           ; Specify input file 2

```

Create the linker command file with the following rules:

File format

The linker command file is a general text format as shown above.
".cm" should be used for the file name extension.

Option description

All options should begin with a hyphen (-). Each individual option needs to be delineated with more than one space, tab, or line feed. For better visibility, it is recommended to describe each option in a separate line.

Notes:

- A numeric value to specify an address should be described in the hexadecimal format (0xn_{nnnn}). Decimal and binary notations will not be accepted.

- When an option that is only permitted in single setting is specified in a duplicated manner, the last entered option will be effective.

Example: `-code 0x0000`
`-code 0x0100` ... `-code 0x0100` is effective.

Input file specification

Describe the relocatable object file names at the end of the link command file. The mapping by linking takes place in described order, unless otherwise specified.

The extension (.o) of the relocatable object files can be omitted.

Comment

A comment can be described in the linker command file.

As in the source file, the character string from a semicolon (;) to the end of the line is regarded as a comment.

Blank line

A blank line carrying only blank characters and a line feed will be ignored. It need not be converted to a comment using a semicolon.

5.6 Link Map File

The link map file serves to refer to the mapping information for the modules of each section. It is output if the -m option is specified.

The file format is a text file, and its file name is "<File name>.map". (<File name> is the same as that of the output object file.)

Sample link map file

```

Linker 63 ver x.xx Link map file TEST.MAP Mon Jan 15 12:40:41 2001

CODE section map of TEST.ABS
Index  Start    End      Size     Opt  Type File          SecNbr
  0: 0x0000  0x000d  0x000e   +0  Rel  SUB.S          1
  1: 0x000e  0x00ff  0x00f2   ---  ---  -----
  2: 0x0100  0x0102  0x0003   +1  Abs  MAIN.S         1
  3: 0x0103  0x010f  0x000d   ---  ---  -----
  4: 0x0110  0x0118  0x0009   +2  Abs  MAIN.S         2
  5: 0x0119  0x1fff  0x1ee7   ---  ---  -----
Total: 0x1a occupied, 0x1fe6 blank

BSS section map of TEST.ABS
Index  Start    End      Size     Type File          SecNbr
  0: 0x0000  0x0007  0x0008   Rel  MAIN.S         3
  1: 0x0008  0xf2bf  -----   ---  -----
  2: 0xf800  0xf8ff  -----   ---  -----
  3: 0xff00  0xffff  -----   ---  -----
Total: 0x8 occupied, 0xf4b8 blank
    
```

Contents of link map file

- Index** Indicates the index number of the section.
 - Start** Indicates the start address of the section.
 - End** Indicates the end address of the section.
 - Size** Indicates the size of the section.
 - Opt** Indicates the number of extension codes that are inserted or removed.
 - Type** Indicates the section type: Rel = relocatable section and Abs = absolute section.
 - File** Indicates the file names of the linked module.
 - SecNbr** Indicates the section number.
 - Total** Indicates the total map size and the unused area size.
- "---" in the Size, Opt, Type, File and SecNbr columns indicate that no section is allocated.

5.7 Symbol File

The symbol file serves to refer to the symbols defined in all the modules and their address information. It is delivered if the `-s` start-up option is specified.

The file format is a text file, and its file name is "`<File name>.sym`". (`<File name>` is the same as that of the output object file.)

Sample symbol file

```

Linker 63 ver x.xx Symbol file TEST.SYM Mon Jan 15 12:40:41 2001

CODE section labels of TEST.ABS
Address Type   File           Symbol
0x0110 Local  "MAIN.O"     .... BOOT
0x0007 Global "SUB.O"     .... INC_RAM_BLK1
0x0000 Global "SUB.O"     .... INIT_RAM_BLK1
0x0116 Local  "MAIN.O"     .... LOOP
0x0100 Local  "MAIN.O"     .... NMI

BSS section labels of TEST.ABS
Address Type   File           Symbol
0x0000 Global "MAIN.O"     .... RAM_BLK0
0x0004 Global "MAIN.O"     .... RAM_BLK1

```

Contents of symbol file

- Symbol** Indicates all the defined symbols in alphabetical order.
- Address** Indicates the absolute address defined for the symbol.
- Type** Indicates the scope of the symbol: Global or Local.
- File** Indicates the object file in which the symbol has been defined.

5.8 Absolute List File

The absolute list file is an assembly source file that carries the absolute addresses and object codes added to the first half of each line. It is delivered only when the `-l` option is specified. Its file format is a text file, and the file name is `<file name>.als`. (The `<file name>` is the same as that of the output object file.) While a relocatable list file can be made for each assembly source file, the absolute list file is made as a single file integrating all the linked objects and their according sources.

Sample absolute list file

Linker 63 ver x.xx Absolute list file TEST.ALS Mon Jan 15 12:40:41 2001

```

1:                ; sub.s
2:                ; AS63 test program (subroutine)
3:
4:                .global RAM_BLK1
5:
6:                ;***** RAM block 1 initialize *****
7:
8:                .global INIT_RAM_BLK1
9:                INIT_RAM_BLK1:
10: 0000 0800      ldb    %ext, RAM_BLK1@h
11: 0001 0a04      ldb    %xl, RAM_BLK1@l ;set RAM_BLK1 address to x
12: 0002 1e90      ld     [%x]+, 0x0
   :           :
55:                .org    0x110
56:                BOOT:
57: 0110 094b      ldb    %ba, SP1_INIT_ADDR
58: 0111 1fc4      ldb    %sp1, %ba      ; set SP1
59: 0112 091f      ldb    %ba, SP2_INIT_ADDR
60: 0113 1fc6      ldb    %sp2, %ba      ; set SP2
61: 0114 08fe      (+)   ldb    ext, fe
62: 0115 02ea      calr   INIT_RAM_BLK1 ; initialize RAM block 1
63:                LOOP:
64: 0116 08fe      (+)   ldb    ext, fe
65: 0117 02ef      calr   INC_RAM_BLK1  ; increment RAM block 1
66: 0118 00fd      jr     LOOP          ; infinity loop
   :           :

```

Contents of absolute list file

The format of each line of the absolute list file is as follows:

Line No. Absolute address Code Source statement

Line No. Indicates the line number from the top of the file.

Address Indicates the absolute address after the instruction is allocated.

Code Indicates the object code.

Source The contents of the assembly source file are delivered.

Results of branch optimization (extension code insertion/deletion/correction)

As the result of branch optimization, extension codes (`ldb %ext, imm8`) may be coded without accordance to the source part. To show the result of such code optimizations clearly, the following description will be made on an absolute list file.

When an extension code is inserted:

"(+)" is placed to the right of the code part. There is no original source for the code but the disassembled "`ldb %ext, imm8`" is delivered at the source part.

When an extension code is deleted:

"(-)" is placed to the left of the original source part. The original statement appears at the source part in the list file but no code is delivered.

When the operand of an extension code is corrected:

"(*)" is placed to the left of the source statement.

Instructions preprocessed in the assembler

The instructions expanded in the assembler (macros and include sources) are listed with a "+".

5.9 Cross Reference File

The cross reference file enumerates all the address labels with their absolute addresses and all the addresses where the address labels are referred to. It is delivered only when the `-x` option is specified. Its file format is a text file, and the file name is `<file name>.xrf`. (The `<file name>` is the same as that of the output object file.)

Sample cross reference file

```

Linker 63 ver x.xx Cross reference file TEST.XRF Mon Jan 15 12:40:41 2001

Label "INIT_RAM_BLK1" at 0x0000  SUB.O  CODE, Global
    0x0101  MAIN.O  CODE
    0x0115  MAIN.O  CODE

Label "RAM_BLK0" at 0x000  MAIN.O  BSS, Global
    0x0101  MAIN.O  CODE
    0x0115  MAIN.O  CODE

Label "RAM_BLK1" at 0x004  MAIN.O  BSS, Global
    0x0000  SUB.O  CODE
    0x0001  SUB.O  CODE
    0x0007  SUB.O  CODE
    0x0008  SUB.O  CODE

Label "INC_RAM_BLK1" at 0x0007  "SUB.O"  CODE, Global
    0x0117  MAIN.O  CODE

Label "NMI" at 0x0100  MAIN.O  CODE, Local

Label "BOOT" at 0x0110  MAIN.O  CODE, Local

Label "LOOP" at 0x0116  MAIN.O  CODE, Local
    0x0118  MAIN.O  CODE

```

Contents of cross reference file

The format of each label information is as follows:

Label information

`<Address> <File name> <Type>`

Label information

Indicates the following information:

- Label name
- Defined address
- Object file in which the label is defined.
- Section type
- Scope

Address Indicates the address where the label is referred.

File Indicates the object file in which the label is referred.

Type Indicates the type of section that contains the address where the label is referred.

5.10 Linking

Linking rules

The linking process takes place in conformity with the following rules:

- Absolute sections are mapped ahead of relocatable sections, according to the absolute addresses which were defined at the time of assembling. If an absolute section exceeds the available memory area, an error will occur.
- The relocatable sections in the file of which the section start address was specified with an option (-rcode, -rdata, -rbss) are mapped from the specified address. Other relocatable sections are mapped from top of the relocatable CODE/DATA/BSS section.
- Basically, the relocatable sections except those that are specified with the -rcode, -rdata or -rbss option are arranged successively in the order of processing. However, if a relocatable section cannot be mapped subsequent to the previous mapped section, for instance, there is unused area indicated by the ICE parameter file or an already mapped absolute section, the linker searches another area to map the section. If there is no available area, an error will occur. A section is not divided into two or more blocks when it is mapped.

After that, another section may be mapped in the vacant area if it is possible to map there.

Restrictions on linking

Note that all sections may not be mapped depending on each section size or address specifications even if the relocatable object size is within the available memory size.

Example of linking

A sample case where two relocatable object files, "test1.o" and "test2.o", are linked together under the following condition is described further below.

Memory configuration of the model

Code ROM: 0x0000 to 0x1fff
 Data ROM: 0x8000 to 0x87ff
 RAM: 0x0000 to 0x07ff
 Display, I/O memory: 0xf000 to 0xffff

Relocatable object files




Fig. 5.10.1 Structure of sample relocatable files

Sample linker command file

```
-code 0x0000           ; Relocatable CODE section start address
-rcode test2.o = 0x0110 ; CODE section start address of test2.o
-data 0x8000           ; Relocatable DATA section start address
-bss 0x0000           ; Relocatable BSS section start address
-rbss test2.o = 0x0400 ; BSS section start address of test2.o
-o test.abs           ; Output file name
test1.o               ; Input file 1
test2.o               ; Input file 2
```

When linking is executed with the commands defined above, the linker maps the sections of each module in the manner graphically presented in Figure 5.10.2.




Fig. 5.10.2 Example of linking

The absolute sections CODE2, BSS2, DATA2 and BSS3 are mapped to the location specified in the source files.

The start addresses of the CODE and BSS relocatable sections in "test2.o" is specified by the `-rcode` and `-rbss` options, so CODE3 is mapped from address 0x0110 and CODE 4 follows CODE3. BSS4 is mapped from address 0x0400.

Since the start addresses of the relocatable CODE, DATA and BSS sections in "test1.o" have not been specified, they are mapped from the relocatable section start addresses specified by the `-code`, `-data` and `-bss` options. First the linker will try to map CODE1 from address 0x0000 to address 0x00ff. If CODE 1 is smaller than 0x100 words, CODE1 can be mapped from address 0x0000. In this example, CODE1 is mapped behind CODE4 because CODE1 is larger than 0x100 words.

DATA1 is mapped from address 0x8000 and BSS1 is mapped from address 0x0000.

A section cannot be overlapped to other sections, therefore an error will occur if there is no free area larger than the section size. For example, an error will occur if CODE2 is larger than 0x10 words.

5.11 Branch Optimization Function

The PC relative branch instructions (jr, jrc, jrnc, jrzc, jrncz and calr) need an address extension instruction (ldb %ext, imm8) when the relative distance to the destination address exceeds the -127 to 128 range. Since the location of relocatable sections is not decided until the linking process is completed, the linker has a function that automatically inserts, removes or corrects the extension codes. This makes it possible to omit the address extension instruction in the source. However, this function is valid only for the branch instructions that use a label to specify the destination address.

This branch optimization function (automatic insertion/deletion/correction of the extension codes) is enabled by default and the branch codes will be optimized unless otherwise specified. All the insertion/deletion/correction functions can be disabled by specifying the -d option. The -di and -dr options can also be specified to disable the extension code insertion and deletion functions, respectively (if the -d option is not specified).

The linker checks the distance from a PC relative branch instruction code to the branch destination label, and inserts, removes or corrects the extension codes according to the check results.

(1) When the branch destination is located within the -127 to +128 range from the branch instruction:

If the branch instruction code does not have an extension code, no extension code is inserted.

If the branch instruction has an extension code, it is removed (if the -dr option is specified, existing expansion code will not be removed).

Examples:

```
jr    LABEL           →    jr    LABEL

ldb  %ext, LABEL@rh
calr LABEL@r1        →    calr LABEL@r1
```

(2) When the branch destination is located outside the -127 to +128 range from the branch instruction:

If the branch instruction code does not have an extension code, an appropriate extension code is inserted.

If the branch instruction has an illegal extension code, it is replaced with a correct extension code.

Examples:

```
jr    LABEL           →    ldb  %ext, LABEL@rh
                               jr    LABEL@r1

ldb  %ext, LABEL1@rh  →    ldb  %ext, LABEL2@rh
calr LABEL2@r1       →    calr LABEL2@r1
```

Unused memory spaces may be generated between sections caused by the branch optimization. In this case the linker moves the relocatable section following an unused area toward a lower address so that the codes are embedded in the unused area.

5.12 Error/Warning Messages

5.12.1 Errors

When an error occurs, the linker will immediately terminate the processing after displaying an error message. No object file will be output. Other files will be delivered only in the part which was processed prior to the occurrence of the error.

The error messages are given below.

Error message	Description
Branch destination too far from <address>	The branch destination address is out of range.
CALZ for non zero page at <address>	The specified address is out of the range (0x0000–0x00ff).
Cannot create absolute object file <FILE NAME>	The absolute object file cannot be created.
Cannot open <file kind> file <FILE NAME>	The file cannot be opened.
Cannot read <file kind> file <FILE NAME>	The file cannot be read.
Cannot relocate <section kind> section of <FILE NAME>	The relocatable section cannot be allocated.
Cannot write <file kind> file <FILE NAME>	Data cannot be written to the file.
Illegal address range <address> for a code at <address>	The address specified by TST/SET/CLR is out of the range (0x0000–0x003f or 0xffc0–0xffff).
Illegal file name <FILE NAME>	The file name is incorrect.
Illegal file name <FILE NAME> specified with option <option>	The file name specified with the option is incorrect.
Illegal ICE parameter at line <line number> of <FILE NAME>	The ICE parameter file contains an illegal parameter setting.
Illegal object <FILE NAME>	The input file is not an object file in IEEE-695 format.
Illegal option <option>	An illegal option is specified.
No address specified with option <option>	Address is not specified with the option.
No code to locate	There is no valid code for mapping.
No ICE parameter file specified	ICE parameter file is not specified.
No name and address specified with option <option>	Name and address are not specified with the option.
No object file specified	Object files to be linked are not specified.
Out of memory	Cannot secure memory space.
<section kind> section <address>-<address> overlaps with <section kind> section <address>-<address>	The address range of the section overlaps with another section's address range.
<section kind> section <address>-<address> overlaps with the unavailable memory	The address range of the section overlaps with the unavailable memory.
Unresolved external <label> in <FILE NAME>	Reference was made to an undefined symbol.
Unusable instruction code <instruction code> in <FILE NAME>	The object contains an instruction invalid for the model.

5.12.2 Warning

Even when a warning appears, the linker continues with the processing. It completes the processing after displaying a warning message, unless, in addition, an error takes place. The output files will all be delivered, but the operation of the program cannot be guaranteed.

The warning messages and their contents are given below.

Warning message	Description
Cannot create <file kind> file <FILE NAME>	The file cannot be created.
Cannot open <file kind> file <FILE NAME>	The file cannot be opened.
No debug information in <FILE NAME>	Debugging information is not included in the file.
No symbols found	Symbols cannot be found.
Second definition of label <label> in <FILE NAME>	The label has already been defined.
Second ICE parameter file <FILE NAME> ignored	Two or more ICE parameter files are specified.

5.13 Precautions

- (1) Upper limits, such as a maximum section count and the number of objects to be linked, depend on the free memory space.
- (2) To load the absolute object file created by the linker to the debugger, the same ICE parameter file must be specified when the debugger is invoked.

For the restrictions, support functions and bug information of the latest version, refer to rel_asm_E.txt of S5U1C63000A.

CHAPTER 6 *HEX CONVERTER*

This chapter describes the functions of hex converter, hx63.

6.1 *Functions*

The hex converter hx63 converts an absolute object file in IEEE-695 format output from the linker into a hex file in Motorola-S format or Intel-HEX format. This conversion is needed when debugging the program with the ROM or when creating mask data using the mask data checker.

When creating the ROM-image hex data, the hex converter fills the unused area of each model with 0xff.

6.2 *Input/Output Files*




Fig. 6.2.1 Flow chart

6.2.1 *Input Files*

Absolute object file

File format: Binary file in IEEE-695 format

File name: <File name>.abs (A path can also be specified.)

Description: Absolute object file created by the linker.

ICE parameter file * This file must always be specified.

File format: Binary file

File name: <File name>.par (A path can also be specified.)

Description: File to specify the memory mapping information of each S1C63 Family model. This file is provided for each model and is commonly used with the linker and debugger.

6.2.2 *Output Files*

Hex file

File format: Text file in Motorola-S format or Intel-HEX format

File name: Motorola-S format <File name>.hsa, <File name>.lsa and <File name>.csa
Intel-HEX format <File name>h.hex, <File name>l.hex and <File name>c.hex

Output destination: Current directory

Description: Three hex files are generated: ".hsa" or "h.hex" that contains the five high-order bits of the object codes with 0b000 extended, ".lsa" or "l.hex" that contains the eight low-order bits and ".csa" or "c.hex" that contains four-bit data for the data ROM.

Motorola-S format files are delivered by default. Intel-HEX format files can be specified using the -i option.

Error file

File format: Text file

File name: hx63.err

Output destination: Current directory

Description: The file is created if the -e start-up option is specified. It records information that the hex converter outputs to the Standard Output (stdout), such as error messages. The file name is "hx63.err" by default, but it can be changed using the -o start-up option.

6.3 Starting Method

General form of command line

hx63 ^ [Options] ^ <Absolute object file name> ^ <ICE parameter file name>

^ denotes a space.

[] indicates the possibility to omit.

The order of options and file names can be arbitrary.

File names

Absolute object file: <File name>.abs

ICE parameter file: <File name>.par

The extension of an absolute object file can be omitted. The ICE parameter file must be specified with its extension.

A long file name supported in Windows and a path name can be specified. When including spaces in the file name, enclose the file name with double quotation marks ("").

Options

The hex converter comes provided with the following four start-up options:

-b

Function: Conversion of existing codes only

Explanation: Converts and delivers only the object codes that exist in the specified absolute object file. Data for unused addresses is not delivered.

Default: If this option is not specified, the hex data for the entire available memory range of the model is delivered to the output file. Unused addresses are filled with 0xff.

-e

Function: Output of error files

Explanation: Creates an .err file which contains the information that the hex converter outputs to the Standard Output (stdout), such as error messages.

Default: If this option is not specified, no error file will be created.

-i

Function: Conversion into Intel-HEX format

Explanation: Generates the hex files ("h.hex", "l.hex" and "c.hex") in Intel-HEX format.

Default: If this option is not specified, Motorola-S format files (".hsa", ".lsa" and ".csa") are generated.

-o <file name>

Function: Specification of output path/file name

Explanation: Specifies an output path/file name without extension or with an extension ".hsa", ".lsa", ".csa", "h.hex", "l.hex" or "c.hex". By specifying only one file name, three hex files will be generated.

If no extension is specified, an appropriate extension will be supplemented at the end of the specified output path/file name. In this case, ".hsa", ".lsa" or ".csa" is added to the output file name. If Intel-HEX format is specified, "h.hex", "l.hex" or "c.hex" is added to the output file name. It may change a DOS file name (8 characters max.) to a long file name for Windows.

Default: The input file name is used for the output file names.

When entering an option in the command line, one or more spaces are necessary before and after the option.

Example: c:\epson\s1c63\bin\hx63 -e test.abs par63xxx.par

6.4 Messages

The hex converter delivers all its messages via the Standard Output (stdout).

Start-up message

The hex converter outputs only the following message when it starts up.

```
Hex converter 63 Ver x.xx
Copyright (C) SEIKO EPSON CORP. 1998-2001
```

End message

The hex converter outputs the following messages to indicate which files have been created when it ends normally.

```
Created hex file <FILE NAME>.HSA
Created hex file <FILE NAME>.LSA
Created hex file <FILE NAME>.CSA
Created error log file HX63.ERR
```

```
Hex conversion 0 error(s) 0 warning(s)
```

Usage output

If no file name was specified or an option was not specified correctly, the hex converter ends after delivering the following message concerning the usage:

```
Usage: hx63 [options] <file names>
Options: -b          Do not fill unused memory with 0xff
         -e          Output error log file (HX63.ERR)
         -i          Use Intel Hex format
         -o <file name> Specify output file name
File names: Absolute object file (.ABS)
            ICE parameter file (.PAR)
```

When error/warning occurs

If an error occurs, an error message will appear before the end message shows up.

Example:

```
Error : No ICE parameter file specified
Hex conversion 1 error(s) 0 warning(s)
```

In the case of an error, the hex converter ends without creating an output file.

If a warning is issued, a warning message will appear before the end message shows up.

Example:

```
Warning : Output file name conflict
Hex conversion 0 error(s) 1 warning(s)
```

In the case of a warning, the hex converter ends after creating the output files, but the result cannot be guaranteed.

For details on errors and warnings, refer to Section 6.6 "Error/Warning Messages".

6.5 Output Hex Files

6.5.1 Hex File Configuration

Since each S1C63000 instruction has a 13-bit code, the hex converter always generates two hex files for the high-order data and the low-order data of the program code. The low-order data hex file (".l.sa" or ".l.hex") contains the low-order bytes (bits 7 to 0) of the object codes. The high-order data hex file (".h.sa" or ".h.hex") contains the high-order bytes (bits 12 to 8 suffixed by high-order bits 0b000). 4-bit data for the data ROM is output to the ".c.sa" or ".c.hex" file.

By specifying the -i option, the hex converter can convert the absolute object file into Intel-HEX files as well as Motorola-S format. However, use Motorola-S format when loading the hex files to the debugger or creating the mask data by the mask data checker because the debugger and mask data checker do not support Intel-HEX files.

6.5.2 Motorola-S Format

The hex converter converts an absolute object file in the IEEE-695 format into the Motorola-S2 format files by default.

The files are generated with an extension ".h.sa" for the high-order program file, ".l.sa" for the low-order program file and ".c.sa" for the data ROM file.

The following shows a sample data in Motorola-S2 format:

```

length
 |
 | address
 |-----|
S224000000FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF
S224000020FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFDB
      :
S22400010008E000F04200420606FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF89
      :
S804000000FB
    
```

- S2 (1 bytes): Indicates that the line is a data record.
- S8 (1 bytes): Indicates that the line is an end record (end of data).
- length (1 byte): Indicates the record length of "address + data + sum". The maximum length of a data record is 0x24, while the end record is fixed at 0x04.
- address (3 bytes): Indicates the address where the head data in a record is placed.
- data (32 bytes max.): The object codes are placed here. This is not included in the end record.
- sum (1 byte): This is a checksum (1's complement) from "length" to the last data.

The end records are always "S804000000FB".

6.5.3 Intel-HEX Format

The hex converter converts an absolute object file in the IEEE-695 format into the Intel-HEX format files when the `-i` option is specified.

The files are generated with a name "`<file name>.h.hex`" for the high-order program file, "`<file name>.l.hex`" for the low-order program file and "`<file name>.c.hex`" for the data ROM file.

The following shows a sample data in Intel-HEX format:

```

data volume type
  |         |
  | address |
  |         |
  |         | data
  |         |
  |         | sum
  |         |
:10000000FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF00
:10001000FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF00
:
:1001000008E000F04200420606FFFFFFFFFFFFFFF8E
:
:100FF000FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF01
:
:00000001FF

```

data volume (1 byte): Indicates the data length of each record. The maximum length of a data record is 0x10, while the end record is fixed at 0x00.

address (2 bytes): Indicates the address where the head data in a record is placed.

type (1 byte): Indicates the type of hexadecimal format, currently only "00".

data (16 bytes max.): The object codes are placed here. This is not included in the end record.

sum (1 byte): This is a checksum (2's complement) from "Data volume" to the last data.

The end records are always "00000001FF".

Note: When using hex files for creating the mask data, do not specify Intel-HEX format because the mask data checker does not support this format.

6.5.4 Conversion Range

By default, the hex converter generates the hex files that include all the codes of the ROM area available for each model. Data for unused addresses are delivered as 0xff. For example, if the model has a built-in 2KB code ROM and the program uses the area from address 0x0 to address 0x6ff, the hex converter fills the area from address 0x700 to address 0x7ff with 0xff. If there are unused addresses in the range from 0x0 to 0x6ff, those data are also delivered as 0xff.

When creating the mask data by the mask data checker, the hex files must be generated in this format.

When the `-b` option is specified, the hex converter does not deliver data in unused addresses of the absolute object file. This allows minimization of the output hex files. Note, however that the hex files generated in this format cannot be used for creating the mask data.

6.6 Error/Warning Messages

6.6.1 Errors

When an error occurs, the hex converter immediately terminates the processing after displaying an error message. It will not output hex files.

The hex converter error messages are given below.

Error message	Description
Cannot create <file kind> file <FILE NAME>	The file cannot be created.
Cannot open <file kind> file <FILE NAME>	The file cannot be opened.
Cannot read <file kind> file <FILE NAME>	The file cannot be read.
Cannot write <file kind> file <FILE NAME>	Data cannot be written to the file.
Illegal file name <FILE NAME> specified with option <option>	The specified hex file name is incorrect.
Illegal ICE parameter at line <line number> of <FILE NAME>	The ICE parameter file contains an illegal parameter setting.
Illegal file name <FILE NAME>	The specified input file name is incorrect.
Illegal option <option>	An illegal option is specified.
Illegal absolute object format	The input file is not an object file in IEEE-695 format.
No ICE parameter file specified	ICE parameter file is not specified.
Out of memory	Cannot secure memory space.

6.6.2 Warning

Even if a warning is issued, the hex converter keeps on processing, and completes the processing after displaying a warning message, unless, in addition, any error occurs.

Warning message	Description
Input file name extension .XXX conflict	Two or more file names with the same extension have been specified. The last one is used.

6.7 Precautions

- (1) When creating the hex files for making the mask data file in the mask data checker, specify Motorola-S format and convert for the entire available memory range of the model (do not specify the -b and -i options). Otherwise, an error will occur in the mask data checker. Refer to the "Development Tool Manual" of each model for details of the mask data checker.
- (2) If an 8-character output file name (DOS file name) without extension is specified for the Intel-HEX files, it will be changed to a long file name because "h.hex", "l.hex" or "c.hex" is added to the file name.

For the restrictions, support functions and bug information of the latest version, refer to rel_asm_E.txt of S5U1C63000A.

CHAPTER 7 DISASSEMBLER

This chapter describes the functions of the disassembler, ds63.

7.1 Functions

The disassembler's input is an object in IEEE-695 or Motorola-S format. The code in the object file is disassembled into mnemonics, and output as a source file. The restored source file can be processed in the assembler/linker/hex converter to obtain the same object or hex file.

7.2 Input/Output Files




Fig. 7.2.1 Flow chart

7.2.1 Input Files

Absolute object file

File format: Binary file in IEEE-695 format
 File name: <File name>.abs (A path can also be specified)
 Description: Absolute object file created by the linker

Hex file

File format: Text file in Motorola-S format
 File name: <File name>.hsa, <File name>.lsa and <File name>.csa
 Description: Hex files created by the hex converter. Three hex files are needed: ".hsa" that contains the four high-order bits of the object codes with 0b000 extended, ".lsa" that contains the eight low-order bits and ".csa" that contains four-bit data for the data ROM. If there is no data ROM, the ".csa" file is not required.

7.2.2 Output Files

Source file

File format: Text file
 File name: <File name>.ms
 Output destination: Current directory
 Description: Disassembled contents of the input file are delivered.

Error file

File format: Text file
 File name: ds63.err
 Output destination: Current directory
 Description: The file is created if the -e start-up option is specified. It records the information that the disassembler outputs to the Standard Output (stdout), such as error messages. The file name is "ds63.err" by default, but it can be changed using the -o start-up option.

7.3 Starting Method

General form of command line

ds63 ^ [Options] ^ <Input file names>

^ denotes a space.

[] indicates the possibility to omit.

Input file names

Absolute object file: <File name>.abs

Motorola-S files: <File name>.hsa, <File name>.lsa, <File name>.csa

The input file must be specified with its extension.

The Motorola-S file can be specified with either ".hsa", ".lsa" or ".csa" as the extension. The other unspecified files will be automatically loaded.

A long file name supported in Windows and a path name can be specified. When including spaces in the file name, enclose the file name with double quotation marks ("").

Options

The disassembler comes provided with the following four start-up options:

-cl

Function: Use of lower-case characters

Explanation: Creates all instructions and labels using lower-case characters.

Default: If neither this option nor the -cu option is specified, the source will be made with all labels in upper-case characters and instructions in lower-case characters.

-cu

Function: Use of upper-case characters

Explanation: Creates all instructions and labels using upper-case characters.

Default: If neither this option nor the -cl option is specified, the source will be made with all labels in upper-case characters and instructions in lower-case characters.

-e

Function: Output of error file

Explanation: Creates an .err file which contains the information that the disassembler outputs to the Standard Output (stdout), such as error messages.

Default: If this option is not specified, an error file will not be created.

-o <Output file names>

Function: Specification of file name

Explanation: Specify a file name without extension or with the extension ".ms". If no extension is specified, ".ms" will be supplemented at the end of the file name.

Default: The input file name is used for the output file name.

When entering an option in the command line, one or more spaces are necessary before and after the option.

Example: c:\epson\s1c63\bin\ds63 -e -o output.ms c\input.abs

7.4 Messages

The disassembler delivers all its messages via the Standard Output (stdout).

Start-up message

The disassembler outputs the following message when it starts up.

```
Disassembler 63 Ver x.xx
Copyright (C) SEIKO EPSON CORP. 1998-2001
```

End message

The disassembler outputs the following messages to indicate which files have been created when it ends normally.

```
Created preprocessed source file <FILE NAME>.MS
Created error log file DS63.ERR
```

```
Disassembly 0 error(s) 0 warning(s)
```

Usage output

If no file name was specified or an option was not specified correctly, the disassembler ends after delivering the following message concerning the usage:

```
Usage: ds63 [options] <file name>
Options: -cl          Use lower case characters
         -cu          Use upper case characters
         -e           Output error log file (DS63.ERR)
         -o <file name> Specify output file name
File names: Absolute object file (.ABS or .CSA/.LSA/.HSA)
```

When error/warning occurs

If an error occurs, an error message will appear before the end message shows up.

Example:

```
Error: Cannot open file TEST.ABS
Disassembly 1 error(s) 0 warning(s)
```

In the case of an error, the disassembler ends without creating an output file.

If a warning is issued, a warning message will appear before the end message shows up.

Example:

```
Warning: Input file name extension .HSA conflict
Disassembly 0 error(s) 1 warning(s)
```

In the case of a warning, the disassembler ends after creating an output file.

For details on errors and warnings, refer to Section 7.6 "Error/Warning Messages".

7.5 Disassembling Output

The data/code mnemonics are restored from the target code. As for the branch instructions, a label will be automatically generated such as "CODEx:" where "x" denotes a hexadecimal number string. Other reference symbols will also be generated as "LABELx", "IOx" and "RAMx". The ".org" pseudo-instruction is used to specify the starting location of each code block.

The following shows examples of disassembled sources:

Sample outputs

Absolute list file "test.als"

Linker 63 ver x.xx Absolute list file "TEST.ALS" Mon Jan 15 12:40:41 2001

```

1:                ; sub.s
2:                ; AS63 test program (subroutine)
3:
4:                .global RAM_BLK1
5:
6:                ;***** RAM block 1 initialize *****
7:
8:                .global INIT_RAM_BLK1
9:                INIT_RAM_BLK1:
10: 0000 0800      ldb    %ext,RAM_BLK1@h
11: 0001 0a04      ldb    %x1,RAM_BLK1@l      ;set RAM_BLK1 address to x
12: 0002 1e90      ld     [%x]+,0x0
13: 0003 1e90      ld     [%x]+,0x0
14: 0004 1e90      ld     [%x]+,0x0
15: 0005 1e80      ld     [%x],0x0          ;set 0x0000 to RAM_BLK1
16: 0006 1ff8      ret
17:
18:                ;***** RAM block 1 increment *****
19:
20:                .global INC_RAM_BLK1
21:                INC_RAM_BLK1:
22: 0007 0800      ldb    %ext,RAM_BLK1@h
23: 0008 0a04      ldb    %x1,RAM_BLK1@l      ;set RAM_BLK1 address to x
24: 0009 1911      add    [%x]+,1
25: 000a 1990      adc    [%x]+,0
26: 000b 1990      adc    [%x]+,0
27: 000c 1980      adc    [%x],0          ; increment 16bit value
28: 000d 1ff8      ret
29:                ; main.s
30:                ; AS63 test program (main routine)
31:                ;
32:
33:                ;***** INITIAL SP1 & SP2 ADDRESS DEFINITION *****
34:
35:                #ifdef SMALL_RAM
36:                .set SP1_INIT_ADDR 0xb      ;SP1 init addr = 0x2c
37:                #else
38:                .set SP1_INIT_ADDR 0x4b     ;SP1 init addr = 0x12c
39:                #endif
40:
41:                .set SP2_INIT_ADDR 0x1f     ;SP2 init addr = 0x1f
42:
43:
44:                ;***** NMI & BOOT, LOOP *****
45:
46:                .global INIT_RAM_BLK1      ; subroutine in sub.s
47:                .global INC_RAM_BLK1       ; subroutine in sub.s
48:
49:                .org    0x100
50:                NMI:
51: 0100 08fe (+)  ldb    ext,fe
52: 0101 02fe      calr   INIT_RAM_BLK1      ; initialize RAM block 1
53: 0102 1ff9      reti                    ; in NMI(watchdog timer)
54:

```

```

55:                                .org    0x110
56:                                BOOT:
57:    0110    094b                ldb     %ba,SP1_INIT_ADDR
58:    0111    1fc4                ldb     %sp1,%ba           ; set SP1
59:    0112    091f                ldb     %ba,SP2_INIT_ADDR
60:    0113    1fc6                ldb     %sp2,%ba           ; set SP2
61:    0114    08fe    (+)         ldb     ext,fe
62:    0115    02ea                calr    INIT_RAM_BLK1     ; initialize RAM block 1
63:                                LOOP:
64:    0116    08fe    (+)         ldb     ext,fe
65:    0117    02ef                calr    INC_RAM_BLK1     ; increment RAM block 1
66:    0118    00fd                jr      LOOP              ; infinity loop

```

Output source file "test.ms" (default)

;Disassembler 63 Ver x.xx Assembly source file TEST.MS Mon Jan 15 13:10:20 2001

```

.set LABEL1 0x4
.set LABEL2 0x4
.set LABEL3 0x4b
.set LABEL4 0x1f
.code
.org    0x0
CODE1:
ldb %ext,LABEL1@h
ldb %x1,LABEL1@l
ld [%x]+,0x0
ld [%x]+,0x0
ld [%x]+,0x0
ld [%x],0x0
ret
CODE2:
ldb %ext,LABEL2@h
ldb %x1,LABEL2@l
add [%x]+,0x1
adc [%x]+,0x0
adc [%x]+,0x0
adc [%x],0x0
ret
.code
.org    0x100
ldb %ext,CODE1@rh
calr CODE1@r1
reti
.code
.org    0x110
ldb %ba,LABEL3@l
ldb %sp1,%ba
ldb %ba,LABEL4@l
ldb %sp2,%ba
ldb %ext,CODE1@rh
calr CODE1@r1
CODE3:
ldb %ext,CODE2@rh
calr CODE2@r1
jr CODE3@r1

```

Output source file "test.ms" (when -cl is specified)

;Disassembler 63 Ver x.xx Assembly source file TEST.MS Mon Jan 15 13:10:20 2001

```

.set label1 0x4
.set label2 0x4
.set label3 0x4b
.set label4 0x1f
.code
.org    0x0
code1:
ldb %ext,label1@h
ldb %x1,label1@l
ld [%x]+,0x0
ld [%x]+,0x0
ld [%x]+,0x0
ld [%x],0x0
ret
code2:
ldb %ext,label2@h
ldb %x1,label2@l
add [%x]+,0x1
adc [%x]+,0x0

```

CHAPTER 7: DISASSEMBLER

```
    adc [%x]+,0x0
    adc [%x],0x0
    ret
    .code
    .org    0x100
    ldb %ext,code1@rh
    calr code1@rl
    reti
    .code
    .org    0x110
    ldb %ba,label3@l
    ldb %sp1,%ba
    ldb %ba,label4@l
    ldb %sp2,%ba
    ldb %ext,code1@rh
    calr code1@rl
code3:
    ldb %ext,code2@rh
    calr code2@rl
    jr code3@rl
```

Output source file "test.ms" (when -cu is specified)

```
;Disassembler 63 Ver x.xx Assembly source file TEST.MS Mon Jan 15 13:10:20 2001
```

```
    .SET LABEL1 0X4
    .SET LABEL2 0X4
    .SET LABEL3 0X4B
    .SET LABEL4 0X1F
    .CODE
    .ORG    0X0
CODE1:
    LDB %EXT,LABEL1@H
    LDB %XL,LABEL1@L
    LD [%X]+,0X0
    LD [%X]+,0X0
    LD [%X]+,0X0
    LD [%X],0X0
    RET
CODE2:
    LDB %EXT,LABEL2@H
    LDB %XL,LABEL2@L
    ADD [%X]+,0X1
    ADC [%X]+,0X0
    ADC [%X]+,0X0
    ADC [%X],0X0
    RET
    .CODE
    .ORG    0X100
    LDB %EXT,CODE1@RH
    CALR CODE1@RL
    RETI
    .CODE
    .ORG    0X110
    LDB %BA,LABEL3@L
    LDB %SP1,%BA
    LDB %BA,LABEL4@L
    LDB %SP2,%BA
    LDB %EXT,CODE1@RH
    CALR CODE1@RL
CODE3:
    LDB %EXT,CODE2@RH
    CALR CODE2@RL
    JR CODE3@RL
```

7.6 Error/Warning Messages

7.6.1 Errors

When an error occurs, the disassembler immediately terminates the processing after displaying an error message. It will not output a source file.

The disassembler error messages are given below.

Error message	Description
Cannot create <file kind> file <FILE NAME>	The file cannot be created.
Cannot open <file kind> file <FILE NAME>	The file cannot be opened.
Cannot read <file kind> file <FILE NAME>	The file cannot be read.
Cannot write <file kind> file <FILE NAME>	Data cannot be written to the file.
Illegal file name <FILE NAME> specified with option <option>	The specified output source file name is incorrect.
Illegal file name <FILE NAME>	The specified input file name is incorrect.
Illegal HEX data format	The input file is not a Motorola-S format file.
Illegal option <option>	An illegal option is specified.
Out of memory	Cannot secure memory space.

7.6.2 Warning

Even if a warning is issued, the disassembler keeps on processing, and completes the processing after displaying a warning message, unless, in addition, an error is produced.

Warning message	Description
Input file name extension .XXX conflict	Two or more file names with the same extension have been specified. The last one is used.
Cannot open Hex file xxx.csa	The file cannot be opened. It is assumed there is no data memory.

7.7 Precautions

For the restrictions, support functions and bug information of the latest version, refer to rel_asm_E.txt of S5U1C63000A.

CHAPTER 8 *DEBUGGER*

This chapter describes how to use the Debugger db63.

8.1 Features

The Debugger db63 is used to debug a program after reading an object file in the IEEE-695 format that is generated by the linker.

It has the following features and functions:

- Various data can be referenced at the same time using multiple windows.
- Frequently used commands can be executed from tool bars and menus using a mouse.
- Also available are source display and symbolic debug functions which correspond to assembly source codes.
- Consecutive program execution and two types of single-stepping are possible.
- Five break functions are supported.
- A real-time display function shows register and memory contents on-the-fly.
- A time display function showing execution time by both duration and steps.
- An advanced trace function.
- An automatic command execution function using a command file.

8.2 Input/Output Files




Fig. 8.2.1 Flow chart

8.2.1 Input Files

Parameter file

File format: Binary file

File name: <file name>.par

Description: This file contains memory information on each microcomputer model and is indispensable for starting the debugger. This file is provided for each microcomputer model.

The following files are read by the debugger according to command specification.

Object file

File format: Binary file in the IEEE-695 format

File name: <file name>.abs (An extension other than ".abs" can also be used.)

Description: This is an object file generated by the linker. This file is read into the debugger by the *If* command. By reading a file in the IEEE-695 format that contains debug information, source display and symbolic debugging can be performed.

Source file

File format: Text file

File name: <file name>.s

Description: This is the source file of the above object file. It is read when the debugger performs source display.

Program file

File format: HEX file in Motorola-S format

File name: <file name>.hsa, <file name>.lsa

Description: This is a load image file of the program ROM, and is read into the debugger by the *lo* command. The file ".hsa" corresponds to the 5 high-order bits of the program code and the file ".lsa" corresponds to the 8 low-order bits of the program code. These files are generated for the purpose of creating mask data from an object file in the IEEE-695 format by the Hex converter. Unlike files in the IEEE-695 format, these files cannot be used for source display or symbolic debugging, but can be used to check the operation of final program data.

Data file for data ROM

File format: HEX file in Motorola-S format

File name: <file name>.csa

Description: This is a load image file of the data ROM, and is read into the debugger by the *lo* command. This file is generated for the purpose of creating mask data from an object file in the IEEE-695 format by the Hex converter. When an absolute object file in the IEEE-695 format is loaded, it is not necessary to load this file.

Option data file

File format: HEX file in Motorola-S format

File name: <file name>.fsa, <file name>.ssa, <file name>.msa (Varies with the type of microcomputer)

Description: These data files are used to set up hardware options for each microcomputer model and is read by the *lo* command. These files are generated by a development tool available for each microcomputer model.

Command file

File format: Text file

File name: <file name>.cmd (An extension other than ".cmd" can also be used.)

Description: This file contains a description of debug commands to be executed successively. By writing a series of frequently used commands in this file, the time and labor required for entering commands from the keyboard can be saved. The command described in the file are read and executed using the *com* or *cmw* command.

8.2.2 Output Files**Log file**

File format: Text file

File name: <file name>.log (An extension other than ".log" can also be used.)

Description: This file contains the information of executed commands and execution results that are output to a file. Output of this file can be controlled by the *log* command.

Record file

File format: Text file

File name: <file name>.cmd (An extension other than ".cmd" can also be used.)

Description: This file contains the information of executed commands that are output to a file. Output of this file can be controlled by the *rec* command.

Trace file

File format: Text file

File name: <file name>.trc (An extension other than ".trc" can also be used.)

Description: This file contains the specified range of trace information. Output of this file can be controlled by the *tf* command.

8.3 Starting Method

8.3.1 Start-up Format

General form of command line

db63 ^ <parameter file name> ^ [start-up option]

^ denotes a space.

[] indicates the possibility to omit.

Note: The parameter file will be recognized by its extension ".par", so ".par" must be included in the parameter file name to be specified.

8.3.2 Start-up Options

The debugger has four start up options available.

<command file name>

Function: Specifies a command file.

Explanation: For a series of commands to be executed immediately after the debugger starts up, specify a command file that describes those commands.

The following two options are effective only when the RS-232C ICE is used.

-comX

Function: Specifies a communication port. (for RS-232C ICE)

Explanation: This option specifies the communication port through which a personal computer is communicated with by the ICE. Specify a port number in the X part of this option. The port that can be used for this purpose varies among different personal computers. Unless this option is specified, the COM1 port is used to communicate with the ICE.

-b <baud rate>

Function: Specifies a communication transmission rate. (for RS-232C ICE)

Explanation: This option specifies the baud rate on the personal computer. For <baud rate>, select one from 2400, 4800, 9600, 19200, or 38400. Unless specified otherwise, the baud rate is set to 9600 bps. This value is the same as the initial setting of the ICE. The baud rate on the ICE is set using the DIP switch mounted on the ICE.

The following option is effective when the USB ICE is used.

-usb

Function: Specifies USB for connection (for USB ICE)

Explanation: This option must be specified when the USB ICE is connected.

When entering an option in a command line, make sure that there is at least one space before and after the option.

Example: c:\epson\s1c63\bin\db63 par63xxx.par startup.cmd -com2 -b 19200

The default start-up options are set as: -com1 & -b 9600.

If no parameter file name was specified or the option was not specified correctly, the debugger ends after delivering the following message concerning the usage:

```
- Usage -
  db63.exe <parameter_file> <startup options>
Options:
  command_file:  ... specifies a command file
  -comX(X:1-4)  ... com port, default com1
  -b            ... baud rate, 2400,9600(default),19200,38400
  -usb         ... specifies usb communication
  -sim         ... specifies simulator mode
```

8.3.3 Start-up Messages

When the debugger starts up, it outputs the following message in the [Command] window. (Refer to the next section for details about windows.)

```
Debugger63 Ver x.xx Copyright SEIKO EPSON CORP. 1998-2007

Connecting COMx with xxxxx baud rate ... done (*1)
Parameter file name      : xxxxxxxx.par
                        Version   : xx
                        Chip name  : 63xxx
CPU version              : x.x
PRC board version       : x.x
LCD board version       : x.x
EXT board version       : x.x
ICE hardware version    : x.x
ICE software version    : x.x
DIAG test                : omitted
Map..... done
Initialize..... done
>
```

*1 The message is a display example when the RS-232C ICE is used. The message below will be displayed when the USB ICE is used.

```
Connecting USB ... done
```

Note that the following description uses the sample message for RS-232C ICE and "Connecting USB" will be displayed when the USB ICE is used.

8.3.4 Hardware Check at Start-up

When the debugger is invoked, it first performs the tests and initializing operations described below.

(1) Testing connection of the ICE

Debugger db63 first checks to see that the ICE is connected to your system and that communication is possible without any problems. The following message is displayed in the [Command] window.

During test

```
Connecting COMx with xxxxx baud rate ...
```

When terminated normally

```
Connecting COMx with xxxxx baud rate ... done
```

When an error is encountered

```
Connecting COMx with xxxxx baud rate ... failure
<error message>
```

The error message indicates that communication between the personal computer and the ICE is not functioning properly. In this case, to verify the following:

- A standard interface cable is used
- The COM port is correct
- The baud rates on both sides are matched
- The PRC board is correctly fitted in place
- The ICE's power is turned on
- The ICE remains reset

For the causes of errors, refer to Section 8.10, "Status/Error/Warning Messages".

If this test indicates that the ICE is not in ready state, the debugger performs the following:

When the ICE is executing the target program:

In this case, the debugger sends a forcible break command to the ICE; it then retests the connection of the ICE several seconds later.

When the ICE is in the BUSY state:

In this case, the debugger will try to retest the connection with the ICE several seconds later.

When the ICE is in a free-run state:

In this case, the debugger displays the following message:

```
Connecting COMx with xxxxx baud rate ... failure  
Error : ICE is free run mode
```

Temporarily quit the debugger and set the ICE to the ICE mode (by turning the ICE/RUN switch to the ICE position), then restart up the debugger.

When the ICE is performing self-diagnosis:

In this case, the debugger waits until the ICE's self-diagnosis is completed before it starts testing the connection of the ICE. Note that the ICE's self-diagnosis is executed simultaneously if it is activated when its DIP switch SW8 is in the up position. If the SW8 switch is in the down position, self-diagnosis is not executed. Self-diagnosis from start to finish requires about 5 minutes. Wait until it is completed.

You will then see the following message:

```
Connecting COMx with xxxxx baud rate ...  
DIAG test, please wait 5 min. .. done
```

If an error is found in self-diagnosis, an error message will be displayed on the screen instead of "done" above.

(2) Version check

When the connection test terminates normally, the debugger checks the contents of the parameter file, the version of the ICE, and the versions of the peripheral boards inserted in the ICE.

```
Parameter file name      : xxxxxxxx.par  
                        Version   : xx  
                        Chip name  : 63xxx  
CPU version              : x.x  
PRC board version       : x.x  
LCD board version       : x.x  
EXT board version       : x.x  
ICE hardware version    : x.x  
ICE software version    : x.x  
DIAG test                : omitted
```

Here, the debugger checks to see if the ICE's system configuration (including extension boards such as a PRC board (Peripheral Circuit Board) and an LCD board) and their versions are matched to the setup contents of the parameter file.

If the ICE does not have a necessary board, or contains an unnecessary board or a board of different version, a warning message appears on the screen.

(3) ICE initialization

When the above tests are finished, the debugger initializes the ICE as follows:

- Mapping (memory configuration is set according to the parameter file)
- Initializing mapped memory (RAM: 0xa; code ROM: 0x1fff; data ROM: 0xf)
- Initializing option data (cleared to 0)
- Initializing break conditions (all break conditions are cleared)
- Initializing trace conditions (normal trace is set and the trace trigger point is set to 0)
- Setting execution cycles counter to 0.
- Initial setting of watch data addresses (addresses 0, 4, 8, and C)
- Initializing CPU registers

When initialization is terminated normally:

```
Map..... done
Initialize..... done
>
```

When an error is encountered:

```
Map..... done
Initialize..... Error
```

```
    Please quit db63 and restart!
```

```
>
```

If an error occurs in the above initialization process, temporarily quit the debugger. Check the cause of the error and repair it before restarting the debugger.

After initialization, the state of the screen including the position and size of the windows will return the same as the last time the debugger was terminated. The contents displayed in each window if it is opened are as follows:

Window	Display contents
[Command] window	Initialization information (and waits for command input)
[Data] window	Data memory contents starting from data memory address 0
[Register] window	Current register values
[Source] window	Program memory contents starting from program memory address 0x0100 The previously set display mode (Unassemble, Source or Mix) is used.
[Trace] window	Blank

8.3.5 Method of Termination

To terminate the debugger, select [Exit] from the [File] menu.

You can also input the *q* command in the [Command] window to terminate the debugger.


```
>q
```

8.4 Windows

This section describes the types of windows used by the debugger.

8.4.1 Basic Structure of Window

The diagram below shows the window structure of the debugger.



Depending on the computer used, the windows may differ from the above display depending on the screen resolution, the number of dots in system font, etc. Adjust the size of each window to suit needs.

Features common to all windows

(1) Open/close and activating a window

All windows except [Command] can be closed or opened.

To open a window, select the window name from the [View] menu. To close a window, click the [Close] box on the window. After initialization, the state of the screen including the position and size of the windows will return to the same as the last time the debugger was terminated.

The opened windows are listed in the [Window] menu. Selecting one from the list activates the selected window. It can also be done by simply clicking on an inactive window. Furthermore, pressing [Ctrl]+[Tab] switches the active window to the next open window.

(2) Resizing and moving a window

Each window can be resized as needed by dragging the boundary of the window with the mouse. The [Minimize] and [Maximize] buttons work in the same way as in general Windows applications. Each window can be moved to the desired display position by dragging the window's title bar with the mouse. However, windows can only be resized and moved within the range of the application window.

(3) Scrolling a window

All windows can be scrolled. (The [Register] window can be scrolled only when its size is reduced.)

Use one of the following three methods to scroll a window:

1. Click on an arrow button or enter an arrow key (cursor movement) to scroll a window one line at a time.
2. Click on the scroll bar of a window to scroll it one page (current window size) at a time.
3. Drag the scroll bar handle of a window to move it to the desired area.

(4) Other


The opened windows can be cascaded or tiled using the [Window] menu.

Note for display

The windows may display incorrect contents caused by incompatibility between the OS and the video card or driver. If there is any problem try the following methods to fix it.

- Update the driver to the latest version if an older version has been installed.
Please inquire about the version to the distributor.
- If the driver allows selection of extended function such as acceleration, turn the functions off.
- If the problem is not fixed using the above, try the standard driver supplied with Windows.

8.4.2 [Command] Window



The [Command] window is used to do the following:

(1) Entering debug commands

When the prompt ">" appears in the [Command] window, the system will accept a command entered from the keyboard.

If some other window is selected, click on the [Command] window. A cursor will blink at the prompt, indicating that readiness to input a command. (Refer to Section 8.7.1, "Entering Commands from Keyboard".)

(2) Displaying debug commands selected from menus or tool bar

When a command is executed by selecting the menu item or tool bar button, the executed command line is displayed in the [Command] window.


(3) Displaying command execution results

The [Command] window displays command execution results. However, some command execution results are displayed in the [Source], [Data], [Register], or [Trace] windows. The contents of these execution results are displayed when their corresponding windows are open. If the corresponding window is closed, the execution result is displayed in the [Command] window.

When writing to a log file, the content of the write data is displayed in the window. (Refer to the description for *log* command.)

Note: The [Command] window cannot be closed.

8.4.3 [Source] Window



The [Source] window displays the contents of (1) to (4) listed below. This window also allows breakpoints to be set and words or labels to be found.

(1) Unassembled codes and source codes

You can choose one of the following three display modes:

1. Mix mode



[Mix] button

(selected by the [Mix] button or entering the *m* command)

In this mode, the window displays the addresses, codes, unassembled contents, and corresponding source line numbers and source statements. (See the diagram above.)

2. Source mode



[Source] button

(selected by the [Source] button or entering the *sc* command)

In this mode, the window displays the source line numbers and source statements.

3. Unassemble mode



[Unassemble] button

(selected by the [Unassemble] button or entering the *u* command)

In this mode, the window displays the addresses, codes, and unassembled contents. This format is selected when the debugger starts up.

*Note: The **m**, **sc** and **u** commands can update the [Source] window if the window is already opened. If the [Source] window is closed, the program code is displayed in the [Command] window. The [Mix], [Source] and [Unassemble] buttons open the [Source] window if the window is closed.*

All program code in the 64K address space can be referenced by scrolling the window. When a break occurs, the display content is updated so that the address line to be executed next is displayed, with an arrow mark at the beginning of the line for identification.

Use the scroll bar or arrow keys to scroll the window. Or enter a command to display the program code beginning with a specified position.

* Display of source line numbers and source statements

The source line numbers and source statements can only be displayed when the IEEE-695 absolute object file including debugging information for the source display is loaded. Furthermore, the source statements that are actually displayed from this file are those which have had the *-g* option specified by the assembler.

** Updating of display*

When a program is loaded and executed (*g*, *gr*, *s*, *n*, or *rst* command), or the memory contents are changed (*a* (*as*), *pe*, *pf*, or *pm* command), the display contents are updated. In this case the [Source] window updates its display contents so that the current PC address can always be displayed. The display contents are also updated when the display mode is changed.

(2) Current PC

The current PC (program counter) address line is indicated by an arrow mark at the beginning of the line. (Address 0x0110 in the diagram)

(3) PC breakpoint

The address line where a breakpoint is set is indicated by a red ● mark at the beginning of the line. (Address 0x0117 in the diagram)

(4) Trace trigger point

The address line where a trace trigger point is set is indicated by the letter "T" at the beginning of the line. (Address 0x0115 in the diagram)

(5) Break setting at the cursor position

Place the cursor at an address line where a breakpoint is to be set (not available for a source-only line).



[Break] button

Then click on the [Break] button. A PC breakpoint will be set at that address. If the same is done at the address line where a PC breakpoint has been set, the breakpoint will be cleared.




[Go to Cursor] button

If the [Go to Cursor] button is clicked, the program will execute beginning with the current PC position, and program execution breaks at the line where the cursor is located.

(6) Finding labels and words

Any labels and words can be found using the [Search Label] pull-down list box or the [Find] button on the [Source] window.




[Search Label] pull-down list box



[Find] button

8.4.4 [Data] Window



(1) Displaying data memory contents

The [Data] window displays the memory dump results in hexadecimal numbers.

The display area is the entire 64K-word data memory space (RAM, data ROM, I/O). The contents of all addresses from 0x0000 to 0xffff can be displayed by scrolling the window. The contents of unmapped addresses in each microcomputer model are indicated by an "*".


* Updating of display

The display contents of the [Data] window are updated automatically when memory contents are modified with a command (*de*, *df*, or *dm* command), or by direct modification. After executing the program (*g*, *gr*, *s*, *n*, or *rst* command), the display contents are also updated. To refresh the [Data] window manually, execute the *dd* command or click the vertical scroll bar. When a program execution is suspended, the values that have been modified from those before execution are displayed in red.

(2) Direct modification of data memory contents

The [Data] window allows direct modification of data memory contents. To modify data on the [Data] window, place the cursor at the front of the data to be modified or double click the data, and then type a hexadecimal character (0–9, a–f). Data in the address will be modified with the entered number and the cursor will move to the next address. This allows successive modification of a series of addresses.

8.4.5 [Register] Window



(1) Displaying register contents

The [Register] window displays the contents of the PC, A register, B register, X register and its memory, Y register and its memory and flags (E, I, C, Z), stack pointers (SP1, SP2), EXT register, and QUEUE register.

(2) Execution cycle counter

This counter calculates and indicates the number of executed cycles or execution time since the CPU was reset.

(3) Monitor data

The debugger allows you to specify four addresses in RAM and monitor the memory contents at these addresses. The [Register] window displays the contents of these four watch data addresses (4 words each beginning from the specified address). When the debugger starts up, addresses 0, 4, 8, and C are initially set as the watch data addresses. The contents are arranged sequentially from left to right in order of their addresses as they are displayed on the screen.


* Updating the display

The display is updated when registers are dumped (*rd* command), when watch data addresses are set (*dw* command), when register data is modified (*rs* command), when the CPU is reset (*rst* command), or after program execution (*g*, *gr*, *s*, or *n* command) is completed. When the on-the-fly function is enabled, the PC, flag and watch data are updated in real time at 0.5 second intervals while the program is being executed. Other contents are left blank until the program is stopped by a break. When a program execution is suspended, the values that have been modified from those before execution are displayed in red.

(4) Direct modification of register contents

The [Register] window allows direct modification of register contents. To modify data on the [Register] window, select (highlight) the data to be modified and type a hexadecimal number (0–9, a–f), then press [Enter]. The register data will be modified with the entered number.

8.4.6 [Trace] Window



The [Trace] window displays the trace result up to 8,192 cycles by reading it from the ICE trace memory. The following lists the trace contents:

- Traced cycle number
- Fetched address
- Fetched code and disassembled contents
- Register contents (A, B, X, Y, and flags)
- Memory access status (address, R/W, data, and SP1/SP2)
- TRCIN pin input status

This window also displays the trace data search results by the *ts* command.

*** Updating of display:**

The contents of the [Trace] window are cleared when the target program is being executed. During this period, the [Trace] window does not accept scrolling and resizing operations.

After an program execution is terminated, this window displays the latest data traced during the execution. To specify a display start cycle, execute the *td* command.

8.5 Tool Bar

This section outlines the tool bar available with the debugger.

8.5.1 Tool Bar Structure

The tool bar has 14 buttons, each one assigned to a frequently used command.



The specified function is executed when you click on the corresponding button.

8.5.2 [Key Break] Button



This button forcibly breaks execution of the target program. This function can be used to cause the program to break when the program has fallen into an endless loop.

8.5.3 [Load File] and [Load Option] Buttons



[Load File] button

This button reads an object file in the IEEE-695 format into the debugger. It performs the same function when the *lf* command is executed.



[Load Option] button

This button reads a program file, data file for the data ROM or an optional HEX file in Motorola-S format into the debugger. It performs the same function when the *lo* command is executed.

8.5.4 [Source], [Mix], and [Unassemble] Buttons

These buttons open the [Source] window or switch over the display modes.



[Source] button

This button switches the display of the [Source] window to the source mode. The [Source] window opens if it is closed. This button performs the same function when the *sc* command is executed.



[Unassemble] button

This button switches the display of the [Source] window to the unassemble mode. The [Source] window opens if it is closed. This button performs the same function when the *u* command is executed.



[Mix] button

This button switches the display of the [Source] window to the mix mode (unassemble & source). The [Source] window opens if it is closed. This button performs the same function when the *m* command is executed.

8.5.5 [Go], [Go to Cursor], [Go from Reset], [Step], [Next], and [Reset] Buttons



[Go] button

This button executes the target program from the address indicated by the current PC. It performs the same function when the *g* command is executed.



[Go to Cursor] button

This button executes the target program from the address indicated by the current PC to the cursor position in the [Source] window (the address of that line). It performs the same function when the *g <address>* command is executed.

Before this button can be selected, the [Source] window must be open and the address line where the program is to break must be clicked. Selecting a break address by clicking on the address line is valid for only the lines that have actual code, and is invalid for the source-only lines.



[Go from Reset] button

This button resets the CPU and then executes the target program from the program start address (0x110). It performs the same function when the *gr* command is executed.



[Step] button

This button executes one instruction step at the address indicated by the current PC. It performs the same function when the *s* command is executed.



[Next] button

This button executes one instruction step at the address indicated by the current PC. If the instruction to be executed is *calr*, *calz* or *int*, it is assumed that a program section until control returns to the next address constitutes one step and all steps of their subroutines are executed. This button performs the same function when the *n* command is executed.



[Reset] button

This button resets the CPU. It performs the same function when the *rst* command is executed.

8.5.6 [Break] Button



Use this button to set and clear a breakpoint at the address where the cursor is located in the [Source] window. This function is valid only when the [Source] window is open. Note that selecting a break address by clicking on the address line is valid for only the lines that have actual code and is invalid for the source-only lines.

8.6 Menu


This section outlines the menu bar available with the debugger.

8.6.1 Menu Structure

The menu bar has eight menus, each including frequently-used commands.

File Run Break Trace View Option Window Help

8.6.2 [File] Menu



[Load File...]

This menu item reads an object file in the IEEE-695 format into the debugger. It performs the same function when the *lf* command is executed.

[Load Option...]

This menu item reads a program file, data file for the data ROM or an optional HEX file in Motorola-S format into the debugger. It performs the same function when the *lo* command is executed.

[Flash Memory Operation...]

This menu item reads/writes data from/to the Flash memory or erases the Flash memory contents. It performs the same function when the *lfl*, *sfl* or *efl* command is executed.


Note: The flash memory operation commands cannot be used when the USB ICE is used. This menu command is disabled as the screen shot on the left.



[Exit]

This menu item quits the debugger. It performs the same function when the *q* command is executed.

8.6.3 [Run] Menu



[Go]

This menu item executes the target program from the address indicated by the current PC. It performs the same function when the *g* command is executed.

[Go to Cursor]

This menu item executes the target program from the address indicated by the current PC to the cursor position in the [Source] window (the address of that line). It performs the same function when the *g <address>* command is executed.


Before this menu item can be selected, the [Source] window must be open and the address line where the program is to break must be clicked. Selecting a break address by clicking on the address line is valid for only the lines that have actual code, and is invalid for the source-only lines.

[Go from Reset]

This menu item resets the CPU and then executes the target program from the program start address (0x0110). It performs the same function when the *gr* command is executed.

[Step]

This menu item executes one instruction step at the address indicated by the current PC. It performs the same function when the *s* command is executed.



[Next]

This menu item executes one instruction step at the address indicated by the current PC. If the instruction to be executed is *calr*, *calz* or *int*, it is assumed that a program section until control returns to the next address constitutes one step and all steps of their subroutines are executed. This menu item performs the same function when the *n* command is executed.

[Command File...]

This menu item reads a command file and executes the debug commands written in that file. It performs the same function when the *com* or *cmw* command is executed.

[Reset CPU]

This menu item resets the CPU. It performs the same function when the *rst* command is executed.

8.6.4 [Break] Menu



[Breakpoint Set...]

This menu item displays, sets or clears PC breakpoints using a dialog box. It performs the same function as executing the *bp* command.

[Data Break...]

This menu item displays, sets or clears data break conditions using a dialog box. It performs the same function as executing the *bd* command.

[Register Break...]

This menu item displays, sets or clears register break conditions using a dialog box. It performs the same function as executing the *br* command.

[Sequential Break...]

This menu item displays, sets or clears sequential break conditions using a dialog box. It performs the same function as executing the *bs* command.

[Stack Break...]

This menu item displays or sets stack break conditions using a dialog box. It performs the same function as executing the *bsp* command.


[Break List]

This menu item displays the all break conditions that have been set. It performs the same function as executing the *bl* command.

[Break All Clear]

This menu item clears all break conditions. It performs the same function as executing the *bac* command.

8.6.5 [Trace] Menu



[Trace Mode Set...]

This menu item sets a trace mode and trace conditions using a dialog box. It performs the same function as executing the *tm* command.


[Trace Search...]

This menu item searches trace information from the trace memory under the condition specified using a dialog box. It performs the same function as executing the *ts* command.

[Trace File...]

This menu item saves the specified range of the trace information displayed in the [Trace] window to a file. It performs the same function as executing the *tf* command.

8.6.6 [View] Menu



[Command]

This menu item activates the [Command] window.

[Program]



This menu item opens or activates the [Source] window and displays the program from the current PC address in the display mode selected from the sub menu items. These sub menu items perform the same functions as executing the *u*, *sc*, and *m* command, respectively.

[Data Dump]

This menu item opens or activates the [Data] window and displays the data memory contents from the memory start address.

[Register]

This menu item opens or activates the [Register] window and displays the current values of the registers.

[Trace]

This menu item opens or activates the [Trace] window and displays the trace data sampled in the ICE trace memory.

[Toolbar]

This menu item shows or hides the toolbar.

[Status Bar]

This menu item shows or hides the status bar.

8.6.7 [Option] Menu



[Log...]

This menu item starts or stops logging using a dialog box. It performs the same function as executing the *log* command.


[Record...]

This menu item starts or stops recording of a command execution using a dialog box. It performs the same function as executing the *rec* command.

[Mode Setting...]

This menu item sets the on-the-fly display, break and execution counter modes using a dialog box. It performs the same functions as executing the *md* command.

8.6.8 [Windows] Menu



[Cascade]

This menu item cascades the opened windows.

[Tile]

This menu item tiles the opened windows.

This menu shows the currently opened window names. Selecting one activates the window.

8.6.9 [Help] Menu



[About Db63...]

This menu item displays an About dialog box for the debugger.

8.7 Method for Executing Commands

All debug functions can be performed by executing debug commands. This section describes how to execute these commands. Refer to the description of each command for command parameters and other details.

To execute a debug command, activate the [Command] window and input the command from the keyboard. The menu and tool bar can be used to execute frequently-used commands.

8.7.1 Entering Commands from Keyboard

Select the [Command] window (by clicking somewhere on the [Command] window). When the prompt ">" appears on the last line in this window and a cursor is blinking behind it, the system is ready to accept a command from the keyboard.

Input a debug command at the prompt position. The commands are not case-sensitive; they can be input in either uppercase or lowercase.

General command input format

```
>command [ parameter [ parameter ... parameter ] ] ↵
```

- A space is required between a command and parameter.
- A space is required between parameters.

Use the arrow keys, [Back Space] key, or [Delete] key to correct erroneous input.

When you press the [Enter] key after entering a command, the system executes that command. (If the command entered is accompanied by guidance, the command is executed when the necessary data is input according to the displayed guidance.)

Input example:

```
>g↵           (Only a command is input.)
>com test.cmd↵ (A command and parameter are input.)
```

Command input accompanied by guidance

For commands that cannot be executed unless a parameter or the commands that modify the existing data are specified, a guidance mode is entered when only a command is input. In this mode, the system brings up a guidance field, so input a parameter there.

Input example:

```
>lf↵
File name   ? test.abs↵ ... Input data according to the guidance (underlined part).
>
```

- **Commands requiring parameter input as a precondition**

The *If* command shown in the above example reads an absolute object file into the debugger. Commands like this that require an entered parameter as a precondition are not executed until the parameter is input and the [Enter] key pressed. If a command has multiple parameters to be input, the system brings up the next guidance, so be sure to input all necessary parameters sequentially. If the [Enter] key is pressed without entering a parameter in some guidance session of a command, the system assumes the command is canceled and does not execute it.

• Commands that replace existing data after confirmation

The commands that rewrite memory or register contents one by one provide the option of skipping guidance (do not modify the contents), returning to the immediately preceding guidance, or terminating during the input session.

[Enter] key Skips input.

[^] key Returns to the immediately preceding guidance.

[q] key Terminates the input session.

Input example:

```
>de↓ ... Command to modify data memory.
Data enter address ? :0↓ ... Inputs the start address.
0000 A:1↓ ... Modifies address 0x0000 to 1.
0001 A:^↓ ... Returns to the immediately preceding address.
0000 1:0↓ ... Inputs address 0x0000 back again.
0001 A:↓ ... Skips address 0x0001 by pressing [Enter] alone.
0002 A:↓
0001 A:q↓ ... Terminates the input session.
>
```

Numeric data format of parameter

For numeric values to be accepted as a parameter, they must be input in hexadecimal numbers for almost all commands. However, some parameters accept decimal or binary numbers.

The following characters are valid for specifying numeric data:

Hexadecimal: 0-9, a-f, A-F, *

Decimal: 0-9

Binary: 0, 1, *

("*" is used to mask bits when specifying a data pattern.)

Specification with a symbol

For address specifications, symbols defined in the source can also be used. However, it is necessary to load an absolute object file that contains debug information.

Symbols should be used as follows:

```
Global symbol @<symbol name> e.g. @RAM_BLK1
Local symbol @<symbol name>@<source file name> e.g. @LOOP@main.s
```

Successive execution using the [Enter] key

The commands listed below can be executed successively by using only the [Enter] key after executing once. Successive execution here means repeating the previous operation or continuous display of the previous contents.

Execution commands: *g* (go), *s* (step), *n* (next), *com* (execute command file)

Display commands: *sc* (source), *m* (mix), *u* (unassemble), *dd* (data memory dump),
od (option data dump), *td* (trace data display), *cv* (coverage), *sy* (symbol list),
ma (map information)

The successive execution function is terminated when some other command is executed.

8.7.2 Executing from Menu or Tool Bar

The menu and tool bar are assigned frequently-used commands as described in Sections 8.5 and 8.6. A command can be executed simply by selecting desired menu command or clicking on the tool bar button. Table 8.7.2.1 lists the commands assigned to the menu and tool bar.

Table 8.7.2.1 Commands that can be specified from menu or tool bar

Command	Function	Menu	Button
lf	Load IEEE-695 absolute object file	[File Load File...]	
lo	Load Motorola-S file	[File Load Option...]	
g	Execute program successively	[Run Go]	
g <address>	Execute program to <address> successively	[Run Go to Cursor]	
gr	Reset CPU and execute program successively	[Run Go from Reset]	
s	Step into	[Run Step]	
n	Step over	[Run Next]	
com, cmw	Load and execute command file	[Run Command File...]	-
rst	Reset CPU	[Run Reset CPU]	
bp, bc (bpc)	Set/clear PC breakpoint	[Break Breakpoint Set...]	
bd, bdc	Set/clear data break	[Break Data Break...]	-
br, brc	Set/clear register break	[Break Register Break...]	-
bs, bsc	Set/clear sequential break	[Break Sequential Break...]	-
bsp	Set stack break	[Break Stack Break...]	-
bl	Break list	[Break Break List...]	-
bac	Clear all break conditions	[Break Break All Clear]	-
tm	Set trace mode	[Trace Trace Mode Set...]	-
ts	Search trace information	[Trace Trace Search...]	-
tf	Save trace information to a file	[Trace Trace File...]	-
u	Unassemble display	[View Program Unassemble]	
sc	Source display	[View Program Source Display]	
m	Mix display	[View Program Mix Mode]	
lfl *	Load from flash memory	[File Flash Memory Operation...]	-
sfl *	Save to flash memory	[File Flash Memory Operation...]	-
efl *	Erase flash memory	[File Flash Memory Operation...]	-
dd	Dump data memory	[View Data Dump]	-
rd	Display register values	[View Register]	-
td	Display trace information	[View Trace]	-
log	Turn log output on or off	[Option Log...]	-
rec	Record commands to a command file	[Option Record...]	-
md	Set modes	[Option Mode Setting...]	-

* The flash memory operation commands (*lfl*, *sfl*, *efl*) cannot be used when the USB ICE is used.

8.7.3 Executing from a Command File

Another method for executing commands is to use a command file that contains descriptions of a series of debug commands. By reading a command file into the debugger the commands written in it can be executed.

Creating a command file

Create a command file as a text file using an editor.

Although there are no specific restrictions on the extension of a file name, Seiko Epson recommends using ".cmd".

Command files can also be created using the *rec* command. The *rec* command creates a command file and saves the executed commands to the file.

Example of a command file

The example below shows a command group necessary to read an object file and an option file.

Example: File name = startup.cmd

```
lf test.abs
lo test.fsa
lo test.ssa
```

A command file to write the commands that come with a guidance mode can be executed. In this case, be sure to break the line for each guidance input item as a command is written.

Reading in and executing a command file

There are two methods to read a command file into the debugger and to execute it, as described below.

(1) Execution by the start-up option

By specifying a command file in the debugger start-up command, one command file can be executed when the debugger starts up.

If the above example of a command file is specified, for example, the necessary files are read into the debugger immediately after the debugger starts up, so everything is ready to debug the program.

Example: Startup command of the debugger

```
db63 startup.cmd par63xxx.par
```

(2) Execution by a command

The debugger has the *com* and *cmw* commands available that can be used to execute a command file. The *com* command reads in a specified file and executes the commands in that file sequentially in the order they are written.

The *cmw* command performs the same function as the *com* command except that each command is executed at intervals specified by the *md* command (1 to 256 seconds).

Examples: `com startup.cmd`

```
cmw test.cmd
```

The commands written in the command file are displayed in the [Command] window.

Restrictions

Another command file can be read from within a command file. However, nesting of these command files is limited to a maximum of five levels. An error is assumed and the subsequent execution is halted when the *com* or *cmw* command at the sixth level is encountered.

8.7.4 Log File

The executed commands and the execution results can be saved to a file in text format that is called a "log file". This file allows verification of the debug procedures and contents. The contents displayed in the [Command] window are saved to this file.

Command example

```
>log tst.log
```

After the debugger is set to the log mode by the *log* command (after it starts outputting to a log file), the *log* command toggles (output turned on in log mode ↔ output turned off in normal mode). Therefore, you can output only the portions needed can be output to the log file.

Display of [Command] window in log mode

The contents displayed in the [Command] window during log mode differ from those appearing in normal mode.

(1) When executing a command when each window is open

(When the window that displays the command execution result is opened)

Normal mode: The contents of the relevant display window are updated. The execution results are not displayed in the [Command] window.

Log mode: The same contents as those displayed in the relevant window are also displayed in the [Command] window. However, changes made to the relevant window by scrolling or opening it are not reflected in the [Command] window.

(2) When executing a command while each window is closed

When the relevant display window is closed, the execution results are always displayed in the [Command] window regardless of whether operation is in log mode or normal mode.

For the display format in the [Command] window, refer to each command description.

8.8 Debug Functions

This section outlines the debug features of the debugger, classified by function. Refer to Section 8.9, "Command Reference" for details about each debug command.

8.8.1 Loading Program and Data Files

Loading files

The debugger can read a file in IEEE-695 format or Motorola-S format in the debugging process.

Table 8.8.1.1 lists the files that can be read by the debugger and the load commands.

Table 8.8.1.1 Files and load commands

File type	Data type	Ext.	Generation tool	Com.	Menu	Button
IEEE-695	Program/data	.abs	Linker	If	[File Load File...]	
Motorola-S	Program (5 high-order bits)	.hsa	HEX converter	Io	[File Load Option...]	
	Program (8 low-order bits)	.lsa	HEX converter			
	Function option	.fsa	Function option generator			
	Segment option	.ssa	Segment option generator			
	Melody data	.msa	Melody assembler			

(Ext. = Extension, Com. = Command)

Debugging a program with source display

To debug a program using the source display and symbols, the object file must be in IEEE-695 format read into the debugger. If any other program file is read, only the unassembled display is produced.

8.8.2 Source Display and Symbolic Debugging Function

The debugger allows program debugging while displaying the assembly source statements. Address specification using a symbol name is also possible.


Displaying program code

The [Source] window displays the program in the specified display mode. The display mode can be selected from among the three modes: Unassemble mode, Source mode, Mix mode.

Table 8.8.2.1 Commands/tool bar buttons to switch display mode


Display mode	Command	Menu	Button
Unassemble	u	[View Program Unassemble]	
Source	sc	[View Program Source Display]	
Mix	m	[View Program Mix Mode]	

(1) Unassemble mode




In this mode, the debugger displays the program codes after unassembling into mnemonics.

(2) Source mode



In this mode, the source that contains the code at the current PC address is displayed like an editor screen. This mode is available only when an absolute object file that contains source debugging information has been loaded.

(3) Mix mode

In this mode, both unassembled codes and sources are displayed like an absolute list. This mode is available only when an absolute object file that contains source debugging information has been loaded.

Refer to Section 8.4.3, "[Source] Window" for details about the display contents.

Symbol reference

When debugging a program after reading an object file in IEEE-695 format, the symbols defined in the source file can be used to specify an address. This feature can be used when entering a command having <address> in its parameter from the [Command] window or a dialog box.

(1) Referencing global symbols

Follow the method below to specify a symbol that is declared to be a global symbol/label by the .global or .comm pseudo-instruction.

@<symbol>

Example of specification:

```
>m @BOOT
>de @RAM_BLK1
```

(2) Referencing local symbols

Follow the method below to specify a local symbol/label that is used in only the defined source file.

@<symbol>@<file name>

The file name here is the source file name (.s) in which the symbol is defined.

Example of specification:

```
>bp @SUB1@test.s
```

(3) Displaying symbol list

All symbols used in the program and the defined addresses can be displayed in the [Command] window.

Table 8.8.2.2 Command to display symbol list

Function	Command
Displaying symbol list	sy

8.8.3 Displaying and Modifying Program, Data, Option Data and Register

The debugger has functions to operate on the program memory, data memory, and registers, as well as option data. Each memory area is set to the debugger according to the map information that is given in a parameter file.

Operating on program memory area

The following operations can be performed on the program memory area:

Table 8.8.3.1 Commands to operate on program memory

Function	Command
Entering/modifying program code	pe
In-line assemble	a (as)
Rewriting specified area	pf
Copying specified area	pm

(1) Entering/modifying program code

The program code at a specified address is modified by entering hexadecimal data.

(2) In-line assemble

The program code at a specified address is modified by entering a mnemonic code.

(3) Rewriting specified area

An entire specified area is rewritten with specified code.

(4) Copying specified area


The content of a specified area is copied to another area.

Operating on data memory area

The following operations can be performed on the data memory areas (RAM, data ROM, display memory, I/O memory):

Table 8.8.3.2 Commands/menu item to operate on data memory

Function	Command	Menu
Dumping data memory	dd	[View Data Dump]
Entering/modifying data	de	—
Rewriting specified area	df	—
Copying specified area	dm	—



(1) Dumping data memory

The contents of the data memory are displayed in hexadecimal dump format. If the [Data] window is opened, the contents of the [Data] window are updated; if not, the contents of the data memory are displayed in the [Command] window.

(2) Entering/modifying data

Data at a specified address is rewritten by entering hexadecimal data. Data can be directly modified on the [Data] window.

(3) Rewriting specified area


An entire specified area is rewritten with specified data.

(4) Copying specified area

The content of a specified area is copied to another area.

(5) Monitoring memory

Four memory locations, each with area to store 4 consecutive words, can be registered as watch data addresses. The registered watch data can be verified in the [Register] window. The content of this window is updated in real time at 0.5-second intervals by the on-the-fly function. Addresses 0, 4, 8, and C are made the watch data addresses by default.



The memory content displayed at the left indicates data at a specified address, and the one displayed at the right indicates 4-word data at the high-order address.


Monitor data

Operating registers

The following operations can be performed on registers:

Table 8.8.3.3 Commands/menu items to operate registers

Function	Command	Menu
Displaying registers	rd	[View Register]
Modifying register values	rs	—

**(1) Displaying registers**

Register contents can be displayed in the [Register] or [Command] window.

Registers: PC, A, B, X and [X], Y and [Y], F, SP1, SP2, EXT, and QUEUE

While the program is being executed, the PC address and F register are updated in real time every 0.5 seconds by the on-the-fly function.

(2) Modifying register values

The contents of the above registers can be set to any desired value.

The register values can be directly modified on the [Register] window.

Displaying option data

Option data in the ICE option areas (function option data, segment option data, or melody data). Data is displayed in the [Command] window in hexadecimal dump format.

Table 8.8.3.4 Command to display option data

Function	Command
Displaying option data	od

8.8.4 Executing Program

The debugger can execute the target program successively or execute instructions one step at a time (single-stepping).

Successive execution

(1) Types of successive execution

There are two types of successive execution available:

- Successive execution from the current PC
- Successive execution from the program start address (0x0110) after resetting the CPU

Table 8.8.4.1 Commands/menu items/tool bar buttons for successive execution

Function	Command	Menu	Button
Successive execution from current PC	g	[Run Go]	
		[Run Go to Cursor]	
Successive execution after resetting CPU	gr	[Run Go from Reset]	

(2) Stopping successive execution

Using the successive execution command (**g**), can specify up to two temporary break addresses that are only effective during program execution.

The temporary break address can also be specified from the [Source] window (one location only).

If the cursor is placed on an address line in the [Source] window and the [Go to Cursor] button clicked, the program starts executing from the current PC address and breaks before executing the instruction at the address the cursor is placed.

Except being stopped by this temporary break, the program continues execution until it is stopped by one of the following causes:

- Break conditions set by a break set up command are met.
- The [Key Break] button is clicked or the [Esc] key is pressed.
- A map break, etc. occurs.

 [Key Break] button * When the program does not stop, use this button to forcibly stop it.

(3) On-the-fly function

The ICE and debugger provide the on-the-fly function to display the PC address, F register and watch data values every 0.5 seconds (default) during successive execution. These contents are displayed in the relevant positions of the [Register] window. If the [Register] window is closed, they are displayed in the [Command] window. In the initial debugger settings, the display update interval of the on-the-fly function is set to twice per second. It can be modified to 0 (OFF)–5 (times) per second using the *md* command. This function provides a complete real-time display that is implemented using the ICE hardware.

Single-stepping

(1) Types of single-stepping

There are two types of single-stepping available:

- Stepping through all instructions (STEP)
All instructions are executed one step at a time according to the PC, regardless of the type of instruction.
- Stepping through instructions except subroutines (NEXT)
The calr, calz and int instructions are executed under the assumption that one step constitutes the range of statements until control is returned to the next step by a return instruction. Other instructions are executed in the same way as in ordinary single-stepping.

In either case, the program starts executing from the current PC.

Table 8.8.4.2 Commands/menu items/tool bar buttons for single-stepping

Function	Command	Menu	Button
Stepping through all instructions	s	[Run Step]	
Stepping through all instructions except subroutines	n	[Run Next]	

When executing single-stepping by command input, the number of steps to be executed can be specified, up to 65,535 steps. When using menu commands or tool bar buttons, the program is executed one step at a time.

In the following cases, single-stepping is terminated before a specified number of steps is executed:

- When the [Key Break] button is clicked or the [Esc] key is pressed.
- When a map break or similar break occurs.

Single-stepping is not suspended by breaks set by the user such as a PC break or data break.



[Key Break] button * When the program does not stop, use this button to forcibly stop it.

(2) Display during single-stepping

In the initial debugger settings, the display is updated as follows:

The display contents of the [Register] window are updated every step. If the [Register] window is closed, its contents are displayed in the [Command] window. This default display mode can be switched over by the *md* command so that the display contents are updated at only the last step in a specified number of steps.

The display of the [Source] and [Data] windows are updated after the specified number of step executions are completed.

(3) HALT and SLEEP states and interrupts

The CPU is placed in a standby mode when the halt or slp instruction is executed. An interrupt is required to cancel this mode.

The debugger has a mode to enable or disable an external interrupt for use in single-step operation.

Table 8.8.4.3 External interrupt modes

	Enable mode	Disable mode
External interrupt	Interrupt is processed.	Interrupt is not processed.
halt and slp instructions	Executed as the halt instruction. Processing is continued by an external interrupt or clicking on the [Key Break] button.	The halt and slp instructions are replaced with a nop instruction as the instruction is executed.

In the initial settings, the debugger is set to the interrupt disable mode. The interrupt enable mode can also be set by using the *md* command.

Measuring execution cycles/execution time

(1) Execution cycle counter and measurement mode

The ICE contains a 31-bit execution cycle counter allowing you to measure the program execution time or the number of bus cycles executed. The measurement mode (time or bus cycle) can be selected using the *md* command. In the initial debugger settings, the bus cycle mode is selected.

The following lists the maximum values that can be measured by the execution cycle counter:

Execution time mode: 2,147,483,647 μ sec = approx. 36 min. (error = $\pm 1 \mu$ sec)
 Bus cycle mode: 2,147,483,647 cycles (error = ± 0)

(2) Displaying measurement results

The measurement result is displayed in the [Register] window. This display is cleared during program execution and is updated after completion of execution. If the [Register] window is closed, the measurement result can be displayed in the [Command] window using the *rd* command. The execution results of single-stepping are also displayed here.

If the counter's maximum count is exceeded, the system indicates "over flow".

(3) Hold mode and reset mode

In the initial debugger settings, the execution cycle counter is set to hold mode. In this mode, the measured values are combined until the counter is reset.

The reset mode can be set by the *md* command. In this mode, the counter is reset each time the program is executed. In successive execution, the counter is reset when the program is made to start executing by entering the *g* command and measurement is taken until the execution is terminated (beak occurs). (The same applies for the *gr* command except that the counter is reset simultaneously when the CPU is reset. Consequently, the counter operates the same way in both hold and reset modes.)

In single-stepping, the counter is reset when the program is made to start executing by entering the *s* or *n* command and measurement is taken until execution of a specified number of steps is completed. The counter is reset every step if execution of only one step is specified or execution is initiated by a tool bar button or menu command.

(4) Resetting execution cycle counter

The execution cycle counter is reset in the following cases:

- When the CPU is reset with the *rst* command, [Reset] in the [Run] menu, or the [Reset] button
- When the *gr* command or [Go from Reset] in the [Run] menu is executed
- When the execution cycle counter mode is switched over by the *md* command (between execution time and bus cycle modes or between hold and reset modes)
- When program execution is started in reset mode

Resetting the CPU

The CPU is reset when the *gr* command is executed, or by executing the *rst* command.

When the CPU is reset, the internal circuits are initialized as follows:

(1) Internal registers of the CPU

PC ... 0x0110
 A, B ... 0xa
 X, Y, QUEUE ... 0xaaaa
 F ... 0b0000
 SP1, SP2, EXT ... 0xaa

(2) The execution cycle counter is reset to 0.

(3) The [Source] and [Register] windows are redisplayed.

Because the PC is set to 0x0110, the [Source] window is redisplayed beginning with that address.

The [Register] window is redisplayed with the internal circuits initialized as described above.

The data memory contents are not modified.

8.8.5 Break Functions

The target program is made to stop executing by one of the following causes:

- Break command conditions are satisfied.
- The [Key Break] button is activated.
- The ICE BRKIN pin is pulled low.
- A map break or similar break occurs.

Break by command

The debugger has five types of break functions that allow the break conditions to be set by a command. When the set conditions in one of these break functions are met, the program under execution is made to break.

(1) Break by PC

This function causes the program to break when the PC matches the set address. The program is made to break before executing the instruction at that address. The PC breakpoints can be set for multiple addresses.

Table 8.8.5.1 Commands/menu items/tool bar button to set breakpoints

Function	Command	Menu	Button
Set breakpoints	bp	[Break Breakpoint Set...]	
Clear breakpoints	bc (bpc)	[Break Breakpoint Set...]	

The addresses that are set as PC breakpoints are marked with a ● as they are displayed in the [Source] window.

Using the [Break] button easily allows the setting and canceling of breakpoints.

Click on the address line in the [Source] window at where the program break is desired (after moving the cursor to that position) and then click on the [Break] button. A ● mark will be placed at the beginning of the line indicating that a breakpoint has been set there, and the address is registered in the breakpoint list. Clicking on the line that begins with a ● and then the [Break] button cancels the breakpoint you have set, in which case the address is deleted from the breakpoint list.

- * The temporary break addresses that can be specified by the successive execution commands (g) do not affect the set addresses in the breakpoint list.

(2) Data break

This break function allows a break to be executed when a location in the specified data memory area is accessed. In addition to specifying a memory area in which to watch accesses, specification as to whether the break is to be caused by a read or write, as well as specification of the content of the data read or written. The read/write condition can be masked, so that a break will be generated for whichever operation, read or write, is attempted. Similarly, the data condition can also be masked in bit units. A break occurs after completing the cycle in which an operation to satisfy the above specified condition is performed.

Table 8.8.5.2 Commands/menu item to set data break

Function	Command	Menu
Set data break condition	bd	[Break Data Break...]
Clear data break condition	bdc	[Break Data Break...]

For example, if the program is executed after setting the data break condition as Address = 0x10, Data pattern = * (mask) and R/W = W, the program breaks after writing any data to the data memory address 0x10.

(3) Register break

This break function causes a break when the A, B, F, X, and Y register reach a specified value. Each register can be masked (so they are not included in break conditions). The F register can be masked in bit units. A break occurs when the above registers are modified to satisfy all set conditions.

Table 8.8.5.3 Commands/menu item to set register break

Function	Command	Menu
Set register break conditions	br	[Break Register Break...]
Clear register break conditions	brc	[Break Register Break...]

For example, if the program is executed after setting 0 for the data of the A register and "***1*" for the data of the F register (C flag = 1) and masking all others, the program breaks when the A register is cleared to 0 and the C flag is set to 1.

(4) Sequential break

This break function allows settings of up to three break addresses and the number of times the instructions of the last address to be executed. While passing through all addresses sequentially in the order set, the program executes instructions at the final specified address the directed number of times, and then fetches the instruction at that address one more time before it breaks.

Table 8.8.5.4 Commands/menu item to set sequential break

Function	Command	Menu
Set sequential break conditions	bs	[Break Sequential Break...]
Clear sequential break conditions	bsc	[Break Sequential Break...]

For example, if you execute the program after first setting a break address in two locations at addresses 0x1000 and 0x2000 and specifying 3 for the execution count using the *bs* command, the program executes address 0x2000 three times after executing address 0x1000 more than one time, and when the PC reaches 0x2000, it breaks before performing the 4th execution. The execution count can be set up to 4,095.

(5) Accessing outside stack area

In this case, a break occurs when a location outside the stack area is accessed by stack pointer SP1 or SP2.

Before this function can be used, the SP1 and SP2 areas must be set by the *bsp* command. The initial value is 0x0 to 0x3ff for SP1, and 0x0 to 0xff for SP2. The address of SP1 must be specified in units of 4 words.

Table 8.8.5.5 Command/menu item to set stack break

Function	Command	Menu
Set stack break conditions	bsp	[Break Stack Break...]

Forced break by the [Key Break] button or the [Esc] key

The [Key Break] button or the [Esc] key can be used to forcibly terminate the program under execution when the program has fallen into an endless loop or cannot exit a standby (HALT or SLEEP) state.



[Key Break] button

Pulling ICE BRKIN pin low

The program is made to break by pulling the ICE BRKIN pin low (by applying a low-level pulse for more than 20 ns).

Map break and illegal instruction break

The program also breaks when one of the following errors is encountered during program execution:

(1) Access to undefined program area

A break occurs when an undefined area of the program memory map is accessed.

(2) Access to undefined data area

A break occurs when an undefined area of the data memory map is accessed.

(3) Write to data ROM area

A break occurs when a write to the data ROM area is attempted.


- Notes:*
- *If the return address is popped from the stack by a ret or reti instruction in an area with prohibited 16-bit access, invalid data is read out from a 16-bit data bus that does not have any memory connected. In the ICE, because the bus is pulled up, 0xffff is read out, causing control to return to that address. This could result in generating a map break.*
 - *A break caused by an undefined program area access occurs before execution of such operation. On the other hand, a map break caused by access to an undefined data area or a write to the data ROM area occurs one or two instructions after execution of such operation.*
 - *In user breaks based on command settings also, a PC break and sequential break occur before execution of operation. However, other breaks such as a data break, register break, and stack break occur one or two instructions after execution of operation.*

8.8.6 Trace Functions

The debugger has a function to trace program execution.

Trace memory and trace information

The ICE contains a trace memory. When the program executes instructions in the trace range according to the trace mode, the trace information on each cycle is taken into this memory. The trace memory has the capacity to store information for 8,192 cycles, making it possible to trace up to 4,096 instructions (for two-clock instructions only). When the trace information exceeds this capacity, the data is overwritten, the oldest data first unless operating in single-delay trigger mode. Consequently, the trace information stored in the trace memory is always within 8,192 cycles. The trace memory is cleared when a program is executed, starting to trace the new execution data.



The following lists the trace information that is taken into the trace memory in every cycle. This list is corresponded to display in the [Trace] window.

- trace cycle: Trace cycle (decimal). The last information taken into the trace memory becomes 00001.
- fetch addr: Fetch address (hexadecimal).
- fetch code disasm: Fetch code (hexadecimal) and disassembled content.
- register: Values of A, B, X, and Y registers after cycle execution (hexadecimal).
- flag: States of E, I, C, and Z flags after cycle execution (binary).
- data: Accessed data memory address (hexadecimal), read/write (denoted by r or w at the beginning of data), and data (1-digit hexadecimal for 4-bit access; 4-digit hexadecimal for 16-bit access).
- SP: Stack access (1 for SP1 access; 2 for SP2 access).
- trace in: Input to TRCIN pin (denoted by L when low-level signal is input).

Notes: The S1C63000 CPU uses two-stage pipelined instruction processing, one for fetch and one for execution. Therefore, please pay attention to the following:

- The CPU fetches the next instruction in the last execution cycle of an instruction. Because the instruction is executed beginning from the cycle which is after the fetch, the displayed states of the registers, etc. are not the execution results of the fetch instruction that is displayed on the same line.
- For reasons of the ICE operation timing, the trace data at the boundary of operations, such as in the fetch cycle at which trace starts or the execution cycle at which trace ends, will not always be stored in memory.

Trace modes

Three trace modes are available, depending on the method for sampling trace information.

Table 8.8.6.1 Trace mode setup command

Function	Command	Menu
Set trace mode	tm	[Trace Trace Mode Set...]

(1) Normal trace mode

In this mode, the trace information on all bus cycles is taken into the trace memory during program execution. Therefore, until a break occurs, the trace memory always contains the latest information on bus cycles up to the one that is executed immediately beforehand.

(2) Single delay trigger trace mode

In this mode as in other modes, trace is initiated by a start of program execution. When the address (trace trigger point) that is set by the **tm** command is executed, trace is performed beginning from that point before being halted according to the next setting, which is also set by the command.

- If the trace trigger point is set to "start"

Trace is halted after sampling trace information for 8,192 cycles beginning from the trace trigger point. In this case, the trace information at the trace trigger point is the oldest information stored in the trace memory.

If the program stops before tracing all 8,192 cycles, trace information on some cycles preceding the trace trigger point may be left in the trace memory within its capacity.




Fig. 8.8.6.1 Trace range when "start" is selected

- If the trace trigger point is set to "middle"

Trace is halted after sampling trace information for 4,096 cycles beginning from the trace trigger point. In this case, the trace information of 4,096 cycles before and after the trace trigger point are sampled into the trace memory.

If the program stops before tracing all 4,096 cycles, trace information for the location 4,096 cycles before the trace trigger point may be left in the trace memory, according to its capacity.




Fig. 8.8.6.2 Trace range when "middle" is selected

- If the trace trigger point is set to "end"

Trace is halted after sampling trace information at the trace trigger point. In this case, the trace information at the trace trigger point is the latest information stored in the trace memory.

If the program stops before tracing the trace trigger point, the system operates in the same way as in normal mode.




Fig. 8.8.6.3 Trace range when "end" is selected

If the program is halted in the middle of single delay trigger trace, bus cycles are traced from the beginning when trace is executed next.

(3) Address-area trace

In this mode, trace information is taken into the trace memory only when instructions within (or outside) a specified address range are executed. This address range can be set in up to four locations by the *tm* command. Whether you want trace to be performed within or outside that address range can also be specified by a command.

*** Trace trigger address**

The *tm* command sets a trace trigger address regardless of the trace mode specified. When the [Source] window is open, the address thus set is marked by a "T" at the beginning of the address. When the program executes that address, the ICE outputs a low-level pulse from its TRGOUT pin.

Displaying and searching trace information

The sampled trace information can be displayed in the [Trace] window by a command. If the [Trace] window is closed, the information is displayed in the [Command] window. In the [Trace] window, the entire trace memory data can be seen by scrolling the window. The trace information can be displayed beginning from a specified cycle.

The display contents are as described above.

Table 8.8.6.2 Command/menu item to display trace information

Function	Command	Menu
Display trace information	td	[View Trace]

It is possible to specify a search condition and display the trace information that matches a specified condition.

The search condition can be selected from the following three:

1. Program's execution address
2. Address from which data is read
3. Address to which data is written

When the above condition and one address are specified, the system starts searching. When the trace information that matches the specified condition is found, the system displays the found data in the [Trace] window (or in the [Command] window if the [Trace] window is closed).

Table 8.8.6.3 Command/menu item to search trace information

Function	Command	Menu
Search trace information	ts	[Trace Trace Search...]

Saving trace information

After the trace information is displayed in the [Trace] window using the *td* or *ts* commands, the trace information within the specified range can be saved to a file.

Table 8.8.6.4 Command/menu item to save trace information

Function	Command	Menu
Save trace information	tf	[Trace Trace File...]

8.8.7 Operation of Flash Memory

The ICE in-circuit emulator contains flash memory. This memory is designed to allow data to be transferred to and from the ICE's emulation memory and the target memory by a command.

The flash memory retains data even when the ICE is turned off. By writing the program and/or data under debug into the flash memory before turning off the power, you can call it up and continue debugging next time. Also, even when operating the ICE in free-run mode (in which a program is executed using only the ICE), you may need to write the program into the flash memory.

Note: The flash memory operation commands cannot be used when the USB ICE is used.

The following operations can be performed on the flash memory:

(1) Read from flash memory

Data is loaded from the flash memory into the emulation and/or target memory.

(2) Write to flash memory

Data in the emulation and/or target memory is saved to the flash memory. Also, the contents of the parameter file can be written to the flash memory as necessary. After writing to the flash memory in this way, you can protect it against read and write.

(3) Erasing flash memory

All contents of the flash memory are erased.

Table 8.8.7.1 Commands to operate on flash memory

Function	Command	Menu
Read from flash memory	lfl	[File Flash Memory Operation...]
Write to flash memory	sfl	[File Flash Memory Operation...]
Erase flash memory	efl	[File Flash Memory Operation...]

*Note: Unless the contents of the parameter file that is specified when invoking Debugger db63 match the contents of parameters in the flash memory, neither write (**sfl**) nor read (**lfl**) to and from the flash memory can be performed. After you have received the shipment of the ICE, erased the flash memory, or used a different parameter file (designed for some other microcomputer model in the S1C63 Family), be sure to write the contents of your parameter file along with other data into the flash memory using the **sfl** command.*

* **Free-run of the ICE**

When operating the ICE in free-run mode (with the program executed using only the ICE), the ICE uses the data written in the flash memory. Therefore, before the ICE can be used in free-run mode, the entire program, data, and option data must be written into the flash memory.

To operate the ICE in free-run mode, set the ICE/RUN switch to the RUN position and turn on the power. During free-run, map breaks caused by operation in the program and data areas set by a parameter file are effective. When a map break occurs, the PC LED on the ICE stops and the EMU LED turns off. All other break settings are invalid because they cannot be written into the flash memory.

8.8.8 Coverage

The ICE retains coverage information (i.e., information on addresses at which a program is executed) and it can be displayed in the [Command] window.

Because the executed address range is displayed as shown below, it is possible to know which areas have not been executed.

```
Coverage Information:
  0: 0110..0118
  1: 0200..020f
```

Table 8.8.8.1 Coverage commands

Function	Command
Display coverage information	cv
Clear coverage information	cvc

8.8.9 Writing Data to the FPGA on the Standard Peripheral Circuit Board

The standard peripheral circuit board is configured for the supported model by writing the peripheral function data to the on-board FPGA. This writing is necessary the first time the standard peripheral circuit board is used or before beginning development of another model.

The debugger supports the following FPGA data handling functions:

(1) Erasing FPGA

All contents of the FPGA are erased.

(2) Writing data to FPGA

Data in the specified file is written to the FPGA. Also, the write command supports erasing the FPGA. Data for the supported models are provided as "c63xxx.mot" files in the "epson\s1c63\ice\fpga" directory (default).

(3) FPGA data comparison

The contents of the FPGA and specified file are compared.

(4) FPGA data dump

The FPGA data is displayed in a hexadecimal dump format.

Table 8.8.9.1 FPGA commands

Function	Command
Erase FPGA	xfer/xfers
Write to FPGA	xfwr/xfwrs
Compare FPGA data and file	xfcp/xfcps
Dump FPGA data	xdp/xdps

Note: The standard peripheral circuit board has two on-board FPGAs, main FPGA and sub FPGA, and the different commands are provided for each FPGA (suffix "s" indicates that the command is for the sub FPGA).

However, it is not necessary to write data to the sub FPGA normally, because the sub FPGA contains LCD DC output function.

8.9 Command Reference

8.9.1 Command List

Table 8.9.1.1 lists the debug commands available with the debugger.

Table 8.9.1.1 Command list

Classification	Command	Function	Page
Program memory operation	a / as (assemble)	Assemble mnemonic	159
	pe (program memory enter)	Input program code	161
	pf (program memory fill)	Fill program area	162
	pm (program memory move)	Copy program memory	163
Data memory operation	dd (data memory dump)	Dump data memory	164
	de (data memory enter)	Input data	166
	df (data memory fill)	Fill data area	168
	dm (data memory move)	Copy data area	169
	dw (data memory watch)	Set watch data address	170
Option information	od (option data dump)	Dump option data	172
Register operation	rd (register display)	Display register values	174
	rs (register set)	Modify register values	175
Program execution	g (go)	Execute successively	177
	gr (go after reset CPU)	Reset CPU and execute successively	179
	s (step)	Step into	180
	n (next)	Step over	182
CPU reset	rst (reset CPU)	Reset CPU	183
Break	bp (breakpoint set)	Set breakpoint	184
	bc / bpc (breakpoint clear)	Clear breakpoint	186
	bd (data break)	Set data break	187
	bdc (data break clear)	Clear data break	189
	br (register break)	Set register break	190
	brc (register break clear)	Clear register break	192
	bs (sequential break)	Set sequential break	193
	bsc (sequential break clear)	Clear sequential break	195
	bsp (break stack pointer)	Specify stack area (for illegal stack access detection)	196
	bl (breakpoint list)	Display all break conditions	198
	bac (break all clear)	Clear all break conditions	199
Program display	u (unassemble)	Unassemble display	200
	sc (source code)	Source display	202
	m (mix)	Mix display	204
Symbol information	sy (symbol list)	List symbols	206
Load file	lf (load file)	Load IEEE-695 format absolute object file	207
	lo (load option)	Load Motorola-S format file	208
Flash memory operation *	lfl (load from flash memory)	Read from flash memory	209
	sfl (save to flash memory)	Write to flash memory	211
	efl (erase flash memory)	Erase flash memory	213
Trace	tm (trace mode)	Set trace mode	214
	td (trace data display)	Display trace information	216
	ts (trace search)	Search trace information	219
	tf (trace file)	Save trace information into a file	221
Coverage	cv (coverage)	Display coverage information	222
	cvc (coverage clear)	Clear coverage information	223
Command file	com (execute command file)	Load & execute command file	224
	cmw (execute command file with wait)	Load/execute command file with execution intervals	225
	rec (record commands to file)	Record commands to a command file	226
Log	log (log)	Turn log output on or off	227
Map information	ma (map information)	Display map information	228
Mode setting	md (mode)	Set mode	229
FPGA operation	xfer/xfers (xilinx fpga data erase)	Erase FPGA	232
	xfwr/xfwrs (xilinx fpga data write)	Write to FPGA	233
	xfcp/xfcps (xilinx fpga data compare)	Compare FPGA data and file	234
	xdp/xdps (xilinx fpga data dump)	Dump FPGA data	235
Quit	q (quit)	Quit debugger	236
Help	? (help)	Display command usage	237

* The flash memory operation commands (*lfl*, *sfl*, *efl*) cannot be used when the USB ICE is used.

8.9.2 Reference for Each Command

The following sections explain all the commands by functions.

The explanations contain the following items.

Function

Indicates the functions of the command.

Format

Indicates the keyboard input format and parameters required for execution.

Example

Indicates a sample execution of the command.

Note

Shows notes on using.

GUI utility

Indicates a menu item or tool bar button if they are available for the command.

Notes:

- *In the command format description, the parameters enclosed by < > indicate they are necessary parameters that must be input by the user; while the ones enclosed by [] indicate they are optional parameters.*

- *The input commands are case-insensitive, you can use either upper case or lower case letters or even mixed.*
- *An error results if the number of parameters is not correct when you input a command using direct input mode.*

`Error : Incorrect number of parameters`

8.9.3 Program Memory Operation

a / as (assemble mnemonic)

Function

This command assembles the input mnemonic and rewrites the corresponding code to the program memory at the specified address.

Format

- (1) **>a <address> <mnemonic> [<file name>]**↓ (direct input mode)
- (2) **>a [<address>]**↓ (guidance mode)
- Start address ? : <address>**↓ ... Displayed only when <address> is omitted.
Address Original code Original mnemonic : <mnemonic>↓

 >
- <address>: Start address from which to write code; hexadecimal or symbol (IEEE-695 format only)
 <mnemonic>: Input mnemonic; valid mnemonic of S1C63000 (expression and symbols are supported)
 <file name>: File in which the symbol used in the operand was defined.
 Condition: $0 \leq \text{address} \leq \text{last program memory address}$

Examples

Format (1)

>a 200 "ld %a, f"↓ ... Assembles "LD %A,0xF" and rewrites the code at address 0x200.

Format (2)

```
>a↓
Start address ? 200↓ ... Address is input.
0200 1ff6 ld %a,%f : add %a,%b↓ ... Mnemonic is input.
Source file name (enter to ignore) ?↓ ... Ignored *
0201 1fff *nop : ^↓ ... Returned to previous address.
0200 1972 add %a,%b : ↓ ... Input is skipped.
0201 1fff *nop : q↓ ... Command is terminated.
>
```

* Source file name should be entered when a symbol/label is used as the operand. Specify the source file name in which the symbol was defined.

```
0200 1972 add %a,%b : jr LOOP↓ ... Symbol is used.
Source file name (enter to ignore) ? main.s↓ ... Source file name is input.
```

Notes

- The *a* and *as* commands have the same function.
- The start address you specified must be within the range of the program memory area available with each microcomputer model.
An error results if the input one is not a hexadecimal number or not a valid symbol.
Error : invalid value (no such symbol / symbol type error)
An error results if the limit is exceeded.
Error : Address out of range, use 0-0xXXXX
- An error results if the input mnemonic is invalid for S1C63000.
Error : illegal mnemonic
- In guidance mode, the following keyboard inputs have special meaning:
"q↵" ... Command is terminated. (finish inputting and start execution)
"^↵" ... Return to previous address.
"↵" ... Input is skipped. (keep current value)
If the maximum address of program memory is reached and gets a valid input other than "^↵", the command is terminated.
- When the contents of the program memory are modified using the *a* (*as*) command, the unassembled contents of the [Source] window are updated immediately.
- Although the contents of the unassembled display are modified by rewriting code, those of source display remain unchanged.

GUI utility

None

pe (program memory enter)

Function

This command rewrites the contents of the specified address in the program memory with the input hexadecimal code.

Format

- (1) **>pe <address> <code1> [<code2> [...<code8>]]** (direct input mode)
 (2) **>pe [<address>]** (guidance mode)
Program enter address ? <address> ... Displayed only when <address> is omitted.
Address Original code : <code>

 >
 <address>: Start address from which to write code; hexadecimal or symbol (IEEE-695 format only)
 <code(1-8)>: Write code; hexadecimal (valid operation code of S1C63000)
 Condition: $0 \leq \text{address} \leq \text{last program memory address}$, $0 \leq \text{input code} \leq 0x1fff$

Examples

Format (1)
 >pe 200 1972 ... Rewrites the code at address 0x200 with 0x1972 (add %a, %b).

Format (2)
 >pe
 Program enter address ? 200 ... Address is input.
 0200 1fff : 1972 ... Code is input.
 0201 1fff : ↵ ... Address 0x201 is skipped.
 0202 1fff : q ... Command is terminated.
 >

Notes

- The start address you specified must be within the range of the program memory area available with each microcomputer model.
 An error results if the input one is not hexadecimal number or not a valid symbol.
 Error : invalid value (no such symbol / symbol type error)
 An error results if the limit is exceeded.
 Error : Address out of range, use 0-0xFFFF
- Code must be input using a hexadecimal number in the range of 13 bits (0 to 0x1fff).
 An error results if the input one is not a hexadecimal number.
 Error : invalid value
 An error results if the input code exceeds the limit or it is invalidated in the .PAR file.
 Error : illegal code
- In guidance mode, the following keyboard inputs have special meaning:
 "q" ... Command is terminated. (finish inputting and start execution)
 "^" ... Return to previous address.
 "↵" ... Input is skipped. (keep current value)
 If the maximum address of program memory is reached and gets a valid input other than "^", the command is terminated.
- When the contents of the program memory are modified using the *pe* command, the unassembled contents of the [Source] window are updated immediately.
- Although the contents of the unassembled display are modified by rewriting code, those of source display remain unchanged.

GUI utility

None

pf (program memory fill)**Function**

This command rewrites the contents of the specified program memory area with the specified code.

Format

(1) **>pf <address1> <address2> <code>** (direct input mode)

(2) **>pf** (guidance mode)

Start address ? <address1>

End address ? <address2>

Fill code ? <code>

>

<address1>: Start address of specified range; hexadecimal or symbol (IEEE-695 format only)

<address2>: End address of specified range; hexadecimal or symbol (IEEE-695 format only)

<code>: Write code; hexadecimal (valid operation code of S1C63000)

Condition: $0 \leq \text{address1} \leq \text{address2} \leq \text{last program memory address}$, $0 \leq \text{code} \leq 0x1fff$

Examples

Format (1)

>pf 200 20f 1ffe ... Fills the area from address 0x200 to address 0x20f with 0x1ffe (nop).

Format (2)

>pf

Start address ? 200 ... Start address is input.

End address ? 20f ... End address is input.

Fill code ? 1fff ... Code is input.

>

* Command execution can be canceled by entering only the [Enter] key and nothing else.

Notes

- The addresses specified here must be within the range of the program memory area available with each microcomputer model.

An error results if the input one is not a hexadecimal number or not a valid symbol.

Error : invalid value (no such symbol / symbol type error)

An error results if the limit is exceeded.

Error : Address out of range, use 0-0xFFFF

- An error results if the start address is larger than the end address.
Error : end address < start address
- When the contents of the program memory is modified using the *pf* command, the contents of the [Source] window are updated automatically.
- Although the contents of the unassembled display are modified by rewriting code, those of source display remain unchanged.

GUI utility

None

pm (program memory move)

Function

This command copies the content of a specified program memory area to another area.

Format

(1) >pm <address1> <address2> <address3>␣ (direct input mode)

(2) >pm␣ (guidance mode)

Start address ? <address1>␣

End address ? <address2>␣

Destination address ? <address3>␣

>

<address1>: Start address of source area to be copied from; hexadecimal or symbol (IEEE-695 format only)

<address2>: End address of source area to be copied from; hexadecimal or symbol (IEEE-695 format only)

<address3>: Address of destination area to be copied to; hexadecimal or symbol (IEEE-695 format only)

Condition: $0 \leq \text{address1} \leq \text{address2} \leq \text{last program memory address}$

$0 \leq \text{address3} \leq \text{last program memory address}$

Examples

Format (1)

>pm 200 2ff 280␣

... Copies the codes within the range from address 0x200 to address 0x2ff to the area from address 0x280.

Format (2)

>pm␣

Start address ? 200␣ ... Source area start address is input.

End address ? 2ff␣ ... Source area end address is input.

Destination address ? 280␣ ... Destination area start address is input.

>

* Command execution can be canceled by entering only the [Enter] key and nothing else.

Notes

- The addresses you specified must be within the range of the program memory area available with each microcomputer model.
An error results if the input one is not a hexadecimal number or not a valid symbol.
Error : invalid value (no such symbol / symbol type error)
An error results if the limit is exceeded.
Error : Address out of range, use 0-0xFFFF
- An error results if the start address is larger than the end address.
Error : end address < start address
- When the contents of the program memory is modified using the *pm* command, the contents of the [Source] window are updated automatically.
- Although the contents of the unassembled display are modified by rewriting code, those of source display remain unchanged.

GUI utility

None

8.9.4 Data Memory Operation

dd (data memory dump)

Function


This command displays the content of the data memory in a 16 words/line hexadecimal dump format.

Format

>dd [<address1> [<address2>]] (direct input mode)
 <address1>: Start address to display; hexadecimal or symbol (IEEE-695 format only)
 <address2>: End address to display; hexadecimal or symbol (IEEE-695 format only)
 Condition: 0 ≤ address1 ≤ address2 ≤ 0xffff

Display

(1) When [Data] window is opened



If both <address1> and <address2> are not defined, the [Data] window is redisplayed beginning with address 0x0000.

If <address1> is defined, or even <address2> is defined, the [Data] window is redisplayed in such a way that <address1> is displayed at the uppermost line.

Even when <address1> specifies somewhere in 16 addresses/line, data is displayed beginning with the top of that line. For example, even though you may have specified address 0xff08 for <address1>, data is displayed beginning with address 0xff00.

However, if an address near the uppermost part of data memory (e.g. maximum address is 0xffff), such as 0xffc0, is specified as <address1>, the last line displayed in the window in this case is 0xffff, the specified address is not at the top of the window.

Since the [Data] window can be scrolled to show the entire data memory, defining <address2> does not have any specific effect. Only defining <address1> and both defining <address1> and <address2> has same display result.

(2) When [Data] window is closed

If both <address1> and <address2> are not defined, the debugger displays data for 256 words from address 0x000 in the [Command] window.

```
>dd
      0 1 2 3 4 5 6 7 8 9 A B C D E F
0000: A A A A D C 0 3 A A A A A A A A
0010: A A A A A A A A A A A A A A A A
      :           :
00E0: A A A A A A A A A A A A A A A A
00F0: A A A A A A A A A A A A A A A A
>
```

If only <address1> is defined, the debugger displays data for 256 words from <address1>.

```
>dd ff00
FF00: 0 0 3 * 0 0 0 2 0 0 1 0 2 0 * *
FF10: * * * * * * * * * * * * * * * *
      :           :
FFE0: 0 0 0 0 0 0 0 0 * * * * * * * *
FFF0: 0 0 0 0 0 0 0 0 * * * * * * * *
>
```

"*" indicates an unused address.

If both <address1> and <address2> are defined, the debugger displays data from <address1> to <address2>.

```
>dd 008 017.␣
      0 1 2 3 4 5 6 7 8 9 A B C D E F
0000: 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
0010: 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
>
```

(3) *During log output*

If a command execution is being output to a log file by the *log* command when you dump the data memory, data is displayed in the [Command] window even if the [Data] window is opened and are also output to the log file.

If the [Data] window is closed, data is displayed in the [Command] window in the same way as in (2) above.

If the [Data] window is open, it is redisplayed to show data in the same way as in (1) above. In this case, the same number of lines is displayed in the [Command] window as are displayed in the [Data] window.

(4) *Successive display*

Once you execute the *dd* command, data can be displayed successively with the [Enter] key only until some other command is executed.

When you hit the [Enter] key, the [Data] window is scrolled one full screen.

When displaying data in the [Command] window, data is displayed for the 16 lines following the previously displayed address (same number of lines as displayed in the [Data] window during log output).

```
>dd.␣
      0 1 2 3 4 5 6 7 8 9 A B C D E F
0000: A A A A A A A A A A A A A A A A
0010: A A A A A A A A A A A A A A A A
:
:
00F0: A A A A A A A A A A A A A A A A
>␣
      0 1 2 3 4 5 6 7 8 9 A B C D E F
0100: A A A A A A A A A A A A A A A A
0110: A A A A A A A A A A A A A A A A
:
:
01F0: A A A A A A A A A A A A A A A A
>
```

When the line at address 0xffff0 is displayed, the system stands by waiting for command input. If you hit the [Enter] key here, data is displayed beginning with address 0x0000.

Notes

- Both the start and end addresses specified here must be within the range of the data memory area available with each microcomputer model.

An error results if the input one is not a hexadecimal number or not a valid symbol.

Error : invalid value (no such symbol / symbol type error)

An error results if the limit is exceeded.

Error : Address out of range, use 0-0xFFFF

- An error results if the start address is larger than the end address.

Error : end address < start address

GUI utility

[View | Data Dump] menu item

When this menu item is selected, the [Data] window opens or becomes active and displays the current data memory contents.

de (data memory enter)

Function

This command rewrites the contents of the data memory with the input hexadecimal data. Data can be written to continuous memory locations beginning with a specified address.

Format

(1) >de <address> <data1> [<data2> [...<data16>]]␣ (direct input mode)

(2) >de␣ (guidance mode)

Data enter address ? : <address>␣

Address Original data : <data>␣

.....

>

<address>: Start address from which to write data; hexadecimal or symbol (IEEE-695 format only)

<data(1-16)>: Write data; hexadecimal

Condition: $0 \leq \text{address} \leq 0\text{xffff}$, $0 \leq \text{data} \leq 0\text{xf}$

Examples

Format (1)

>de 100 0␣ ... Rewrites data at address 0x100 with 0.

Format (2)

>de␣

Data enter address ? :100␣ ... Address is input.

0100 0 : a␣ ... Data is input.

0101 0 : ␣ ... Skipped.

0102 0 : q␣ ... Command is terminated.

>

Notes

- The start address specified here must be within the range of the data memory area available with each microcomputer model.

An error results if the input one is not a hexadecimal number or a valid symbol.

Error : invalid value (no such symbol / symbol type error)

An error results if the limit is exceeded.

Error : Address out of range, use 0-0xFFFF

- The contents of the unused area will be marked as "*". If you encounter any address marked by "*", press [Enter] key to skip that address or terminate the command.
- Data must be input using a hexadecimal number in the range of 4 bits (0-0xf). An error results if the limit is exceeded.
- When the contents of the data memory is modified using the *de* command, the displayed contents of the [Data] window are updated automatically.

Error : Data out of range, use 0-0xF

- In guidance mode, the following keyboard inputs have special meaning:

"q␣" ... Command is terminated. (finish inputting and start execution)


"^␣" ... Return to previous address.

"␣" ... Input is skipped. (keep current value)

If the maximum address of data memory is reached and gets a valid input other than "^␣", the command is terminated.

GUI utility

[Data] window



The [Data] window allows direct modification of data. Click the [Data] window and select the displayed data to be modified then enter a hexadecimal number.

df (data memory fill)

Function

This command rewrites the contents of the specified data memory area with the specified data.

Format

(1) **>df <address1> <address2> <data>** (direct input mode)

(2) **>df** (guidance mode)

Start address ? <address1>

End address ? <address2>

Data pattern ? <data>

>

<address1>: Start address of specified range; hexadecimal or symbol (IEEE-695 format only)

<address2>: End address of specified range; hexadecimal or symbol (IEEE-695 format only)

<data>: Write data; hexadecimal

Condition: $0 \leq \text{address1} \leq \text{address2} \leq 0\text{xffff}$, $0 \leq \text{data} \leq 0\text{xf}$

Examples

Format (1)

>df 200 2ff 0 ... Fills the data memory area from address 0x200 to address 0x2ff with 0x0.

Format (2)

>df

Start address ? 200 ... Start address is input.

End address ? 2ff ... End address is input.

Data pattern ? 0 ... Data is input.

>

* Command execution can be canceled by entering only the [Enter] key and nothing else.

Notes

- Both the start and end addresses specified here must be within the range of the data memory area available with each microcomputer model.

An error results if the input one is not a hexadecimal number or a valid symbol.

Error : invalid value (no such symbol / symbol type error)

An error results if the limit is exceeded.

Error : Address out of range, use 0-0xFFFF

- An error results if the start address is larger than the end address.
Error : end address < start address
- Data must be input using a hexadecimal number in the range of 4 bits (0 to 0xf). An error results if the limit is exceeded.
Error : Data out of range, use 0-0xF
- Write operation is not performed to the read only address of the I/O area.
- When there is an unused area in the specified address range, no error occurs. The area other than the unused area will be filled with the specified data.
- When the contents of the data memory is modified using the *df* command, the displayed contents of the [Data] window are updated automatically.

GUI utility

None

dm (data memory move)

Function

This command copies the contents of the specified data memory area to another area.

Format

(1) **>dm <address1> <address2> <address3>↵** (direct input mode)

(2) **>dm↵** (guidance mode)

Start address ? <address1>↵

End address ? <address2>↵

Destination address ? <address3>↵

>

<address1>: Start address of source area to be copied from; hexadecimal or symbol (IEEE-695 format only)

<address2>: End address of source area to be copied from; hexadecimal or symbol (IEEE-695 format only)

<address3>: Address of destination area to be copied to; hexadecimal or symbol (IEEE-695 format only)

Condition: $0 \leq \text{address1} \leq \text{address2} \leq 0\text{xffff}$, $0 \leq \text{address3} \leq 0\text{xffff}$

Examples

Format (1)

```
>dm 200 2ff 280↵
```

... Copies data within the range from address 0x200 to address 0x2ff to the area from address 0x280.

Format (2)

```
>dm↵
```

```
Start address ? 200↵
```

... Source area start address is input.

```
End address ? 2ff↵
```

... Source area end address is input.

```
Destination address 280↵
```

... Destination area start address is input.

>

* Command execution can be canceled by entering only the [Enter] key and nothing else.

Notes

- All the addresses specified here must be within the range of the data memory area available with each microcomputer model.

An error results if the input one is not a hexadecimal number or a valid symbol.

Error : invalid value (no such symbol / symbol type error)

An error results if the limit is exceeded.

Error : Address out of range, use 0-0xFFFF

- Write operation is not performed to the read-only address of the I/O area.
- Data in the write-only area cannot be read. If the source area contains write-only address, 0 is written to the corresponding destination. If the destination area contains read-only address, the data of that address can not be rewritten. If the source and destination areas contain I/O address of mixed read-only bits and write-only bits, either read or write operation can be executed for the corresponding bits.
- When the contents of the data memory is modified using the *dm* command, the displayed contents of the [Data] window are updated automatically.

GUI utility

None

dw (data memory watch)

Function

This command registers four data memory locations as the watch data addresses. Memory contents equivalent to 4 words at each watch address are displayed in the [Register] window.

Format

(1) >dw <address1> [... <address4>] ↵ (direct input mode)

(2) >dw↵ (guidance mode)

Address 1 = Old value : <address1>↵

Address 2 = Old value : <address2>↵

Address 3 = Old value : <address3>↵

Address 4 = Old value : <address4>↵

>

<address1-4>: Watch address; hexadecimal or symbol (IEEE-695 format only)

Condition: 0 ≤ address1 ≤ address2 ≤ 0xffff

Examples

Format (1)

>dw 10 14 18 1c↵ ... Sets watch addresses to 0x10, 0x14, 0x18, and 0x1c.

Format (2)

>dw↵

Address1 = 0010 :0↵

Address2 = 0014 :4↵

Address3 = 0018 :8↵

Address4 = 001c :c↵

>

Notes

- When the debugger starts up, four locations at addresses 0, 4, 8, and 0xc are initially set as the watch data addresses.
- The address specified here must be within the range of the data memory area available with each microcomputer model.

An error results if the input one is not a hexadecimal number or a valid symbol.

Error : invalid value (no such symbol / symbol type error)

An error results if the limit is exceeded.

Error : Address out of range, use 0-0xFFFF

- The watch data addresses are set in units of 4 words. A warning results if you specify an address that is outside the 4-word boundary, with your specified address rounded down to a multiple of 4.

Example: >dw↵

Address1 = 0000 :0↵

Address2 = 0004 :10↵

Address3 = 0008 :15↵ ... Illegal address

Address4 = 000c :19↵ ... Illegal address

Warning : round down to multiple of 4

Address1 = 0

Address2 = 10

Address3 = 14

>

- Be aware that a value is displayed as the watch data even if the invalid address, which is displayed as an "*" in the *dd* command, is registered. The value in this case is indeterminate.
- The value displayed to the left shows the content of the start address, and that displayed to the right is the content of an address that is equal to the start address + 3.

GUI utility

None

8.9.5 Command to Display Option Information

od (option data dump)

Function

This command displays option data in the [Command] window in a hexadecimal dump format after reading it from the ICE.

Option data	Target memory address range
Function option data (fog)	0 to 0xef
Segment option data (sog)	0 to 0x1fff
Melody data (mla)	0 to 0xffff

Format

(1) >od <type> [<address1> [<address2>]]␣ (direct input mode)

(2) >od␣ (guidance mode)

1.fog 2.sog 3.mla ... ? <type>␣

Start address ? <address1>␣

End address ? <address2>␣

Option data display

>

<type>: Option type; fog, sog, or mla

<address1>: Start address of specified range; hexadecimal

<address2>: End address of specified range; hexadecimal

Condition: 0 ≤ address1 ≤ address2 ≤ 0xef (fog), 0x1fff (sog) or 0xffff (mla)

Examples

Format (1)

```
>od fog 0 f␣ ... Displays function option data within the range of 0 to 0xf.
    0 1 2 3 4 5 6 7 8 9 A B C D E F
0000: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
```

Format (2)

```
>od
1.fog 2.sog 3.mla ... ? 1␣ ... Function option is selected.
Start address ? 10␣ ... Start address is input.
End address ? 1f␣ ... End address is input.
    0 1 2 3 4 5 6 7 8 9 A B C D E F
0010: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
>
```

Notes

- The start and end addresses can be omitted by entering the [Enter] key only. If the start address is omitted, data is displayed beginning with address 0. If the end address is omitted, data is displayed for up to 16 lines within the range of the option area.
- Data in unused areas is marked by an "*" as it is displayed in the window.
- The maximum number of lines that can be displayed at once is 16 (fog data is limited to 15 lines). Even if you specify the end address in an attempt to display more than 16 lines, the system will only display data for 16 lines and then stand by waiting for a command input. As with the *dd* command, this command allows you to display data for the following addresses by entering the [Enter] key only. (The maximum number of lines is 16.)

- Both the start and end addresses must be specified within the setup range of each option. An error results if this limit is exceeded.
 - Error : FO address out of range, use 0-0xEF
... Specified address for the function option is outside the range.
 - Error : SO address out of range, use 0-0x1FFF
... Specified address for the segment option is outside the range.
 - Error : MLA address out of range, use 0-0xFFF
... Specified address for the melody data is outside the range.
- An error results if the start address is larger than the end address.
 - Error : end address < start address
- The default value of option data is 0.

GUI utility

None

8.9.6 Register Operation

rd (register display)

Function


This command displays the contents of the registers, execution cycle counter, and watch data.

Format

>rd␣ (direct input mode)

Display

(1) Contents of display



The following lists the contents displayed by this command.

- PC: Program counter
- A: A register
- B: B register
- X: Contents of X register and indirectly addressed data memory
- Y: Contents of Y register and indirectly addressed data memory
- EICZ: Flags
- SP1: Stack pointer SP1
- SP2: Stack pointer SP2
- EXT: EXT register
- QUEUE: QUEUE register
- bus cycle: Execution cycle counter
- [xxxx]: Watch data at four locations

* If the memory locations indicated by the X and Y registers are in an unused area, the data in that area is marked by an "*" as it is displayed.
 Note that watch data is always displayed even if it resides in an unused area (indeterminate).

(2) When [Register] window is opened

When the [Register] window is opened, all the above contents are displayed in the [Register] window according to the program execution. When you use the *rd* command, the displayed contents of the [Register] window is updated.

(3) When [Register] window is closed

Data is displayed in the [Command] window in the following manner:

```
>rd␣
PC:0110 A:A B:A X:[AAAA] = * Y:[AAAA] = * EICZ:0000 SP1:AA SP2:AA EXT:AA
QUEUE:AAAA bus cycle:000002AB3D cycle
[0000] = 0000 [0010] = AAAA [0014] = AAAA [0018] = AAAA
>
```

(4) During log output

If a command execution result is being output to a log file by the *log* command, the register values are displayed in the [Command] window even if the [Register] window is opened and are also output to the log file.

GUI utility

[View | Register] menu item

When this menu item is selected, the [Register] window opens or becomes active and displays the current register contents.

RS (register set)

Function

This command modifies the register values.

Format

(1) `>rs <register> <value> [<register> <value> [...<register> <value>]]` (direct input mode)

(2) `>rs` (guidance mode)

```

PC = Old value : <value>↵
A = Old value : <value>↵
B = Old value : <value>↵
X = Old value : <value>↵
Y = Old value : <value>↵
FE = Old value : <value>↵
FI = Old value : <value>↵
FC = Old value : <value>↵
FZ = Old value : <value>↵
SP1 = Old value : <value>↵
SP2 = Old value : <value>↵
EXT = Old value : <value>↵
Q = Old value : <value>↵

```

>

<register>: Register name (PC, A, B, X, Y, F, SP1, SP2, EXT, Q)

<value>: Value to be set to the register; hexadecimal

Examples

Format (1)

```
>rs pc 110 f 0 ... Sets PC to 0x0110 and resets all the flags.
```

Format (2)

```

>rs↵
PC= 116: 110↵
A= 0: f↵
B= 0: ↵
X= 0: 100↵
Y= 0: 100↵
FE= 0: ↵
FI= 0: ↵
FC= 1: 0↵
FZ= 1: 0↵
SP1= aa: ff↵
SP2= aa: ff↵
EXT= 0: ↵
Q= 0: ↵

```

When a register is modified, the [Register] window is updated to show the contents you have input. If you input "q" to stop entering in the middle, the contents input up to that time are updated.

Notes

- An error results if you input a value exceeding the register's bit width.
Error : invalid value
- An error results if you input a register name other than PC, A, B, X, Y, F, SP1, SP2, EXT or Q in direct input mode.
Error : Incorrect register name, use PC/A/B/X/Y/F/SP1/SP2/EXT/Q
- In guidance mode, the following keyboard inputs have special meaning:
"q↵" ... Command is terminated. (finish inputting and start execution)
"^↵" ... Return to previous register.
"↵" ... Input is skipped. (keep current value)

GUI utility

[Register] window

The [Register] window allows direct modification of data. Click the [Register] window, select the displayed data to be modified and enter a value then press [Enter].

8.9.7 Program Execution

g (go)

Function

This command executes the target program from the current PC position.

Format

>g [<address1> [<address2>]]-␣ (direct input mode)

<address1-2>: Temporary break addresses; hexadecimal or symbol (IEEE-695 format only)

Condition: $0 \leq \text{address1(2)} \leq \text{last program memory address}$

Operation

(1) Program execution

The target program is executed from the address indicated by the PC. Program execution is continued until it is made to break for one of the following causes:

- The set break condition is met
- The [Key Break] button is clicked or the [Esc] key is pressed
- A map break, etc., occurs

If a temporary break is specified, the program execution will be suspended before executing the instruction at the specified address. Up to two temporary break addresses can be specified.

>g 1a0-␣ ... Executes the program from the current PC address to address 0x1a0.

When program execution breaks, the system stands by waiting for a command input after displaying a break status message. When you hit the [Enter] key here, program execution is resumed beginning with a PC address next to the break address. Temporary break address settings are also valid.

(2) Window display by program execution

In the initial debugger settings, the on-the-fly function is turned on.

During program execution, the PC, flags and watch data contents in the [Register] window are updated in real time every 0.5 seconds (default) by the on-the-fly function. If the [Register] window is closed, the above contents are displayed in the [Command] window. The on-the-fly function can be turned off by the *otf* command. In this case, the [Register] window is updated after a break.

The [Source] window is updated after a break in such a way that the break address is displayed within the window.

If the [Trace] window is opened, the display contents are cleared as the program is executed. It is updated with the new trace information after a break.

If the [Data] window is opened, the display contents are updated after a break.

(3) Display during log mode

If the program is executed after turning on the log mode, an on-the-fly display appears in the [Command] window as well as the [Register] window.

Example:

```
>g
PC:0007 EICZ:0001 [0000] = AAAA [0004] = 3D30 [0008] = AAAA [000C] = AAAA
PC:000C EICZ:0000 [0000] = AAAA [0004] = 5250 [0008] = AAAA [000C] = AAAA
PC:0117 EICZ:1001 [0000] = AAAA [0004] = 6760 [0008] = AAAA [000C] = AAAA
PC:000B EICZ:0000 [0000] = AAAA [0004] = 8C70 [0008] = AAAA [000C] = AAAA
Key Break
PC:0008 A:F B:1 X:[0007] = 0 Y:[AAAA] = * EICZ:1001 SP1:4A(128) SP2:1F EXT:00
QUEUE:0118 bus cycle:0000029332 cycle [0000] = AAAA [0004] = E280 [0008] = AAAA
[000C] = AAAA
>
```

When a break occurs, the same display appears as when data is displayed by the *rd* command.

(4) Execution cycle counter

The execution cycle counter displayed in the [Register] window indicates the number of cycles executed or the execution time of the target program. (Refer to Section 8.8.4 for details.)

In the initial debugger settings, the execution cycle counter is set to hold mode so that execution time is added up until the CPU is reset. If this mode is changed to reset mode by the *md* command, the execution cycle counter is cleared to 0 each time the *g* command is executed. The counter is also reset simultaneously when execution is restarted by hitting the [Enter] key.

Notes

- If a break condition is met, program execution is suspended and the PC will be set to the program address at the breakpoint.
- The address you specified must be within the range of the program memory area available with each microcomputer model.

An error results if the input one is not a hexadecimal number or a valid symbol.

Error : invalid value (no such symbol / symbol type error)

An error results if the limit is exceeded.

Error : Address out of range, use 0-0xXXXX

GUI utility

[Run | Go] menu item, [Go] button

When this menu item or button is selected, the *g* command without temporary break is executed.

 [Go] button

[Run | Go to Cursor] menu item, [Go to Cursor] button

When this menu item or button is selected after placing the cursor to the temporary break address line in the [Source] window, the *g* command with a temporary break is executed. The program execution will be suspended after executing the address at the cursor position.

 [Go to Cursor] button

gr (go after reset CPU)

Function

This command executes the target program from the boot address after resetting the CPU.

Format

>gr [<address1> [<address2>]]↵ (direct input mode)

<address1-2>: Temporary break addresses; hexadecimal or symbol (IEEE-695 format only)

Condition: $0 \leq \text{address1(2)} \leq \text{last program memory address}$

Operation

This command resets the CPU before executing the program. This causes the PC to be set at address 0x0110, from which the command starts executing the program.

Once the program starts executing, the command operates in the same way as the **g** command, except that the **gr** command does not support the function for restarting execution by hitting the [Enter] key. Refer to the explanation of the **g** command for more information.

Notes

- If a break condition is met, program execution is suspended and the PC will be set to the program address at the breakpoint.
- The address you specified must be within the range of the program memory area available with each microcomputer model.

An error results if the input one is not a hexadecimal number or a valid symbol.

Error : invalid value (no such symbol / symbol type error)

An error results if the limit is exceeded.

Error : Address out of range, use 0-0XXXXX

GUI utility

[Run | Go from Reset] menu item, [Go from Reset] button

When this menu item or button is selected, the **gr** command is executed.



[Go from Reset] button

S (step)

Function

This command single-steps the target program from the current PC position by executing one instruction at a time.

Format

>s [*<step>*] (direct input mode)

<step>: Number of steps to be executed; decimal (default is 1)
 Condition: 0 ≤ step ≤ 65,535

Operation

(1) Step execution

If the *<step>* is omitted, only the program step at the address indicated by the PC is executed, otherwise the specified number of program steps is executed from the address indicated by the PC.

>s↵ ...Executes one step at the current PC address.
 >s 20↵ ...Executes 20 steps from the current PC address.

The program execution is suspended by the following cause even before the specified number of steps is completed.

- The [Key Break] button is clicked or the [Esc] key is pressed
- A map break, etc. occurs

After each step is completed, the register contents in the [Register] window are updated. If the [Register] window is closed, the register contents are displayed in the [Command] window same as executing the *rd* command.

When program execution is completed by stepping through instructions, the system stands by waiting for command input. If you hit the [Enter] key here, the system single-steps the program in the same way again.

(2) HALT and SLEEP states and interrupts

When the halt or slp instruction is executed, the CPU is placed in standby mode. An interrupt is required to clear this mode. The debugger has a mode to enable or disable an external interrupt for use in a single-step operation.

	Enable mode	Disable mode
External interrupt	Interrupt is processed.	Interrupt is not processed.
halt and slp instructions	Executed as the halt instruction. Processing is continued by an external interrupt or clicking on the [Key Break] button.	The halt and slp instructions are replaced with a nop instruction as the instruction is executed.

In the initial settings, the debugger is set to the interrupt disable mode. The interrupt enable mode can also be set by using the *md* command.

(3) Execution cycle counter

The execution cycle counter displayed in the [Register] window indicates the number of cycles executed or the execution time of the target program.

In the initial debugger settings, the execution cycle counter is set to hold mode so that execution time is added up until the CPU is reset. If this mode is changed to reset mode by the *md* command, the execution cycle counter is cleared to 0 each time the *s* command is executed. The counter is also reset simultaneously when execution is restarted by hitting the [Enter] key.

(4) During log mode

If the program is single-stepped after turning on the log mode, the same contents as when executing the *rd* command are displayed in the [Command] window after each step is completed.

Notes

- The step count must be specified within the range of 0 to 65,535. An error results if the limit is exceeded.
Error : Number of steps out of range, use 0-65535
- If the [Data] window is opened, its display contents are updated after the execution.
- During a single-step operation, the program will not break even if the break condition set by a command is met.
- Unlike in successive executions (*g* or *gr* command), the [Register] window is updated every time a step is executed.

GUI utility**[Run | Step] menu item, [Step] button**

When this menu item or button is selected, the *s* command without step count is executed.



[Step] button

n (next)

Function

This command single-steps the target program from the current PC position by executing one instruction at a time.

Format

>n [<step>]␣ (direct input mode)

<step>: Number of steps to be executed; decimal (default is 1)

Condition: $0 \leq \text{step} \leq 65,535$

Operation

This command basically operates in the same way as the *s* command.

However, the *calr*, *calz* and *int* instructions, including all subroutines until control returns to the next address, are executed as one step.

Notes

- The step count must be specified within the range of 0 to 65,535. An error results if the limit is exceeded.
Error : Number of steps out of range, use 0-65535
- If the [Data] window is opened, its display contents are updated after the execution.
- During a single-step operation, the program will not break even if the break condition set by a command is met.
- Unlike in successive executions (*g* or *gr* command), the [Register] window is updated every time a step is executed.

GUI utility

[Run | Next] menu item, [Next] button

When this menu item or button is selected, the *n* command without step count is executed.

 [Next] button

8.9.8 CPU Reset

rst (reset CPU)

Function

This command resets the CPU.

Format

>rst␣ (direct input mode)

Notes

- The registers and flags are set as follows:

PC:	0110
A:	A
B:	A
X:	AAAA
Y:	AAAA
EICZ:	0000
SP1:	AA
SP2:	AA
EXT:	AA
QUEUE:	AAAA
- The execution cycle counter is cleared to 0.
- If the [Source] window is open, the window is redisplayed beginning with address 0x0110. If the [Register] window is open, the window is redisplayed with the above contents.
- The debug status, such as memory contents, breaks, and trace, is not reset.

GUI utility

[Run | Reset CPU] menu item, [Reset] button

When this menu item or button is selected, the *rst* command is executed.



[Reset] button

8.9.9 Break

bp (break point set)

Function

This command sets or clears breakpoints using a program's execution address.

Format

(1) >bp <break1> [<break2> [... <break16>]]↵ **(direct input mode)**

(2) >bp↵ **(guidance mode)**

PC break set status

1. set 2. clear 3. clear all ... ? <1 | 2 | 3>↵

..... (guidance depends on the above selection, see examples)

>

<break1-16>: Break address; hexadecimal or symbol (IEEE-695 format only)

Condition: 0 ≤ address ≤ last program memory address

Examples

Format (1)

>bp 116 200↵ ... Sets break points at addresses 0x0116 and 0x0200.
* The direct input mode cannot clear the set break points.

Format (2)

>bp↵ (Set)

No PC break is set.

1. set	2. clear	3. clear all	...? 1↵	... "1. set" is selected.
Set break address ? :	116↵			... Address 0x0116 is set as a breakpoint.
Set break address ? :	200↵			... Address 0x0200 is set as a breakpoint.
Set break address ? :	↵			... Terminated by [Enter] key.

>bp↵ (Clear)

1: 0116
2: 0200

1. set	2. clear	3. clear all	...? 2↵	... "2. clear" is selected.
Clear break address ? :	200↵			... Break address 0x0200 is cleared.
Clear break address ? :	↵			... Terminated by [Enter] key.

>bp↵ (Clear all)

1: 0116

1. set	2. clear	3. clear all	...? 3↵	... "3. clear all" is selected.
--------	----------	--------------	---------	---------------------------------

>bp↵

No PC break is set.

1. set	2. clear	3. clear all	...? ↵	... Terminated by [Enter] key.
--------	----------	--------------	--------	--------------------------------

>

Notes

- The addresses must be specified within the range of the program memory area available for each microcomputer model.

An error results if the input one is not a hexadecimal number or a valid symbol.

Error : invalid value (no such symbol / symbol type error)

An error results if the limit is exceeded.


Error : Address out of range, use 0-0xXXXX

- An error results if you attempt to clear an address that has not been set.
Error : Input address does not exist
- For direct input mode, an error results if you attempt to set breakpoints at more than 16 locations at a time. But for guidance mode, there is no such limitation, so you can specify more than 16 breakpoints before terminating the command by the [Enter] key.
- You can use this command for multiple times to set new breakpoints.

GUI utility

[Break | Breakpoint Set...] menu item

When this menu item is selected, a dialog box appears for setting breakpoints.



To set a breakpoint, select a [Set] button and enter an address in the text box corresponding to the selected button.

When setting more than four breakpoints, click the [Next] button to continue settings.

The [Previous] and [Next] buttons are used to view previous and subsequent four breakpoints.

To clear a breakpoint, select the [Clear] button of the address to be cleared.


The [Clear All Breakpoint] button clears all the set breakpoints

[Break] button

When this button is clicked after placing the cursor to a line in the [Source] window, the address at the cursor position is set as a breakpoint. If the address has been set as a breakpoint, this button clears the breakpoint.

 [Break] button

The set breakpoints are marked with a ● at the beginning of the address lines in the [Source] window.



bc / bpc (break point clear)

Function

This command clears the specified breakpoints that have been set.

Format

>bc [<break1> [. . .<break16>]] (direct input mode)
 <break1-16>: Break address; hexadecimal or symbol (IEEE-695 format only)

Examples

```
>bp
1: 0116          ... Breakpoints that have been set.
2: 0200
3: 0260
1. set  2. clear 3. clear all ...?
>bc 200
... Clears breakpoints at address 0x0200.
>bp
1: 0116
2: 0260
1. set  2. clear 3. clear all ...?
>bc
... Clears all breakpoints.
>bp
No PC break is set.
1. set  2. clear 3. clear all ...?
>
```

Notes

- The *bc* and *bpc* commands have the same functions.
- If no address parameter is specified, all the breakpoints that have been set are cleared.
- The format of parameters is same as the *bp* command. You can also use the guidance input mode of *bp* command to do the same operation.
- You can use this command for multiple times to clear breakpoints.
- An error results if an address that is not set at a breakpoint is specified.
 Error : Input address does not exist


GUI utility

[Break | Breakpoint Set ...] menu item

When this menu item is selected, a dialog box appears for clearing breakpoints. (See the *bp* command.)

[Break] button

When this button is clicked after placing the cursor to a break address line in the [Source] window, the breakpoint is cleared. If the address has not been set as a breakpoint, this button sets a new breakpoint at the address.



bd (data break)

Function

This command sets or clears data break. This command allows you to specify the following break conditions:

1. Memory address range to be read or written (one area)
2. Data pattern to be read or written (bit mask possible)
3. Memory read/write (three conditions: read, write, or read or write)

The program breaks after completing a memory access that satisfies the above conditions.

Format

(1) **>bd <data> <option> <address1> <address2>**↓ **(direct input mode)**

(2) **>bd**↓ **(guidance mode)**

Data break set status

1. set 2. clear ...? <1 | 2>↓ (Command is completed when "2" is selected.)

data *Old data* : <data>↓

R/W (R,W,*) *Old option* : <option>↓

Start address *Old address* : <address1>↓

End address *Old address* : <address2>↓

>

<data>: Data pattern; binary (* can be input for the bits to be masked)

<option>: Memory read/write option; r, w, or *

<address1-2>: The specified address; hexadecimal or symbol (IEEE-695 format only)

Condition: $0 \leq \text{address1} \leq \text{address2} \leq 0\text{xffff}$, $0 \leq \text{data} \leq 0\text{b1111}$

Examples

Format (1)

```
>bd 1000 W 0 f↓ ... Sets a data break condition so that the program breaks when 0x8 is written
to the address range from 0x0 to 0xf.
* The direct input mode cannot clear the set condition.
```

Format (2)

```
>bd↓
data: -      R/W: -  area:      -
1. set  2. clear ...? 1↓ ... "1. set" is selected.
data    ---- : 1***↓ ... Data pattern is set to 0b1***.
R/W (R,W,*) -  : w↓ ... R/W condition is set for write access.
Start address ---- : 0↓ ... Break address range is set to 0x0-0xf.
End address ---- : f
>bd↓
data: 1*** R/W: W  area: 0000 - 000F ... Currently set condition.
1. set  2. clear ...? 2↓ ... "2. clear" is selected.
>bd↓
data: -      R/W: -  area:      -
1. set  2. clear ...? ↓ ...Terminated by [Enter] key.
>
```

"*" in the binary data pattern specifies that the bit will not be compared with the actual read/write data.


Notes

- For the first time this command is executed, no item can be skipped because no default value is set.
- In guidance mode, the following keyboard inputs have special meaning:
 "q,_" ... Command is terminated. (finish inputting and start execution)
 "^,_" ... Return to previous item.
 ",_" ... Input is skipped. (keep current value)
 When the command is terminated in the middle of guidance by "q,_" , the contents that have been input up to that time will be modified. However, these contents will not be modified if some cleared settings are left intact.
- The addresses must be specified within the range of the data memory area available for each micro-computer model.
 An error results if the input one is not a hexadecimal number or a valid symbol.
 Error : invalid value (no such symbol / symbol type error)
 An error results if the limit is exceeded.
 Error : Address out of range, use 0-0xFFFF
- An error results if the start address in the address range is larger than the end address.
 Error : end address < start address
- Address and R/W specifications are effective even for 16-bit access (push/pop to and from SP1 stack). However, the data specification will not have any effect because data is compared with a 4-bit bus. In this case, specify data with "****". When setting a break for 4-bit access, be careful not to specify an address that overlaps the 16-bit access area, because such specification can cause the system to operate erratically.
- The data value can be input as a binary number with or without mask bits in the range of 4 bits (0 to 0xf). An error results if the limit is exceeded.
 Error : invalid data pattern
- An error results if you input the R/W option other than "r", "w" or "*".
 Error : Incorrect r/w option, use r/w/*
- The program stops one to two instructions after the break condition has been met.

GUI utility

[Break | Data Break ...] menu item

When this menu item is selected, a dialog box appears for setting a data break condition.



To set a data break condition, enter an address and a data pattern in the text box, and select R/W condition from the radio buttons. Then click [OK]. To clear the set data break condition, click [Clear].

bdc (data break clear)

Function

This command clears the data break condition that has been set.

Format

>bdc␣ (direct input mode)

GUI utility

[Break | Data Break ...] menu item

When this menu item is selected, a dialog box appears for clearing the set data break condition. (See the *bd* command.)

br (register break)

Function

This command sets or clears register break. This command allows you to specify data or a mask that constitutes a break condition for each register (A, B, F, X, and Y). The program will break when all setting conditions are met.

Format

(1) **>br <register> <value> [<register> <value> [...<register> <value>]]** (direct input mode)

(2) **>br** (guidance mode)

Register break set status

1. set 2. clear ...? <1 | 2> (Command is completed when "2" is selected.)

A Old value: <value>

B Old value: <value>

FE Old value: <value>

FI Old value: <value>

FC Old value: <value>

FZ Old value: <value>

X Old value: <value>

Y Old value: <value>

>

<register>: Register name; A, B, F, X or Y

<value>: Data pattern for the register; hexadecimal or binary (F register) (* can be used for the bits to be masked)

Examples

Format (1)

>br f **1* ... Sets a register break condition so that the program breaks when the C flag is set.

Format (2)

>br

A: - B: - X: - Y: - EICZ: -

1. set 2. clear ...? 1 ... "1. set" is selected.

A - : a ... Data 0xa is set for A register condition.

B - : * ... "*" masks the register condition.

FE - : * ...

FI - : * ...

FC - : 1 ...

FZ - : * ...

X - : 20 ...

Y - : ^ ... "^" returns guidance to previous setting.

X 20 : 60 ...

Y - : * ...

>br

A:a B:* X:60 Y:* EICZ:**1*

1. set 2. clear ...? 2 ... "2. clear" is selected.

>br

A: - B: - X: - Y: - EICZ: -

1. set 2. clear ...? ...Terminated by [Enter] key.

>

Notes


- For the first time this command is executed, no item can be skipped because no default value is set.
- In guidance mode, the following keyboard inputs have special meaning:
 - "q↵" ... Command is terminated. (finish inputting and start execution)
 - "^↵" ... Return to previous address.
 - "↵" ... Input is skipped. (keep current value)
 When the command is terminated in the middle of guidance by "q↵", the contents that have been input up to that time will be modified. However, these contents will not be modified if some cleared settings are left intact.
- An error results if you input the register name other than A, B, X, Y or F when using the direct input mode.


```
Error : Incorrect register name, use A/B/X/Y/F
```
- You can use the direct input mode to set register break condition at a time, or change one or several items for register break setting.
- The register value can be input as a binary number with or without mask bits or a hexadecimal number in the range of the bit width of each register. An error results if the limit is exceeded.


```
Error : invalid data pattern
```
- The program stops one to two instructions after the break condition has been met.

GUI utility**[Break | Register Break ...] menu item**

When this menu item is selected, a dialog box appears for setting register break conditions.



To set a register condition, select the radio button for the register and enter a value in the [Enter Value:] box, then click [Modify]. All the register condition must be set. Enter an "*" to exclude the register from the break condition.

When the [Apply] button is clicked, the dialog box closes and the register break is set with the specified conditions. However, if there is a register of which the condition has not been set (indicated with "---"), no register break condition is set.

To clear the register break conditions, click [Clear].

brc (register break clear)

Function

This command clears the register break conditions that have been set.

Format

>brc␣ (direct input mode)

GUI utility

[Break | Register Break ...] menu item

When this menu item is selected, a dialog box appears for clearing the register break conditions. (See the *br* command.)

bs (sequential break)**Function**

This command sets and clears sequential break and displays the sequential break condition that have been set.

This command allows you to set break addresses in up to three locations and the number of times you want the program to be executed at the last of the three addresses. While passing through all addresses sequentially in the order they are set, the program executes the last-specified address a specified number of times, then breaks after fetching the instruction from that address again.

Format

```
(1) >bs <pass> <address1> [<address2> [<address3>]]␣ (direct input mode)
(2) >bs␣ (guidance mode)
    Sequential break set status
    1. set  2. clear  ...? <1 | 2>␣ (Command is completed when "2" is selected.)
    Number of sequential address (1-3) ? : <1 | 2 | 3>␣
    Set address ? Old address : <address1>␣
    Set address ? Old address : <address2>␣
    Set address ? Old address : <address3>␣
    Pass count ? Old count : <pass>␣
    >
    <pass>: Pass count; decimal
    <address1-3>: Program execution address; hexadecimal or symbol (IEEE-695 format only)
    Condition: 0 ≤ address1-3 ≤ last program memory address, 0 ≤ pass ≤ 4095
```

Examples

Format (1)

```
>bs 3 116 120␣
```

... Sets two sequential addresses and the pass count. In this case, a break will occur when the CPU fetches the instruction at address 0x0120 after the instruction at address 0x0116 is executed and the instruction at address 0x0120 is executed three times.

Format (2)

```
>bs␣
1: -      2: -      3: -      pass: -
1. set  2. clear ...? 1␣ ... "1. set" is selected.
Number of sequential address (1-3) ? : 2␣ ... Number of addresses is input.
Set address ? : 116␣ ... 1st address is input.
Set address ? : 120␣ ... 2nd address is input.
Pass count ? : 3␣ ... Pass count is input.
>bs␣
1: 0116 2: 0120 3: -      pass:3
1. set  2. clear ...? 2␣ ... "2. clear" is selected.
>bs␣
1: -      2: -      3: -      pass: -
1. set  2. clear ...? ␣ ...Terminated by [Enter] key.
>
```

* If you press [Enter] in the middle of a guidance, the command is canceled.


Notes

- The maximum number of times a program can be executed is 4,095. Specifying a pass count exceeding this limit will result in an error.
Error : Number of passes out of range, use 0-4095
- The addresses must be specified within the range of the program memory area available for each microcomputer model.
An error results if the input one is not a hexadecimal number or a valid symbol.
Error : invalid value (no such symbol / symbol type error)
An error results if the limit is exceeded.
Error : Address out of range, use 0-0xFFFF

GUI utility

[Break | Sequential Break ...] menu item

When this menu item is selected, a dialog box appears for setting sequential break conditions.



To set a sequential break, enter sequential addresses and a pass count in the text boxes, then click [OK]. At least one address (Address 1) and the pass count must be set. To clear the sequential break condition, click [Clear].

bsc (sequential break clear)

Function

This command clears the sequential break condition that has been set.

Format

>bsc. (direct input mode)

GUI utility

[Break | Sequential Break ...] menu item

When this menu item is selected, a dialog box appears for clearing sequential break conditions. (See the *bs* command.)

bsp (break stack pointer)

Function

This command allows you to specify a stack area to generate a break for illegal stack access. A break occurs when stack operation is performed in locations other than the area specified by this command.

Format

(1) **>bsp <address1> <address2> <address3> <address4>↵** (direct input mode)

(2) **>bsp↵** (guidance mode)

Stack area set status

SP1 start address ? : <address1>↵

SP1 end address ? : <address2>↵

SP2 start address ? : <address3>↵

SP2 end address ? : <address4>↵

>

<address1>: SP1 start address; hexadecimal or symbol (IEEE-695 format only)

<address2>: SP1 end address; hexadecimal or symbol (IEEE-695 format only)

<address3>: SP2 start address; hexadecimal or symbol (IEEE-695 format only)

<address4>: SP2 end address; hexadecimal or symbol (IEEE-695 format only)

Condition: $0 \leq \text{address1(2)} \leq 0x03ff$, $0 \leq \text{address3(4)} \leq 0x00ff$

Examples

Format (1)

>bsp 0 3ff 0 ff↵ ... Sets SP1 area to 0x0–0x3FF and SP2 area to 0x0–0xFF.

Format (2)

>bsp↵

SP1 : 0000 - 03FF SP2 : 0000 - 00FF

SP1 start address ? : 0↵

... Address is input.

SP1 end address ? : 1ff↵

SP2 start address ? : 0↵

SP2 end address ? : ff↵

>bsp↵

SP1 : 0000 - 01FF SP2 : 0000 - 00FF

SP1 start address ? : ↵

... Terminated by [Enter] key.

>


* If you press only [Enter] in the middle of a guidance, the command is canceled.

Notes

- The stack area that is set by this command will not affect the stack operation performed in the program.
- Specify the SP1 address in the range of 0 to 0x3ff and the SP2 address in the range of 0 to 0xff. Entering an address exceeding this limit will result in an error.
 Error : SP1 address out of range, use 0-0x3FF
 Error : SP2 address out of range, use 0-0xFF
- Specify the SP1 address in units of 4 words (start address = multiple of 4; end address = multiple of 4 + 3).
- Due to the S1C63000 CPU's prefetch function, SP1 can access the top end of the actually used stack + 4 words. Depending on your system configuration, add 4 to the end address when you set it.
- The program stops one to two instructions after the break condition has been met.

GUI utility**[Break | Stack Break ...] menu item**

When this menu item is selected, a dialog box appears for setting stack areas.



To set stack areas, enter start and end addresses in the text boxes, then click [OK].

bl (break point list)**Function**

This command lists the current setting of all break conditions.

Format

>bl␣ (direct input mode)

Example

```
>bl␣
PC break:
  1: 0116
  2: 0200
Sequential break:
1: 0116 2: 0120 3: -      pass:3
Data break:
data: 1*** R/W: W area: 0000 - 000F
Register break:
A:* B:* X:* Y:* EICZ:**1*
Stack break:
SP1 : 0000 - 03FF   SP2 : 0000 - 00FF
>
```

GUI utility**[Break | Break List] menu item**

When this menu item is selected, the *bl* command is executed.

bac (break all clear)

Function

This command clears all break conditions set by the *bp*, *bd*, *br* and/or *bs* commands.

Format

>**bac**.**␣** (direct input mode)

GUI utility

[Break | Break All Clear] menu item

When this menu item is selected, the *bac* command is executed.

8.9.10 Program Display

U (unassemble)

Function

This command displays a program in the [Source] window after unassembling it. The display contents are as follows:

- Program memory address
- Object code
- Unassembled contents of the program

Format


>u [<address>]↵ (direct input mode)

<address>: Start address for display; hexadecimal or symbol (IEEE-695 format only)

Condition: 0 ≤ address ≤ last program memory address

Display

(1) When [Source] window is opened



If <address> is not specified, display in the [Source] window is changed to the unassemble display mode. If <address> is specified, display in the [Source] window is changed to the unassemble display mode. At the same time, code is displayed beginning with <address>.

(2) When [Source] window is closed

The 16 lines of unassembled result are displayed in the [Command] window. The system then waits for a command input.

If <address> is not specified, this display begins with the current PC (displayed in the [Register] window). If <address> is specified, the display begins with <address>.

```
>u↵
ADDR CODE UNASSEMBLE
0110 094B ldb %ba,0x4b
0111 1FC4 ldb %sp1,%ba
0112 091F ldb %ba,0x1f
0113 1FC6 ldb %sp2,%ba
: : :
011E 1FFF *nop
011F 1FFF *nop
>
```

(3) During log output

If the command execution result is being output to a log file as specified by the *log* command, code is displayed in the [Command] window and its contents are also output to the log file.

If the [Source] window is closed, the result is displayed in the same way as in (2) above.

If the [Source] window is opened, the window is redisplayed. In this case, the same number of lines is displayed in the [Command] window as displayed in the [Source] window.

(4) Successive display

If you execute the *u* command after entering it from the keyboard, code can be displayed successively by entering the [Enter] key only until some other command is executed.

When you press the [Enter] key, the [Source] window is scrolled forward one screen.

When displaying code in the [Command] window, 16 lines of code following the previously displayed address are displayed (the same number of lines as displayed in the [Source] window if the *u* command is executed during log output).

Note

The display start address you specified must be within the range of the program memory area available with each microcomputer model.

An error results if the input one is not a hexadecimal number or not a valid symbol.

Error : invalid value (no such symbol / symbol type error)

An error results if the limit is exceeded.

Error : Address out of range, use 0-0xFFFF

GUI utility**[View | Program | Unassemble] menu item, [Unassemble] button**

When this menu item or button is selected, the [Source] window opens or activates and displays the program from the current PC address.



[Unassemble] button

SC (source code)

Function

This command displays the contents of the program source file in the [Source] window. The display contents are as follows:

- Line number in the source file
- Source code

Format


>sc [<address>]↵ (direct input mode)

<address>: Start address for display; hexadecimal or symbol (IEEE-695 format only)

Condition: $0 \leq \text{address} \leq \text{last program memory address}$

Display

(1) When [Source] window is opened



If <address> is not specified, display in the [Source] window is changed to the source display mode. If <address> is specified, display in the [Source] window is changed to the source display mode. At the same time, code is displayed beginning with <address>.

(2) When [Source] window is closed

The 16 lines of source code are displayed in the [Command] window. The system then waits for a command input.

If <address> is not specified, this display begins with the current PC (displayed in the [Register] window). If <address> is specified, the display begins with <address>.

```
>sc↵
    ldb %ba,SP1_INIT_ADDR
    ldb %sp1,%ba           ; set SP1
    ldb %ba,SP2_INIT_ADDR
    ldb %sp2,%ba           ; set SP2
    calr INIT_RAM_BLK1     ; initialize RAM block 1
LOOP:
    ldb %ext,INC_RAM_BLK1@rh
    calr INC_RAM_BLK1@r1   ; increment RAM block 1
    ldb %ext,LOOP@rh
    jr  LOOP@r1           ; infinity loop
>
```

(3) During log output

If the command execution result is output to a log file as specified by the *log* command, code is displayed in the [Command] window and its contents are also output to the log file.

If the [Source] window is closed, code is displayed in the same way as in (2) above.

If the [Source] window is open, the window is redisplayed. In this case, the same number of lines is displayed in the [Command] window as displayed in the [Source] window.

(4) Successive display

If you execute the *sc* command after entering it from the keyboard, code can be displayed successively by entering the [Enter] key only until some other command is executed.

When you press the [Enter] key, the [Source] window is scrolled forward one screen.

When displaying code in the [Command] window, 16 lines of code following the previously displayed address are displayed (the same number of lines as displayed in the [Source] window if the *sc* command is executed during log output).

Notes

- Source codes can be displayed only when an absolute object file that contains source debug information has been loaded.
- The display start address you specified must be within the range of the program memory area available with each microcomputer model.

An error results if the input one is not a hexadecimal number or not a valid symbol.

Error : invalid value (no such symbol / symbol type error)

An error results if the limit is exceeded.

Error : Address out of range, use 0-0xXXXX

GUI utility**[View | Program | Source Display] menu item, [Source] button**

When this menu item or button is selected, the [Source] window opens or activates and displays the program from the current PC address.



[Source] button

m (mix)

Function

This command displays the unassembled result of the program and the contents of the program source file in the [Source] window. The display contents are as follows:

- Line number
- Program memory address
- Object code
- Unassembled contents of the program
- Source code

Format


>m [<address>] ↵ (direct input mode)

<address>: Start address for display; hexadecimal or symbol (IEEE-695 format only)

Condition: 0 ≤ address ≤ last program memory address

Display

(1) When [Source] window is opened



If <address> is not specified, display in the [Source] window is changed to the mix (unassemble & source) display mode. If <address> is specified, display in the [Source] window is changed to the mix (unassemble & source) display mode. At the same time, code is displayed beginning with <address>.

(2) When [Source] window is closed

The 16 lines of mix display are produced in the [Command] window. The system then waits for a command input.

If <address> is not specified, this display begins with the current PC (displayed in the [Register] window). If <address> is specified, the display begins with <address>.

```
>m↵
0110 094b  ldb  ba,4b                ldb  %ba,SP1_INIT_ADDR
0111 1fc4  ldb  sp1,ba                ldb  %sp1,%ba
0112 091f  ldb  ba,1f                ldb  %ba,SP2_INIT_ADDR
0113 1fc6  ldb  sp2,ba                ldb  %sp2,%ba
0114 08fe  ldb  ext,fe (+)          ldb  ext,fe
0115 02ea  calr ea                    calr  INIT_RAM_BLK1

                                LOOP:
0116 08fe  ldb  ext,fe (*)          ldb  %ext,INC_RAM_BLK1@rh
0117 02ef  calr ef                    calr  INC_RAM_BLK1@rl
                                (-)          ldb  %ext,LOOP@rh

:      :      :      :      :      :      :
```

(3) During log output

If the command execution result is output to a log file as specified by the *log* command, code is displayed in the [Command] window and its contents are output to the log file also.

If the [Source] window is closed, code is displayed in the same way as in (2) above.

If the [Source] window is open, the window is redisplayed. In this case, the same number of lines is displayed in the [Command] window as displayed in the [Source] window.

(4) Successive display

If you execute the *m* command after entering it from the keyboard, code can be displayed successively by entering the [Enter] key only until some other command is executed.

When you press the [Enter] key, the [Source] window is scrolled forward one screen.

When displaying code in the [Command] window, 16 lines of code following the previously displayed address are displayed (the same number of lines as displayed in the [Source] window if the *m* command is executed during log output).

Notes

- Source codes can be displayed only when an absolute object file that contains source debug information has been loaded.
- The display start address you specified must be within the range of the program memory area available with each microcomputer model.

An error results if the input one is not a hexadecimal number or not a valid symbol.

Error : invalid value (no such symbol / symbol type error)

An error results if the limit is exceeded.

Error : Address out of range, use 0-0xFFFF

GUI utility**[View | Program | Mix Mode] menu item, [Mix] button**

When this menu item or button is selected, the [Source] window opens or activates and displays the program from the current PC address.



[Mix] button

8.9.11 Symbol Information

SY (symbol list)

Function

This command displays a list of symbols in the [Command] window.

Format

- (1) >sy [/a]␣ **(direct input mode)**
- (2) >sy \$<keyword> [/a]␣ **(direct input mode)**
- (3) >sy #<keyword> [/a]␣ **(direct input mode)**

<keyword>: Search character string; ASCII character
 Condition: 0 ≤ length of keyword ≤ 32

Examples

Format (1)

```
>sy␣
INC_RAM_BLK1          0007
INIT_RAM_BLK1        0000
RAM_BLK0              0000
RAM_BLK1              0004
BOOT@C:\E0C63\TEST\MAIN.S 0110
LOOP@C:\E0C63\TEST\MAIN.S 0116
NMI@C:\E0C63\TEST\MAIN.S 0100
>
```

In format (1), all the defined symbols are displayed in alphabetical order. Global symbols are displayed first, then local symbols. Shown to right to each symbol is the address that is defined in it.

Format (2)

```
>sy $R␣
INC_RAM_BLK1          0007
INIT_RAM_BLK1        0000
RAM_BLK0              0000
RAM_BLK1              0004
>
```

In format (2), the debugger displays global symbols that contain the character string specified by <keyword>.

Format (3)

```
>sy #B␣
BOOT@C:\E0C63\TEST\MAIN.S 0110
>
```

In format (3), the debugger displays local symbols that contain the character string specified by <keyword>.

When local symbols are displayed, @ and the source file name in which the symbol is defined are added.

Notes

- The symbol list will be sorted by letter order if no option is added. If the option is added, the symbol list will be sorted by address.
- The symbol list can only be displayed when the object file in IEEE-695 format has been read.
- The specification of keyword conforms to which defined for assembler tools.

GUI utility

None

8.9.12 Load File

If (load file)

Function

This command loads an object file in IEEE-695 format into the debugger.

Format

(1) >lf <file name>␣ **(direct input mode)**

(2) >lf␣ **(guidance mode)**

File Name ? <file name>␣

>

<file name>: File name to be loaded (path can also be specified)

Examples

Format (1)

```
>lf test.abs␣
Loading file ... OK!
>
```

Format (2)

```
>lf␣
File name    ? test.abs
Loading file ... OK!
>
```

Notes

- An error results if the loaded file is linked with a different ICE parameter file than the one the debugger is using.
Error : Different chip type, cannot load this file
- Only an IEEE-695 format object file (generated by the linker) can be loaded by the *If* command.
- If you want to use source display and symbols when debugging a program, the object file must be in IEEE-695 format that contains debug information loaded into the computer.
- If the [Source] window is opened when loading a file, its contents are updated. The program contents are displayed from the current PC address.
- If an error occurs when loading a file, portions of the file that have already been read will remain in the emulation memory.


GUI utility

[File | Load File ...] menu item, [Load File] button

When this menu item or button is selected, a dialog box appears allowing selection of an object file to be loaded.



[Load File] button



lo (load option)

Function

This command loads a Motorola-S format program, data or option file listed below into the debugger.

File	Name specification
Program file	~.hsa (5 high-order bits), ~.lsa (8 low-order bits)
Data file*	~.csa
Function option data file	~.fsa
Segment option data file*	~.ssa
Melody data file*	~.msa

* Not used in some microcomputer models

Format

(1) >lo <file name>␣ (direct input mode)

(2) >lo␣ (guidance mode)

File Name ...? <file name>␣

>

<file name>: File name to be loaded (path can also be specified)

Examples

Format (1)

>lo test.lsa␣ ...Loads the program files test.lsa and test.hsa.

Loading file ... OK!

>

Format (2)

>lo␣ ...Loads a function option file.

File name ? test.fsa␣

Loading file ... OK!

>

Notes


- The debugger determines the file type based on the specified file name. Therefore, the debugger cannot load a file not following to the name specification listed above, and an error will result.
Error : invalid file name
- If an error occurs when loading a file, portions of the file that have already been read are left as they were loaded.

GUI utility

[File | Load Option ...] menu item, [Load Option] button

When this menu item or button is selected, a dialog box appears allowing selection of a hex file to be loaded.

 [Load Option] button



8.9.13 Flash Memory Operation

Note: The flash memory operation commands cannot be used when the USB ICE is used.

lfl (load from flash memory)

Function

This command loads the memory contents from the flash memory of the ICE into the target memory. It therefore allows you to debug the program beginning from the contents previously saved to the flash memory up to latest one.

Format

(1) >lfl <content> [... <content>] ↵ **(direct input mode)**

(2) >lfl ↵ **(guidance mode)**

```
Read program 1. yes 2. no ...? <1 | 2> ↵
data         1. yes 2. no ...? <1 | 2> ↵
fog          1. yes 2. no ...? <1 | 2> ↵
sog          1. yes 2. no ...? <1 | 2> ↵
mla          1. yes 2. no ...? <1 | 2> ↵
```

Loading ...

>

<content>: Data type; p (program) / d (data) / f (fog) / s (sog) / m (mla)

Examples

Format (1)

```
>lfl p ↵ ...Loads program data.
Loading from flash memory ... done!
```

Format (2)

```
>lfl ↵
Read program 1.yes 2.no ...? 1↵ ...Select the contents to be loaded.
data         1.yes 2.no ...? 1↵
fog          1.yes 2.no ...? 1↵
sog          1.yes 2.no ...? 1↵
mla          1.yes 2.no ...? 1↵
Loading from flash memory ... done!
>
```

Notes

- This command cannot be used when the USB ICE is used.
- If the flash memory is protected against read/write, an error will result and memory contents will not be loaded into the target memory.
Error : flash ROM is protected
- If the flash memory has been erased, an error will result and memory contents will not be loaded into the target memory.
Error : format error

- If the flash memory and target memory are mapped differently (e.g., the parameter file used in the current debug differs from one that was used when the program was saved to the flash memory), an error will result and memory contents will not be loaded into the target memory.

Error : Map information is not the same

In this case, the system displays the map information of the target memory and the flash memory after showing the message above.

	ICE	flash
Chip name	63A08	
Parameter version	02	00
Size of program	2000	0
data RAM	800	8000
data ROM	1000	7000
ext. memory	100	700
LCD	2C0	800
IO	20	20
FO	20	F0
SO1	0	1000
SO2	100	1000
MLA	510	1000


Redo the loading with the correct parameter file using the *efl* or *sfl* command.

- If an error occurs when loading data, portions of the data that have already been read into the target memory are left as they were loaded.

GUI utility

[File | Flash Memory Operation...] menu item

When this menu item is selected, a dialog box appears allowing selection of flash memory operations.



To execute the *lfl* command, select "Load from flash memory" from the [Operation] list box and select contents using the check boxes, then click [OK].

sfl (save to flash memory)

Function

This command writes the contents of the target memory in the ICE into the flash memory. Writing to the flash memory allows the ICE to be operated in free-run mode. Furthermore, the next debug session can be continued immediately from the current contents in the flash memory.

Format

(1) `>sfl <content> [... <content>] [-p]` (direct input mode)

(2) `>sfl` (guidance mode)

```
Protect flash memory 1.yes 2.no ...? <1 | 2>
Write program       1.yes 2.no ...? <1 | 2>
  data              1.yes 2.no ...? <1 | 2>
  fog               1.yes 2.no ...? <1 | 2>
  sog               1.yes 2.no ...? <1 | 2>
  mla               1.yes 2.no ...? <1 | 2>
```

Saving ...

>

<content>: Data type; p (program) / d (data) / f (fog) / s (sog) / m (mla)

-p: Protect option

Examples

Format (1)

```
>sfl p d f s m -p
```

...Saves all contents and sets protect.

Please wait few minutes

Save to flash memory ... done!

>

Format (2)

```
>sfl
```

```
Protect flash memory 1.yes 2.no ...? 1
```

... Protect is set.

```
Write program       1.yes 2.no ...? 1
```

... Write contents are selected.

```
  data              1.yes 2.no ...? 1
```

```
  fog               1.yes 2.no ...? 1
```

```
  sog               1.yes 2.no ...? 1
```

```
  mla               1.yes 2.no ...? 1
```

Please wait few minutes

Save to flash memory ... done!

>

- * If you enter only the [Enter] key in the middle of guidance, the guidance is terminated and only the area you have selected up to that time is written into the flash memory.

Notes

- This command cannot be used when the USB ICE is used.
- If the flash memory is write-protected, an error results and memory contents are not written to the flash memory.

Error : flash ROM is protected

The write-protect can be removed by erasing the flash memory with the *efl* command.

- If the flash memory has been erased, an error results, in which case you can choose to continue or stop processing.

```
Error : format error
Save with the map information,
or quit the command ? 1.save 2.quit ...? 1
Protect flash memory 1.yes 2.no ...?
```

- If the flash memory and target memory are mapped differently, an error results. In this case, the system displays the map information of the memory and a message prompting you to choose to continue or stop processing.


```
Error : Map information is not the same
ICE flash
-----
Chip name          63A08
Parameter version  02    00
Size of program    2000  0
  data RAM         800  8000
  data ROM         1000 7000
  ext. memory      100   700
  LCD              2C0   800
  IO               20   20
  FO               20   F0
  SO1              0   1000
  SO2             100  1000
  MLA             510  1000
Save with the map information,
or quit the command ? 1.save 2.quit ...? 1
Protect flash memory 1.yes 2.no ...?
```

- When shipped from the factory or erased by the *efl* command, all data in the flash memory is initialized to 0xff. When part of the data, such as a program, is written to the flash memory by the *sfl* command, all other data in it remains unchanged (= 0xff). In this condition, the ICE cannot be operated in free-run mode. To operate the ICE in free-run mode, always make sure that after erasing the flash memory, all the data has been written into the flash memory. In the ICE, furthermore, the default values for all option data are 0x00. Consequently, if you write to the flash memory before loading option data (*lo* command), the data you have written to the flash memory is overwritten by 0x00.

GUI utility

[File | Flash Memory Operation...] menu item

When this menu item is selected, a dialog box appears allowing selection of flash memory operations.



To execute the *sfl* command, select "Save to flash memory" from the [Operation] list box and select contents to be saved using the check boxes, then clock [OK]. The -p option can be specified using the [Protect flash memory] check box.

efl (erase flash memory)

Function

This command erases the contents of the ICE flash memory (including map information) and removes its protect function.

Format

efl␣ (direct input mode)

Example

```
>efl␣
Clear flash memory ... done!
>
```


Notes

- This command cannot be used when the USB ICE is used.
- When erased by the *efl* command, all data in the flash memory is initialized at 0xff. Even when part of the data, such as a program, is thereafter written to the flash memory by the *slf* command, all other data remains unchanged (= 0xff). In this condition, the ICE cannot be operated in free-run mode. In order for the ICE to be operated in free-run mode, always make sure that after erasing the flash memory, all the data has been written into the flash memory. In the ICE, furthermore, the default values for all option data are 0x00. Consequently, if you write to the flash memory before loading option data (*lo* command), the data you have written to the flash memory is overwritten by 0x00.

GUI utility

[File | Flash Memory Operation...] menu item

When this menu item is selected, a dialog box appears allowing selection of flash memory operations.



To execute the *efl* command, select "Erase flash memory" from the [Operation] list box and then click [OK].

8.9.14 Trace

tm (trace mode display/set)

Function

This command sets and displays a trace mode. It allows you to set the following three trace modes and a trace trigger point (when a specified address is executed, the TRGOUT pin outputs a pulse).

1. Normal trace mode
The data written to the trace memory is always the latest trace information.
2. Single-delay trigger trace mode
One of the following three trace sampling areas can be specified with respect to the trace trigger point:
 - Start: Trace information is a sample beginning from the trace trigger point.
 - Middle: Trace information is a sample from before and after the trace trigger point.
 - End: Trace information is a sample all the way up to the trace trigger point.
3. Address-area trace mode
The execution process is traced as instructions inside or outside a specified address range are executed. This address range can be specified in up to four locations.

Format

(1) >tm <mode> <trigger> [<option>] [<addr1> <addr2> [... <addr7> <addr8>]␣ (direct input mode)

(2) >tm␣ (guidance mode)

Current type setting

1. normal 2. single delay 3. address area ... ? <1 | 2 | 3>␣

Trigger address ? : <trigger>␣

..... (guidance depends on the above selection, see examples)

>

- <mode>: Trace mode; -n (normal), -s (single delay), or -a (address area)
- <trigger>: Trace trigger address; hexadecimal or symbol (IEEE-695 format only)
- <option>: For single-delay trace mode: s (start) / m (middle) / e (end)
For address-area trace mode: i (in area) / o (out area)
- <addr1-8>: Address ranges; hexadecimal or symbol (IEEE-695 format only)
- Condition: 0 ≤ trigger, addr1-8 ≤ last program memory address

Examples

Format (1)

```
>tm -n 116␣ ... Sets normal trace mode and sets trigger point to 0x0116.
```

Format (2)

```
>tm␣
Normal mode
Trigger Address : 0
1.normal 2.single delay 3.address area ...? 1␣ ... [1. normal] is selected.
Trigger address ? :116␣ ... Trigger address is input.
```

```
>tm␣
Normal mode
Trigger Address : 0116
1.normal 2.single delay 3.address area ...? 2␣ ... [2. single delay] is selected.
Trigger address ? :116␣ ... Trigger address is input.
1.start 2.middle 3.end ...? 2␣ ... Trace sampling area is selected.
>
```

```

>tm.↓
Single delay mode
Trigger Address : 0116
Position: Middle
1.normal  2.single delay  3.address area  ...? 3↓ ... [2. address area] is selected.
Trigger address ? :116↓ ... Trigger address is input.
1.in area  2.out area  ...? 1↓ ... In/out is selected.
Start address ? 110↓ ... Address range is input
End address ? 200↓ ... in up to 4 locations.
Start address ? ↓ ... Terminated by [Enter] key.
>

```

If you enter the [Enter] key only, the command will be canceled.

However, if more than one pair of addresses is specified after selecting the address-area trace mode (one pair of addresses is specified in the above example), the range of specified addresses will be set as the trace area.

Notes

- The trigger addresses set here are marked by the letter "T" at the beginning of the address lines displayed in the [Source] window.
- The address you specified must be within the range of the program memory area available with each microcomputer model.

An error results if the input one is not a hexadecimal number or not a valid symbol.

Error : invalid value (no such symbol / symbol type error)


An error results if the limit is exceeded.

Error : Address out of range, use 0-0xFFFF

GUI utility


[Trace | Trace Mode Set ...] menu item

When this menu item is selected, a dialog box appears allowing selection of a trace mode.




Normal trace mode

Select a trace mode using the radio button.
Enter addresses and/or select an option and then click [OK].



Single-delay trace mode



Address-area trace mode

td (trace data display)

Function

This command displays the trace information that has been sampled into the ICE trace memory.

Format

(1) >td [<cycle>]␣ (direct input mode)

(2) >td␣ (guidance mode)

Start point ? : (ENTER from the latest) <num>␣

(Trace data is displayed)

>

<cycle>: Start cycle number of trace data; decimal (from 0 to 8,191)

Display

The following lists the contents of trace information:

trace cycle: Trace cycle (decimal). The last information taken into the trace memory becomes 00001.

fetch addr: Fetch address (hexadecimal).

fetch code disasm: Fetch code (hexadecimal) and disassembled content.

register: Values of A, B, X, and Y registers after cycle execution (hexadecimal).

flag: States of E, I, C, and Z flags after cycle execution (binary).

data: Accessed data memory address (hexadecimal), read/write (denoted by r or w at the beginning of data), and data (1-digit hexadecimal for 4-bit access; 4-digit hexadecimal for 16-bit access).


SP: Stack access (1 for SP1 access; 2 for SP2 access).

trace in: Input to TRCIN pin (denoted by L when low-level signal is input).

(1) When [Trace] window is opened:

When the *td* command is input without <cycle>, the [Trace] window redisplay the latest data; when the *td* command is input with <cycle>, the trace data starting from <cycle> is displayed in the [Trace] window.

The display contents of the [Trace] window is updated after an execution of the target program. All trace data can be displayed by scrolling the window.



(2) When [Trace] window is closed:

When the *td* command is input without <cycle>, the debugger displays 11 lines of the latest trace data in the [Command] window. When the *td* command is input with <cycle>, the debugger displays 11 lines of the trace data from <cycle> in the [Command] window.

```
>td␣
Start point ?:(ENTER from the latest)␣
trace fetch      fetch          register      flag   data          trace
cycle addr  code disasm      A B X   Y   EICZ addr data  SP   in
00011 0118  00FD jr    0xfd          F 1 0007 AAAA 0000 012C rAAAA 1
00010 0116  08FE ldb  %ext,0xfe     F 1 0007 AAAA 0000 ---- --
00009 0117  02EF calr 0xef          F 1 0007 AAAA 1000 ---- --
00008 0007  0800 ldb  %ext,0x00     F 1 0007 AAAA 0000 0128 w0118 1
00007 0008  0A04 ldb  %x1,0x04     F 1 0007 AAAA 1000 ---- --
00006 0009  1911 add  [%x]+,0x01   F 1 0004 AAAA 0000 ---- --
00005 ----  ----  ----          F 1 0005 AAAA 0000 0004 rD
00004 000A  1990 adc  [%x]+,0x00   F 1 0005 AAAA 0000 0004 wE
00003 ----  ----  ----          F 1 0006 AAAA 0000 0005 r5
00002 000B  1990 adc  [%x]+,0x00   F 1 0006 AAAA 0000 0005 w5
00001 ----  ----  ----          F 1 0007 AAAA 0000 0006 rE
>td 10␣
trace fetch      fetch          register      flag   data          trace
cycle addr  code disasm      A B X   Y   EICZ addr data  SP   in
00020 0009  1911 add  [%x]+,0x01   F 1 0004 AAAA 0000 ---- --
00019 ----  ----  ----          F 1 0005 AAAA 0000 0004 rC
00018 000A  1990 adc  [%x]+,0x00   F 1 0005 AAAA 0000 0004 wD
00017 ----  ----  ----          F 1 0006 AAAA 0000 0005 r5
00016 000B  1990 adc  [%x]+,0x00   F 1 0006 AAAA 0000 0005 w5
00015 ----  ----  ----          F 1 0007 AAAA 0000 0006 rE
00014 000C  1980 adc  [%x],0x00    F 1 0007 AAAA 0000 0006 wE
00013 ----  ----  ----          F 1 0007 AAAA 0000 0007 r4
00012 000D  1FF8 ret          F 1 0007 AAAA 0000 0007 w4
00011 0118  00FD jr    0xfd          F 1 0007 AAAA 0000 012C rAAAA 1
00010 0116  08FE ldb  %ext,0xfe     F 1 0007 AAAA 0000 ---- --
>
```

(3) During log output

When the command execution result is being output to a log file as specified by the *log* command, the trace data is displayed in the [Command] window and its contents are also output to the log file.

If the [Trace] window is closed, data is displayed in the same way as in (2) above.

If the [Trace] window is open, its contents are redisplayed. In this case, the same number of lines are displayed in the [Command] window as displayed in the [Trace] window.

(4) Successive display

When you execute the *td* command, the trace data can be displayed successively by entering the [Enter] key only until some other command is executed.

When you input the [Enter] key, the [Trace] window is scrolled forward one screen.

When displaying data in the [Command] window, 11 lines of data preceding the previously displayed cycle are displayed in the [Command] window (the same number of lines as displayed in the [Trace] window if the command is executed during log output).

The direction of display is such that each time you input the [Enter] key, data on older execution cycles is displayed (FORWARD). This direction can be reversed (BACKWARD) by entering the [B] key. To return the display direction to FORWARD, input the [F] key. If the [Trace] window is open, the direction in which the window is scrolled is also changed.

```
>t d 100 ↵          ... Started display in FORWARD.  
                  (Data on cycle Nos. 110 to 100 is displayed.)  
>b ↵              ... Changed to BACKWARD.  
                  (Data on cycle Nos. 99 to 89 is displayed.)  
> ↵              ... Continued display in BACKWARD.  
                  (Data on cycle Nos. 88 to 78 is displayed.)  
>f ↵             ... Changed back to FORWARD.  
                  (Data on cycle Nos. 99 to 89 is displayed.)  
>
```

Notes

- Specify the trace cycle No. within the range of 0 to 8,191. An error results if this limit is exceeded.
Error : Address out of range, use 0-8191
- The trace memory receives new data until a break occurs. When the trace memory is filled, old data is overwritten by new data.
- For reasons of the ICE operation timing, the trace data at the boundary of operations, such as in the fetch cycle at which trace starts or the execution cycle at which trace ends, will not always be stored in memory.

GUI utility

[View | Trace] menu item

When this menu item is selected, the [Trace] window opens and displays the latest trace data.

ts (trace search)**Function**

This command searches trace information from the trace memory under a specified condition. The search condition can be selected from three available conditions:

1. Search by executed address
In this mode, you can specify a program memory address. The debugger searches the cycle in which the specified address is executed.
2. Search for a specified memory read cycle
In this mode, you can specify a data memory address. The debugger searches the cycle in which data is read from the specified address.
3. Search for a specified memory write cycle
In this mode, you can specify a data memory address. The debugger searches the cycle in which data is written to the specified address.

Format

(1) >ts <option> <address>␣ (direct input mode)

(2) >ts␣ (guidance mode)

1. pc address 2. data read address 3. data write address ...? <1 | 2 | 3>␣

Search address ? : <address>␣

(Search result is displayed)

>

<option>: Condition type (program address, data read address or data write address); pc/dr/dw

<address>: Search address; hexadecimal or symbol (IEEE-695 format only)

Display

The search results are displayed in the [Trace] window if it is opened; otherwise, the results are displayed in the [Command] window in the same way as for the *td* command.

Format (1)

```
>ts pc 116␣
```

```
Trace searching ... Done!
```

trace	fetch	fetch		register	flag	data	trace					
cycle	addr	code	disasm	A	B	X	Y	EICZ	addr	data	SP	in
00010	0116	08FE	ldb %ext,0xfe	F	1	0007	AAAA	0000	----	--		

Format (2)

```
>ts␣
```

```
1.pc address 2.data read address 3.data write address ...? 1␣
```

```
Search address ? :116␣
```

```
Trace searching ... Done!
```

trace	fetch	fetch		register	flag	data	trace					
cycle	addr	code	disasm	A	B	X	Y	EICZ	addr	data	SP	in
00010	0116	08FE	ldb %ext,0xfe	F	1	0007	AAAA	0000	----	--		

When command execution results are being output to a log file by the *log* command, the search results are displayed in the [Command] window as well as output to the log file even when the [Trace] window is opened.

Note

The address specified for search must be within the range of the program/data memory area available for each microcomputer model.

An error results if the input one is not a hexadecimal number or not a valid symbol.

Error : invalid value (no such symbol / symbol type error)

An error results if the limit is exceeded for program memory address.

Error : Address out of range, use 0-0xFFFF


An error results if the limit is exceeded for data memory address.

Error : Address out of range, use 0-0xFFFF

GUI utility

[Trace | Trace Search ...] menu item

When this menu item is selected, a dialog appears for setting a search condition.



Select a option using the radio button and enter an address in the text box, then click [OK].

tf (trace file)

Function

This command saves the specified range of the trace information displayed in the [Trace] window by the *td* or *ts* command to a file.

Format

(1) >tf [<cycle1> [<cycle2>]] <file name>␣ (direct input mode)

(2) >tf␣ (guidance mode)

Start cycle number (max 8191) ? : <cycle1>␣

End cycle number (min 0) ? : <cycle2>␣

File Name ? : <file name>␣

>

<cycle1>: Start cycle number; decimal (max 8,191)

<cycle2>: End cycle number; decimal (min 0)

<file name>: Output file name (path can also be specified)

Examples

Format (1)

```
>tf trace.trc␣ ... Saves all trace information extracted by the td command.
```

```
8191-8000
```

```
8000-7000
```

```
:
```

```
1000- 1
```

```
OK!
```

```
>
```

Format (2)

```
>tf␣
```

```
Start cycle number (max 8191) ? :1000␣
```

```
End cycle number (min 0) ? :1␣
```

```
File name ? :test.trc␣
```

```
1000- 1
```

```
OK!
```

```
>
```


Notes

- If an existing file is specified, the file is overwritten with the new data.
- The default value of <cycle1> is the last location, and the default value of <cycle2> is "1".

GUI utility

[Trace | Trace File ...] menu item

When this menu item is selected, a dialog box appears allowing specification of the parameters.



Enter a start cycle number, end cycle number and a file name, then click [OK].

To save all the trace information, leave the [Start cycle number] and [End cycle number] boxes blank.

The file name can be selected using a standard file selection dialog box that appears by clicking [Browse...].

8.9.15 Coverage

CV (coverage)

Function

This command displays coverage information (addresses where the program is executed). The coverage information is displayed in the [Command] window.

Format

>cv [<address1> [<address2>]] **(direct input mode)**

<address1>: Start address; hexadecimal or symbol (IEEE-695 format only)

<address2>: End address; hexadecimal or symbol (IEEE-695 format only)

Condition: $0 \leq \text{address1} \leq \text{address2} \leq \text{last program memory address}$

Examples

`>cv 100 1ff` ... Displays the executed addresses within the range from 0x100 to 0x1ff.

Coverage Information:

1: 0100..0102

2: 0110..0118

`>cv` ... Displays all the executed addresses.

Coverage Information:

1: 0000..000d

2: 0100..0102

3: 0110..0118

>

Notes

- If the *cv* command is input without <address1> and <address2>, coverage information in all address is displayed; if both <address1> and <address2> are specified, coverage information within the specified address range is displayed; if just <address1> is specified, the end address is treated as the maximum program address and coverage information within that range is displayed.
- The addresses specified here must be within the range of the program memory area available with each microcomputer model.
An error results if the input one is not a hexadecimal number or a valid symbol.
Error : invalid value (no such symbol / symbol type error)
An error results if the limit is exceeded.
Error : Address out of range, use 0-0xFFFF
- An error results if the start address is larger than the end address.
Error : end address < start address

GUI utility

None

CVC (coverage clear)

Function

This command clears the coverage information.

Format

>cvc␣ (direct input mode)

GUI utility

None

8.9.16 Command File

COM (execute command file)

Function

This command reads a command file and executes the debug commands written in that file. You can execute the commands successively, or set an interval between each command execution.

Format

(1) >com <file name> [<interval>]↵ (direct input mode)

(2) >com↵ (guidance mode)

File name ? <file name>↵

Execute commands 1. successively 2. with wait ...? <1 | 2>↵

Interval (0 - 256 seconds) : <interval>↵ (appears only when "2. With wait" is selected)

>(Display execution progress)

<file name>: Command file name (path can also be specified)

<interval>: Interval (wait seconds) between each command; decimal (0–256)

Examples

Format (1)

```
>com batch1.cmd↵
```

```
>.....           ... Commands in "batch1.com" are executed successively.
```

Format (2)

```
>com↵
```

```
File name ? test.cmd↵
```

```
Execute commands 1. successively 2. with wait ...? 2↵
```

```
Wait time (0 - 256 seconds) : 2↵
```

```
>.....           ... 2 sec. of interval is inserted after each command execution.
```


Notes

- Any contents other than commands cannot be written in the command file.
- An error results if the file you specified does not exist.
Error : Cannot open file
- Another command file can be read from a command file. However, the nesting of command files is limited to a maximum of 5 levels. An error results if a *com* (or *cmw*) command at the sixth level is encountered, the commands in the file specified by that *com* (or *cmw*) command will not be executed, but the subsequent execution of the commands in upper level files will be executed continuously.
Error : Maximum nesting level(5) is exceeded, cannot open file
- If you specify an interval more than 256 seconds, it is set to 256 by default.
- Use the hot key ([CTRL]+[Q]) to stop executing a command file.

GUI utility

[Run | Command File ...] menu item

When this menu item is selected, a dialog box appears allowing selection of a command file.



Enter an interval and a file name, then click [OK]. The file name can be selected using a standard file selection dialog box that appears by clicking [Browse...].

CMW (execute command file with wait)

Function

This command reads a command file and executes the debug commands written in that file at predetermined time intervals.

The execution interval of each command can be set in a range of 1 to 256 seconds (in 1-second increments) using the *md* command. In the initial debugger settings, the execution interval is 1 second.

Format

(1) >cmw <file name>␣ (direct input mode)

(2) >cmw␣ (guidance mode)

File name ? <file name>␣

>(Display execution progress)

<file name>: Command file name (path can also be specified)

Examples

Format (1)

```
>cmw batch1.cmd␣
```

```
>.....
```

Format (2)

```
>cmw␣
```

```
File name ? test.cmd␣
```

```
>.....
```

Notes

- Any contents other than commands cannot be written in the command file.
- An error results if the file you specified does not exist.
Error : Cannot open file
- Another command file can be read from a command file. However, the nesting of command files is limited to a maximum of 5 levels. An error results if a *cmw* (or *com*) command at the sixth level is encountered, the commands in the file specified by that *cmw* (or *com*) command will not be executed, but the subsequent execution of the commands in upper level files will be executed continuously.
Error : Maximum nesting level(5) is exceeded, cannot open file
- If the *cmw* command is written in the command file that you want to be read by the *com* command, all other commands following that command in the file (even when a *com* command is included) will be executed at predetermined time intervals.
- Use the hot key ([CTRL]+[Q]) to stop executing a command file.

GUI utility

None

However, the same function as the *cmw* can be executed using [Command File...] in the [Run] menu (see the *com* command).

REC (record commands to a file)

Function

This command records all debug commands following this command to a specified command file.

Format

(1) **>rec <file name>** (direct input mode)

(2) **>rec** (guidance mode) ...See Examples for guidance.

<file name>: Command file name (path can also be specified)

Examples

(1) First rec execution after debugger starts up

```
>rec
File name ? sample.cmd
1. append 2. clear and open ...? 2 ...Displayed If the file is already exists.
>
```

(2) "rec" command input in the second and following sessions

```
>rec
Set to record off mode. ...Record function toggles when rec is input.
.....
>rec
Set to record on mode.
```

Notes

- In record on mode, besides the commands directly input in the [Command] window, the commands executed by selecting from a menu or with a tool bar button (except the [Help] menu commands) are also displayed in the [Command] window, and output to the specified file. If you modify the register value or data memory contents by direct editing in the [Register] or [Data] window, or set breakpoints in the [Source] window by double-clicking the mouse, the corresponding commands are also displayed in the [Command] window, and output to the specified file.
- At the first time, you should specify the file name to which all debug commands following the *rec* command will be output.
- Once an output command file is opened, the recording is suspended and resumed (toggled) every time you input the *rec* command. This toggle operation remains effective until you terminate the debugger. If you want to record following commands to another file, you can use format (1) to specify the file name, then current output file is closed and all following commands will be recorded in the newly specified file.
- If you want to execute some commands frequently, you can record them to a file at the first execution, and then use the *com* or *cmw* command to execute that command file you made.

GUI utility

[Option | Record ...] menu item

When this menu item is selected, a standard file selection dialog box appears for specifying a command recording file. If the recording function has been activated, a dialog box appears allowing selection of either record-off mode or record-on mode. A new recording file can also be specified using the [New...] button.



8.9.17 log

log (log)**Function**

This command saves the input commands and the execution results to a file.

Format

(1) **>log <file name>** (direct input mode)

(2) **>log** (guidance mode) ...See Examples for guidance.

<file name>: Log file name (path can also be specified)

Examples**(1) First log execution after debugger starts up**

```
>log
File name ? debug1.log
1. append 2. clear and open ...? 2 ...Displayed If the file is already exists.
>
```

(2) "log" command input in the second and following sessions

```
>log
Set to log off mode. ...Logging function toggles when log is input.
.....
>log
Set to log on mode.
```

Notes

- In log on mode, the contents displayed in the [Command] window are written as displayed directly to the log file.

The commands executed by selecting from a menu or with a tool bar button are displayed in the [Command] window. However, the [Help] menu and button commands are not displayed. If you modify the register value or data memory contents by direct editing in the [Register] or [Data] window, or set breakpoints in the [Source] window by double-clicking the mouse, the corresponding commands and the execution results are also displayed in the [Command] window, and output to the specified file.


The displayed contents of the [Source], [Data], [Trace] or [Register] window produced by command execution are displayed in the [Command] window as well. The on-the-fly information is also displayed. However, the updated contents of each window after some execution, as well as the contents of each window scrolled by scroll bar or arrow keys, are not displayed.

- At the first time, you should specify the file name to which all following debug commands and execution results will be output.
- Once a log file is open, log output is suspended and resumed (toggled) every time you input the *log* command. This toggle operation remains effective until you terminate the debugger. If you want to specify a new log file, you can use format (1) to specify the file name, then current log file is closed and following commands and results will be output to the newly specified file.

GUI utility**[Option | Log ...] menu item**

When this menu item is selected, a standard file selection dialog box appears for specifying a log file.

If the logging function has been activated, a dialog box appears allowing selection of either log-off mode or log-on mode. A new log file can also be specified using the [New...] button.



8.9.18 Map Information

ma (map information)

Function

This command displays the map information that is set by a parameter file.

Format

>ma. (direct input mode)

Example

After the command is input, the system displays the chip name, version of the parameter file, and map information in each area. When you input the [Enter] key here, the system goes on and displays the map information in the I/O area and LCD area.

```

>ma.
Chip name           : 63A08
Parameter file version : 02
Program area       : 0000 - 1FFF
Data ram area      : 0000 - 07FF
Data rom area      : 8000 - 8FFF
LCD area           : F000 - F2BF
External memory area : F800 - F8FF
IO area            : FF00 - FFFF
Size of FO area    : 32
Size of SO1 area   : 0
Size of SO2 area   : 256
Size of MLA area   : 1296
>
IO Area
  01234567 89ABCDEF 01234567 89ABCDEF 01234567 89ABCDEF 01234567 89ABCDEF
FF00 mmmmm- -mmmm ---mmmmmm ----- -mmmm- -mmmm ----- mmmmmmmmm -----mm
FF40 -mmmm- -mmmm -mmmm- -mmmm -----mmmm ----- -mmmm ---- -mmmm -mmmm- -mmmm
FF80 mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm
FFC0 mmmmmmmmmmm ---- -mmmm ----- -mmmm ----- mmmmmmmmmmm ----- mmmmmmmmmmm -----
>
LCD Area
  01234567 89ABCDEF 01234567 89ABCDEF 01234567 89ABCDEF 01234567 89ABCDEF
F000 mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm
F040 mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm
F080 mmmmmmmmmmm mmmmmmmmmmm ----- -mmmm ----- -mmmm ----- -mmmm ----- -mmmm -----
F0C0 ----- -mmmm ----- -mmmm ----- -mmmm ----- -mmmm ----- -mmmm ----- -mmmm -----
F100 mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm
F140 mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm mmmmmmmmmmm
F180 mmmmmmmmmmm mmmmmmmmmmm ----- -mmmm ----- -mmmm ----- -mmmm ----- -mmmm -----
F1C0 ----- -mmmm ----- -mmmm ----- -mmmm ----- -mmmm ----- -mmmm ----- -mmmm -----
F200 -m-m-m-m -m-m-m-m -m-m-m-m -m-m-m-m -m-m-m-m -m-m-m-m -m-m-m-m -m-m-m-m
F240 -m-m-m-m -m-m-m-m -m-m-m-m -m-m-m-m -m-m-m-m -m-m-m-m -m-m-m-m -m-m-m-m
F280 -m-m-m-m -m-m-m-m ----- -mmmm ----- -mmmm ----- -mmmm ----- -mmmm -----
>

```

* When displaying the map information of the I/O and LCD areas, the mapped addresses are marked by the letter "m".

GUI utility

None

8.9.19 Mode Setting

md (mode)

Function

This command sets the debugger modes described below.

1. Displaying on-the-fly information

You can choose the display interval of the on-the-fly information from 0 to 5 (times) per second. When 0 is chosen, the on-the-fly information will not be displayed.

2. Measurement mode for the execution cycle counter

This mode can be selected from the actual execution-time measurement mode (indicated in microseconds) or the bus cycle mode (indicated in terms of the number of cycles executed).

3. Interrupt mode for step execution

You can choose to enable or disable interrupts during single-stepping.

4. Single-step display mode

You can choose to display the execution results of each step or only the last step during single-step operation. The register values are updated when their contents are displayed in the [Register] window; they are displayed in the [Command] window if the [Register] window is closed. If the [Source] window is open, the displayed lines are marked with an arrow as they are executed according to the setting of this mode.

5. Mode of execution cycle counter

This can be selected from hold mode or reset mode. In reset mode, the counter value is reset to 0 each time you enter a program execution command (including execution by the [Enter] key). The value of the execution cycle counter is also reset when you execute a *gr* command, switch this mode or the counter measurement mode, or execute an *rst* command.

6. Illegal instruction check mode

When loading a program file into the computer using the *lf* or *lo* command, you can choose whether or not you want illegal instructions to be checked. This check is disabled when rewriting the program memory with a *pe* or *pf* command.

7. cmw command wait time

A *cmw* command wait time can be set in the range of 1 to 256 seconds (in 1-second increments).

Default values of debugger modes

Mode	Default setting
On-the-fly function	Twice per second
Counter measurement mode	Bus cycle
Interrupt at stepping	Not allowed
Step display	Each step
Execution cycle counter reset	Hold
Illegal instruction check	Checked
cmw wait time	1 second

Format

```
(1) >md <option> <num> [ ... <option> <num>]␣      (direct input mode)
(2) >md␣                                             (guidance mode)
    Current settings
    On the fly interval  0 - 5 times/sec           ...? Current setting : <0 ... 5>␣
    Counter unit        1. time    2. cycle       ...? Current setting : <1 | 2>␣
    Interrupt at step   1. allowed  2. not allowed ...? Current setting : <1 | 2>␣
    Step display mode   1. each     2. last      ...? Current setting : <1 | 2>␣
    Counter mode        1. reset    2. hold      ...? Current setting : <1 | 2>␣
    Illegal instruction 1. check    2. no check ...? Current setting : <1 | 2>␣
    Cmw wait time       1 - 256 s      ...? Current setting : <1 ... 256>␣
>
    <option>:          <num>:
    -f (on the fly interval)  0-5 times/sec
    -u (counter unit)         1. Time    2. Cycle
    -i (interrupt at step)    1. Allowed  2. Not allowed
    -s (step display mode)    1. Each     2. Last
    -c (counter mode)         1. Reset    2. Hold
    -il (illegal instruction)  1. Check    2. No check
    -cm (cmw wait time)      1-256 sec
```

Examples

```
>md -u 1␣      ...Sets the execution cycle counter in time measurement mode.
>md␣
On the fly interval : 2 times/sec
Counter unit        : time
Interrupt at step   : not allowed
Step display mode   : each
Counter mode        : hold
Illegal instruction : check
Cmw wait time       : 1 s


On the fly interval 0 - 5 times/sec           ...? 2 times/sec : 5␣
Counter unit        1.time    2.cycle       ...? time           : 2␣
Interrupt at step   1.allowed  2.not allowed ...? not allowed    : 1␣
Step display mode   1.each     2.last      ...? each           : 2␣
Counter mode        1.reset    2.hold      ...? hold           : ␣
Illegal instruction 1.check    2.no check  ...? check          : ␣
Cmw wait time       1 - 256 s      ...? 1             s : 3␣
>
```

Notes

- The actual interval of the on-the-fly display is obtained from the expression below.
 $(1 \text{ [sec]} / \text{Count set}) + (\text{Overhead of the PC, RS-232C interface and ICE [sec]}) = \text{display interval [sec]}$
 The overhead varies depending on the performance of the PC and baud rate of the RS-232C interface. Be aware that there is a 0.05 sec to 0.1 sec overhead in this system.
- In guidance mode, the following keyboard inputs have special meaning:
 "q␣" ... Command is terminated. (finish inputting and start execution)
 "^␣" ... Return to previous item.
 "␣" ... Input is skipped. (keep current value)

GUI utility**[Option | Mode Setting...] menu item**

When this menu item is selected, a dialog box appears allowing selection of each mode.



Select the mode using the check boxes or enter the number interval settings, and then click [OK].

8.9.20 FPGA Operation

xfer/xfers (xilinx fpga data erase)

Function

This command erases the contents of the FPGA on the standard peripheral circuit board inserted in the ICE.

Format

>xfer↓ for main FPGA (direct input mode)
>xfers↓ for sub FPGA (direct input mode)

Example

```
>xfer↓  
>
```

After the command is entered, a dialog box appears to select start or cancel erasing.

Notes

- A dialog box appears to show the progress of erasing while executing. To abort erasing, click the [Cancel] button on the dialog box or press the [ESC] key. When the execution stops, the warning message shown below is displayed.

```
Warning : User cancel
```

In this case, the standard peripheral circuit board cannot be used until the FPGA is erased and reprogrammed.

- Erase time is about 2 minutes 40 seconds (max.) when the transfer rate between the ICE and PC is 38400 bps.
- Do not erase the sub FPGA unless otherwise specified, as it normally contains some LCD functions.

GUI utility

None

xfwr/xfwrs (xilinx fpga data write)

Function

This command writes peripheral circuit data to the FPGA on the standard peripheral circuit board inserted in the ICE.

Format

```
>xfwr <file name> ;{H | S} [;N]↵    for main FPGA    (direct input mode)
>xfwrs <file name> ;{H | S} [;N]↵    for sub FPGA     (direct input mode)
```

<file name>: FPGA data file (.mot: Motorola S, .mcs: Intel HEX)

H: Load Intel HEX file

S: Load Motorola S file

N: Skip erasing before writing data

Examples

```
>xfwr ..\ice\fpga\c63xxx.mot ;S↵
>
```

In this example, the main FPGA is erased and then data in the c63xxx.mot file (Motorola S format) is written to it.

```
>xfwr ..\ice\fpga\c63xxx.mot ;S ;N↵
>
```

In this example, erasing before writing is skipped. However, the main FPGA must be erased beforehand.

Notes

- Use the file provided by Seiko Epson as the data to be written without modifying the contents. Also the file extension cannot be changed as it is .mot (Motorola S) or .mcs (Intel HEX). Specifying an illegal file results in an error and data cannot be written.

```
Error : cannot open file
```

- The N option can be specified when the FPGA has been erased completely using the xfer/xfers command. When writing data to the FPGA that has not been erased, do not specify the N option.
- A dialog box appears to show the progress while executing. To abort execution, click the [Cancel] button on the dialog box or press the [ESC] key. When the execution stops, the warning message shown below is displayed.

```
Warning : User cancel
```

In this case, the standard peripheral circuit board cannot be used until the FPGA is erased and reprogrammed.

- Process time including erase is about 8 minutes (max.) when the transfer rate between the ICE and PC is 38400 bps.
- Do not write data to the sub FPGA unless otherwise specified, as it normally contains some LCD functions.

xfcp/xfcps (xilinx fpga data compare)

Function

This command compares the contents between the FPGA and the specified file.

Format

>xfcp <file name> ;{H | S}␣ for main FPGA (direct input mode)
 >xfcps <file name> ;{H | S}␣ for sub FPGA (direct input mode)

<file name>: FPGA data file (.mot: Motorola S, .mcs: Intel HEX)

H: Intel HEX file

S: Motorola S file

Examples

```
>xfcp ..\ice\fpga\c63xxx.mot ;S␣
>
...No error has occurred.

>xfcp ..\ice\fpga\c63yyy.mot ;S␣
Warning : Verify error
0X00000 0XFF
0X00001 0X84
0X00002 0XAB
:
:
>
```

...Verify error has occurred.
 ...Error addresses and data in the FPGA are displayed.

Notes

- Data is verified only within the valid address range in the specified file. If the FPGA contains data outside the range, it is not verified.
- Use the file provided by Seiko Epson as the data to be compared without modifying the contents. Also the file extension cannot be changed as it is .mot (Motorola S) or .mcs (Intel HEX). Specifying an illegal file results in an error and data cannot be written.
 Error : cannot open file
- A dialog box appears to show the progress while executing. To abort execution, click the [Cancel] button on the dialog box or press the [ESC] key. When the execution stops, the warning message shown below is displayed.
 Warning : User cancel

GUI utility

None

xdp/xdps (xilinx fpga data dump)

Function

This command displays the content of the FPGA on the standard peripheral circuit board to the [Command] window in a 16 words/line hexadecimal dump format.

Format

```
>xdp <address1> [<address2>]␣ for main FPGA (direct input mode)
>xdps <address1> [<address2>]␣ for sub FPGA (direct input mode)
<address1>: Start address to display; hexadecimal
<address2>: End address to display; hexadecimal
Condition: 0 ≤ address1 ≤ address2 ≤ FPGA end address
```

Examples

If only <address1> is defined, the debugger displays data for 256 words from <address1>.

```
>xdp 0␣
Addr   +0 +1 +2 +3 +4 +5 +6 +7 +8 +9 +A +B +C +D +E +F
00000: FF 84 AB EF F9 D8 FF BB FB BB BF FB BF BF FB BF
00010: BB FB BB BF BB BF FB BB BF BF FB BB FF EE FF EE
00020: EF FE D7 FB FE EE EF EF EE EE FE EE FB FE EF EF
      :           :
000E0: FF FF FF FF FB FF FF FF BD DF FB FD DF FF FF FF
000F0: FF FF BF FF FF FF FF F9 FF FF FF FF FF FF FF FF
>
```

If both <address1> and <address2> are defined, the debugger displays data from <address1> to <address2>.

```
>xdp 100 100␣
Addr   +0 +1 +2 +3 +4 +5 +6 +7 +8 +9 +A +B +C +D +E +F
00100: FF
>
```

Notes

- An error results if the specified address is not a hexadecimal number.
Error : invalid value
- An error results if the start address is larger than the end address.
Error : end address < start address

GUI utility

None

8.9.21 *Quit*

Q (quit)

Function

This command quits the debugger.

Format

>q↵ (direct input mode)

GUI utility

[File | Exit] menu item

Selecting this menu item terminates the debugger.

8.9.22 Help

? (help)

Function

This command displays the input format of each command.

Format

- (1) ? (direct input mode)
 (2) ? <n> (direct input mode)
 (3) ? <command> (direct input mode)

<n>: Command group number; decimal

<command>: Command name

Condition: $1 \leq n \leq 6$

Examples

When you input the command in Format 1 or 2, the system displays a list of commands classified by function. Use the command in Format 3 if you want to display the input format of each individual command.

```
>?␣
group 1: program, data & register . pe,pf,pm,a(as)/dd,de,df,dm,dw/od/rd,rs
group 2: execution & break ..... g,gr,s,n,rst/bp,bc(bpc),bd,bdc,br,brc,bs,bsc,bsp,bl,bac
group 3: source & symbol ..... u,sc,m/sy
group 4: file & flash rom ..... lf,lo/lfl,sfl,efl/xfer,xfers,xfwr,xfwrs,xfcp,xfcps,xdp,xdps
group 5: trace & coverage ..... tm,td,ts,tf/cv,cvc
group 6: others ..... com,cmw,rec,log/ma,mā,q,?
Type "? <group #>" to show group or type "? <command>" to get usage of the command
>? 1␣
group 1: program, data & register
pe (program enter), pf (program fill), pm (program move), a/as (inline assemble),
dd (data dump), de (data enter), df (data fill), dm (data move), dw (data watch),
od (option dump),
rd (register display), rs (register set)
Type "? <command>" to get usage of the command
>? pe␣
pe (program enter): change program memory
usage: pe [address] ... change program with guidance
       pe address code1 [... code8] ... change program with specified code
>
```

GUI utility

[Help | Contents...] menu item, [Help] button

When this menu item or button is selected, the [Help] window opens to show help topics.

 [Help] button

8.10 Status/Error/Warning Messages

1. ICE status messages

Status message	Content of message
Break by PC break	Break caused by PC breakpoint
Break by data break	Break caused by data break condition
Break by register break	Break caused by register break condition
Break by sequential break	Break caused by sequential break condition
Key Break	Break caused by pressing [ESC] key or [Key break] button
Break by accessing no map program area	Break caused by accessing undefined program-memory area
Break by accessing no map data area	Break caused by accessing undefined data-memory area
Break by accessing ROM area	Break caused by writing to data ROM area
Out of SP1 area	Break caused by accessing outside SP1 stack area
Out of SP2 area	Break caused by accessing outside SP2 stack area
Break by external break	Break caused by signal input to ICE BRKIN pin

2. ICE error messages

Error message	Content of message
communication error	Communication error other than time-out (overrun, framing, or BCC error)
CPU is running	Target is running.
ICE is busy	ICE is busy processing a job.
ICE is free run mode	ICE is operating in free-run mode.
ICE is maintenance mode	ICE is placed in maintenance mode.
no map area, XXXX	No-map area is specified for accessing.
not defined ID, XXXX	ICE respond ID is invalid.
on tracing	System is tracing execution data.
reset time out	CPU cannot be reset (for more than 1 second).
target down	Peripheral Circuit Board does not operate correctly or remains reset.
Time Out!	Communication time-out

3. Flash memory error messages

Error message	Content of message
flash memory error, XXXX	Writing or erasing flash memory has failed at XXXX.
flash ROM is protected	Flash memory is protected against access.
format error	Flash memory is not mapped.
Map information is not the same	Map information loaded from parameter file does not match that in the parameter file.
verify error, XXXX	Verify error has occurred when data was written to flash memory.

4. Command error/warning messages

Error message	Content of message (Commands involved)
Address out of range, use 0–0xFFFF	The specified program memory address is out of range. (a/as, pe, pf, pm, sc, m, u, g, gr, bp, bc, bs, tm, ts, cv)
Address out of range, use 0–0xFFFF	The specified data memory address is out of range. (dd, de, df, dm, dw, bd, ts)
Cannot load program/ROM data, check ABS file	Failed to load program/ROM data; some file other than IEEE-695 executable format was specified. (lf)
Cannot open file	The file cannot be opened. (lf, lo, com, cmw, log, rec, xfwr/xfwrs, xfcpx/xfcps)
Data out of range, use 0–0xF	The specified number is out of the data range. (de, df)
Different chip type, cannot load this file	A different ICE parameter is used in the file. (lf)
end address < start address	The start address is larger than the end address. (pf, pm, df, dm, bd, cv, xdp/xdps)
error file type (extension should be CMD)	The specified file extension is invalid. (com, cmw)
FO address out of range, use 0–0xEF	FO address is invalid. (od)
illegal code	The input code is not available. (pe, pf)
illegal mnemonic	The input mnemonic is invalid for S1C63000. (a/as)
Incorrect number of parameters	The parameter number is incorrect. (All commands)
Incorrect option, use -f/-u/-i/-s/-c/-il/-cm	An invalid mode setting option was specified. (md)
Incorrect r/w option, use r/w/*	An illegal R/W option was specified. (bd)
Incorrect register name, use A/B/X/Y/F	An invalid register name was specified. (br)

Error message	Content of message (Commands involved)
Incorrect register name, use PC/A/B/X/Y/F/SP1/SP2/EXT/Q	The specified register name is invalid. (rs)
Input address does not exist	Attempt is made to clear a break address that has not been set. (bp)
invalid command	This is an invalid command. (All commands)
invalid data pattern	The input data pattern is invalid. (bd, br)
invalid file name	The file name (extension) is invalid. (lo)
invalid value	The input data, address or symbol is invalid. (All commands)
Maximum nesting level(5) is exceeded, cannot open file	Nesting of the com/cmw command exceeds the limit. (com, cmw)
MLA address out of range, use 0–0xFFF	MLA address is invalid. (od)
no such symbol	There is no such symbol. (All symbol support commands)
no symbol information	No symbol information is available since the ".ABS" file has not been loaded. (sy)
Number of passes out of range, use 0–4095	The specified pass count for sequential break is out of range. (bs)
Number of steps out of range, use 0–65535	The specified step count is out of range. (s, n)
SO address out of range, use 0–0x1FFF	SO address is invalid. (od)
SP1 address out of range, use 0–0x3FF	The specified SP1 address is out of range. (bsp)
SP2 address out of range, use 0–0xFF	The specified SP2 address is out of range. (bsp)
symbol type error	The specified symbol type (program/data) is incorrect. (All symbol support commands)

Warning message	Content of message (Commands involved)
Break address already exists	Attempt is made to set an already-set break address. (bp)
Identical break address input	Input command contains identical address.
round down to multiple of 4	Watch data address is invalid. (dw)
User cancel	Command is aborted by the user. (xfer/xfers, xfwr/xfwrs, xfcp/xfcps)
Verify error	FPGA verify error. (xfcp/xfcps)

8.11 Precautions

For the restrictions, support functions and bug information of the latest version, refer to rel_debug_E.txt of S5U1C63000A.

For the models supported by the latest version, refer to Readme_E.txt of S5U1C63000A.

CHAPTER 9 FUNCTION OPTION GENERATOR

9.1 Outline of the Function Option Generator winfog

The S1C63 chip allows several hardware specifications such as I/O port functions to be selected as mask options. This helps you to configure the hardware of your product by changing the S1C63 chip's mask patterns according to its specifications.

The Function Option Generator winfog is the software tool for creating the files necessary to generate mask patterns. Its graphical user interface (GUI) ensures easy selection mask options. From the files created by winfog, Seiko Epson produces the mask patterns for the S1C63 chip.

In addition, simultaneously with this file, winfog can create mask option setup files (Motorola S2 format data) that are required when debugging programs with the ICE. When using the ICE to debug a program, you can download this file from the host computer, making it possible to materialize optional functions on the ICE that are equivalent to those on the actual IC.

9.2 Input/output Files

Figure 9.2.1 shows the input/output files of winfog.




Fig. 9.2.1 Input/Output Files of winfog

Device information definition file (s1c63xxx.ini)

This file contains option lists for various types of microcomputers and other information. Always be sure to use the files presented by Seiko Epson. This file is effective for only the type of microcomputer indicated by the file name. Do not modify the contents of the file or use the file in other types of microcomputers.

Function option document file (zzzzzzzz.fdc)

This is a text format file in which the contents of selected mask options are stored. You can read this file into winfog and correct the already selected option settings. This file is packed along with completed other program/data files into a single file by the mask data checker winmdc, which we would like to have presented to Seiko Epson as the mask data file. From this file, Seiko Epson will create the mask patterns for the IC.

Function option HEX file (zzzzzzzz.fsa)

This is the Motorola S2 format file necessary to set the selected mask options in the ICE. When you debug programs with the ICE, download this file into the ICE using debugger commands.

- *1 The "xxx" in the file name denotes the model name of a microcomputer. For the "zzzzzzzz" part, any given file name can be specified.
- *2 For details on how to download mask options into the ICE, refer to Chapter 8, "Debugger".

9.3 Using winfog

9.3.1 Starting Up

Startup from Explorer



Double-click on the winfog.exe icon or select winfog from the start menu.

If the device information definition file (s1c63xxx.ini) was loaded into your computer during previous execution, winfog automatically reads the same file as it starts.

Alternatively, drag the Device information definition file icon into the winfog.exe icon to start winfog, which will then read the Device information definition file.

Startup by command input


You can also start winfog from the command prompt by entering the command shown below.

```
>winfog [s1c63xxx.ini] ↵
```


↵ denotes entering the return key.

You can specify the device information definition file (s1c63xxx.ini) as a command option. (You can also specify a path.) When you specify the device information definition file here, winfog reads it as it starts. This specification can be omitted.

When winfog starts, it displays the [FOG] window. The following diagrams show a [FOG] window when the device information definition file has been loaded and when it has not.




[FOG] Window (initial screen)



[FOG] Window (after reading the device information definition file)

9.3.2 Window



- * The microcomputer model name on the title bar is the file name (not including the path and extension) of the device information definition file that has been read.
- * The option list and the function option document vary with each type of microcomputer.

Fig. 9.3.2.1 Window Configuration

The [FOG] window is divided into three areas as shown above.

Option list area

Lists mask options set in the device information definition file (s1c63xxx.ini). Use the check boxes in this area to select each option. A selected option has its check box marked by ✓.

Function option document area

Displays the contents of selected options in the function option document format. The contents displayed in this area are output to the function option document file. When you change any selected item in the option list area, the display in this area is immediately updated.

Message area

When you create a file by selecting [Generate] from the [Tool] menu or clicking the [Generate] button, this area displays a message showing the result of the selected operation.

9.3.3 Menus and Toolbar Buttons

This section explains each menu item and toolbar button.

[File] menu



Open

Opens a function option document file. Use this menu command when correcting an existing file. The [Open] button has the same function.



[Open] button

End

Terminates winfog.

[Tool] menu



Generate

Creates a file according to the selected contents of the option list. The [Generate] button has the same function.



[Generate] button

Setup

Sets the date of creation, output file name and a comment included in the function option document file. The [Setup] button has the same function.



[Setup] button


Device INI Select

Loads the device information definition file (s1c63xxx.ini). The [Device INI Select] button has the same function. This file must be loaded first before performing any operation with winfog.



[Device INI Select] button

[Help] menu




Version

Displays the version of winfog. The [Help] button has the same function.



[Help] button

The dialog box shown below appears. Click [OK] to close this dialog box.



9.3.4 Operation Procedure


The following shows the basic operation procedure.

(1) Loading the device information definition file

First, select a device information definition file (s1c63xxx.ini) and load it. Select [Device INI Select] from the [Tool] menu or click the [Device INI Select] button.



The dialog box shown below appears. Enter a file name including the path in the text box or select a file by clicking the [Ref] button.



Click [OK], and the file is loaded. If the specified file exists and there is no problem with its contents, the option list and the function option document, which have both been set by default, are displayed in each area.


To stop loading the file, click [Cancel].

Once a device information definition file is selected, the same file is automatically loaded the next time you start winfog.

Note: When you load a device information definition file after setting up options, all settings are reset to the default state.

(2) Setup

Select [Setup] from the [Tool] menu or click the [Setup] button to bring up the [Setup] dialog box. From this dialog box, select items and enter data.



Date

Displays the current date. Change it as necessary.

Function Option Document file

Specify the function option document file name you want to create. The file name displayed by default can be modified. You can use the [Ref] button to look at other folders.

Function Option HEX

Do you make hex file?

Select whether to create a function option HEX file. You need to create one when you use the ICE to debug programs.

Function Option HEX file

When you create a function option HEX file, specify its file name here. The file name displayed by default can be modified. You can use the [Ref] button to look at other folders.

EPROM Type

This option is not available for S1C63 Family microcomputers.

User's Name

Enter your company name. Up to 40 characters can be entered. You can use English letters, numbers, symbols, and spaces. The content entered here is recorded in the USER'S NAME field of the function option document file.

Comment

Enter a comment. Up to 50 characters can be entered in one line. You can enter up to 10 lines. You can use English letters, numbers, symbols, and spaces. Use the [Enter] key to create a new line. All comments should include the following information:

- Place of business, your department or section
- Address, telephone number, and facsimile number
- Other: Technical information, etc.

The content entered here is recorded in the COMMENT field of the function option document file. When you have finished entering the above necessary items, click [OK]. The setup contents are saved, and the dialog box is closed. The setup contents take effect immediately. If you click [Cancel], current settings will not be changed and the dialog box is closed.

Notes: • *File name specification is subject to the following limitations:*

1. *The number of characters that can be used to specify a file name including the path is 2,048.*
2. *The file name itself (not including the extension) can be up to 15 characters, and the extension up to three characters.*
3. *The file name cannot begin with a hyphen (-), nor can the following symbols be used as part of directory names (folder names), file names, and extensions:*

*/ : , ; * ? " < > |*

- *The symbols shown below cannot be used in the User's Name and Comment:*
\$ \ | `

(3) Selecting options

Select necessary options by clicking the corresponding check boxes in the option list. When you change any selection item in the option list area, the display in the function option document area is updated. Note that when you have loaded the device information definition file, the option list is placed in its default selection state.

For details about option specifications, refer to the Technical Manual available for each type of microcomputer.

(4) Creating files

After selecting options, select [Generate] from the [Tool] menu or click the [Generate] button to create the files.



[Generate] button


The function option document file you specified from the [Setup] dialog box and the function option HEX file (if specified) are created. When winfog has finished creating the files normally, it displays the message "Making file(s) is completed" in the message area. If an error occurs, an error message is displayed.

(5) Correcting an existing document file

You can read an existing function option document file into winfog and correct it as necessary. To read a file, select [Open] from the [File] menu or click the [Open] button.



The dialog box shown below appears, so enter a file name including the path in the text box or select a file by clicking the [Ref] button.



Click [OK], and the file is loaded. If the specified file exists and there is no problem with its contents, the option list and the function option document areas are updated according to the contents of the file. To stop loading the file, click [Cancel].

Perform steps (2) to (4) to update the file.

If you select [Generate] without changing the file name, the message shown below is displayed asking you whether or not to overwrite the file. Click [Yes] to overwrite or [No] or [Cancel] to stop overwriting. Use the [Setup] dialog box to change the file name.



Note: The function option document file can be read only when the device information definition file has been loaded.

(6) Quitting

To terminate winfog, select [End] from the [File] menu.

9.4 Error Messages

The error messages of winfog are listed below. The "Dialog" in the Display column means that messages are displayed in the dialog box, and "Message" means that messages are displayed in the [FOG] window message area.

Table 9.4.1 List of winfog Error Messages

Message	Description	Display
File name error	Number of characters in the file name or extension exceeds the limit.	Dialog
Illegal character	Prohibited characters have been entered.	Dialog
Please input file name	File name has not been entered.	Dialog
Can't open File : xxxx	File (xxxx) cannot be opened.	Dialog
INI file is not found	Specified device information definition file (.ini) does not exist.	Dialog
INI file does not include FOG information	Specified device information definition file (.ini) does not contain function option information.	Dialog
Function Option document file is not found	Specified function option document file does not exist.	Dialog
Function Option document file does not match INI file	Contents of the specified function option document file do not match device information definition file (.ini).	Dialog
A lot of parameter	Too many command line parameters are specified.	Dialog
Making file(s) is completed [xxxx is no data exist]	Finished creating the file, but the created file (xxxx) does not contain any data.	Message
Can't open File: xxxx Making file(s) is not completed	File (xxxx) cannot be opened when executing Generate.	Message
Can't write File: xxxx Making file(s) is not completed	File (xxxx) cannot be written when executing Generate.	Message

Table 9.4.2 winfog Warning Messages

Message	Description	Display
Are you file update? xxxx is already exist	Overwrite confirmation message (Specified file already exists.)	Dialog

9.5 Precautions

(1) winfog does not support Japanese (2-byte) characters. Do not use Japanese characters for path or file names.

For the restrictions, support functions and bug information of the latest version, refer to rel_windev_E.txt of S5U1C63000A.

For the models supported by the latest version, refer to Readme_E.txt of S5U1C63000A.

9.6 Example Output Files

Note: Option and other configurations vary with each type of microcomputer.

Example of a function option document file

```

* S1C63xxx FUNCTION OPTION DOCUMENT Vx.xx      ← Version
*
* FILE NAME      zzzzzzzz.FDC                  ← File name (specified by [Setup])
* USER'S NAME   SEIKO EPSON CORPORATION       ← User name (specified by [Setup])
* INPUT DATE    yyyy/mm/dd                    ← Date of creation (specified by [Setup])
* COMMENT       SAMPLE DATA                  ← Comment (specified by [Setup])
*
* *** OPTION NO.1 ***                          ← Option number
* --- OSC1 SYSTEM CLOCK ---                   ← Option name
* Crystal(32.768KHz) ---- Selected           ← Selected specification
OPT0101 01                                    ← Mask data
*
* *** OPTION NO.2 ***
* --- OSC3 SYSTEM CLOCK ---
* CR 200KHz ---- Selected
OPT0201 01
*
* *** OPTION NO.3 ***
* --- INPUT PORT PULL UP RESISTOR ---
* K00 With Resistor ---- Selected
* K01 With Resistor ---- Selected
* K02 With Resistor ---- Selected
* K03 With Resistor ---- Selected
* K10 With Resistor ---- Selected
* K11 With Resistor ---- Selected
* K12 With Resistor ---- Selected
* K13 With Resistor ---- Selected
OPT0301 01
OPT0302 01
OPT0303 01
OPT0304 01
OPT0305 01
OPT0306 01
OPT0307 01
OPT0308 01
*
* *** OPTION NO.4 ***
* --- OUTPUT PORT OUTPUT SPECIFICATION ---
* R00 Complementary ---- Selected
* R01 Complementary ---- Selected
* R02 Complementary ---- Selected
* R03 Complementary ---- Selected
OPT0401 01
OPT0402 01
OPT0403 01
OPT0404 01
*
      :
*
* *** OPTION NO.8 ***
* --- SOUND GENERATOR POLARITY ---
* NEGATIVE ---- Selected
OPT0801 01
* EOF                                          ← End mark

```

Example of a function option HEX file (Motorola S2 format)

```

S22400000022FF0200FFFFFFFFFFFFFFFFFFFFFFFF000000000000FFFFFFFFFFFFFFFFFC
S804000000FB

```

For details about the Motorola S2 format, refer to Section 6.5.2, "Motorola S format".

CHAPTER 10 SEGMENT OPTION GENERATOR

10.1 Outline of Segment Option Generator winsog

Some types of microcomputers in the S1C63 Family allow the LCD output pin output specifications and LCD output pin assignments to be set with hardware options, so that mask patterns for the IC are generated according to option settings. The Segment Option Generator winsog is the software tool for creating the files required to generate mask patterns. Its graphical user interface (GUI) ensures simple mask option setting.

In addition, simultaneously with this file, winsog can create mask option setup files (Motorola S2 format data) that are required when debugging programs with the ICE. When using the ICE to debug a program, you can download this file from the host computer, making it possible to realize optional functions on the ICE that are equivalent to those on the actual IC.

Note: The Segment Option Generator winsog is provided for only certain types of microcomputers that have set segment options.

10.2 Input/output Files

Figure 10.2.1 shows the input/output files of winsog.




Fig. 10.2.1 Input/Output Files of winsog

Device information definition file (s1c63xxx.ini)

This file contains option lists for various types of microcomputers and other information. Always be sure to use the files presented by Seiko Epson. This file is effective for only the type of microcomputer indicated by the file name. Do not modify the contents of the file or use the file in other types of microcomputers.

Function option document file (zzzzzzzz.fdc)

This is the text format file generated by winfog and contains the selected mask options. This file is required only when the segment option setup condition depends on the mask option selected with winfog.

Segment option document file (zzzzzzzz.sdc)

This is a text format file in which setup contents of segment options are stored. You can read this file into winsog and correct the option settings. This file is packed along with completed other program/data files into a single file by the mask data checker winmdc, which will be presented to Seiko Epson as the mask data file. From this file, Seiko Epson will create the mask patterns for the IC.

Segment option HEX file (zzzzzzzz.ssa)

This is the Motorola S2 format file necessary to set the selected segment options in the ICE. When you debug programs with the ICE, download this file into the ICE using debugger db63 commands.

Segment assignment data file (zzzzzzzz.sad)

This is a text format file in which segment assignment data is stored. Create this file when terminating winsog before finishing segment assignment. You can continue option setting next time by loading this file to winsog.

- *1 The "xxx" in the file name denotes the model name of a microcomputer. For the "zzzzzzzz" part, any given file name can be specified.
- *2 For details on how to download mask options into the ICE, refer to Chapter 8, "Debugger".

10.3 Using winsog

10.3.1 Starting Up

Startup from Explorer



Double-click on the winsog.exe icon or select winsog from the start menu.

If the device information definition file (s1c63xxx.ini) was loaded into your computer during previous execution, winsog automatically reads the same file as it starts.

Alternatively, drag the device information definition file icon into the winsog.exe icon to start winsog, which will then read the device information definition file. If a function option document file is required for setting the segment option, a dialog box will appear to allow file selection. In this case enter the file name including the path in the text box or choose the file from the dialog box that appears by clicking on the [Ref] button.

Startup by command input


You can also start winsog from the command prompt by entering the command shown below.

```
>winsog [s1c63xxx.ini] ↵
```


↵ denotes entering the return key.

You can specify the device information definition file (s1c63xxx.ini) as a command option. (You can also specify a path.) When you specify the device information definition file here, winsog reads it as it starts. If a function option document file is required for setting the segment option, the file (zzzzzzzz.fdc) must be prepared in the directory in which s1c63xxx.ini and winsog.exe exist before entering the command. When the command is entered, a dialog box will appear to allow file selection. Enter the file name including the path in the text box or choose the file from the dialog box that appears by clicking on the [Ref] button. This specification can be omitted.

When winsog starts, it displays the [SOG] window. The following diagrams show a [SOG] window when the device information definition file has been loaded and when it has not.




[SOG] Window (initial screen)



[SOG] Window (after reading the device information definition file)

10.3.2 Window



- * The microcomputer model name on the title bar is the file name (not including the path and extension) of the device information definition file that has been read.
- * The display memory addresses and segment configuration vary with each type of microcomputer.

Fig. 10.3.2.1 Window Configuration

The [SOG] window is divided into two areas as shown above.

Option setup area

Comprised of a display memory map, a segment decode table, and buttons to select pin specifications. By clicking on cells in the display memory map and segment decode table, you can assign display memory addresses and bits.


Message area

When you create a file by selecting [Generate] from the [Tool] menu or clicking the [Generate] button, this area displays a message showing the result of the selected operation.

10.3.3 Menus and Toolbar Buttons

This section explains each menu item and toolbar button.

[File] menu



Open

Opens a segment option document file. Use this menu command when correcting an existing file. The [Open] button has the same function.



Record - Save

Saves the current option settings to a file (segment assignment data file). The [Save] button has the same function.



Record - Load


Loads a segment assignment data file. The [Load] button has the same function.



End


Terminates winsog.

[Tool] menu



Generate

Creates a file according to the contents of segment options set. The [Generate] button has the same function.



Setup

Sets the date of creation or output file name or a comment included in the segment option document file. The [Setup] button has the same function.




Device INI Select

Loads the device information definition file (s1c63xxx.ini). The [Device INI Select] button has the same function. This file must be loaded first before performing any operation with winsog.



[Help] menu




Version

Displays the version of winsog. The [Help] button has the same function.



The dialog box shown below appears. Click [OK] to close this dialog box.



10.3.4 Option Selection Buttons

The following buttons are available in the option setup area.

OUTPUT Option buttons

These buttons select SEG pin output modes. These buttons are enabled when you click a SPEC cell in [SEGMENT DECODE TABLE].

-  Selects LCD segment output.
-  Selects DC-complementary output.
-  Selects DC-Pch open-drain output.
-  Selects DC-Nch open-drain output.
-  Selects segment/common shared output.

[Delete] button

-  Clears one selected segment assignment.

10.3.5 Operation Procedure

The following shows the basic operation procedure.

(1) Loading the device information definition file

First, select a device information definition file (s1c63xxx.ini) and load it. Select [Device INI Select] from the [Tool] menu or click the [Device INI Select] button.



[Device INI Select] button


The dialog box shown below appears. Enter a file name including the path in the text box or select a file by clicking the [Ref] button.



Click [OK], and the file is loaded. If the specified file exists and there is no problem with its contents, the set-up items in winsog are initialized with the loaded device information. To stop loading the file, click [Cancel].

Once a device information definition file is selected, the same file is automatically loaded the next time you start winfog.

If a function option document file is required for setting the segment option, the dialog box shown below will appear to allow file selection. In this case enter the file name including the path in the text box or choose the file from the dialog box that appears by clicking on the [Ref] button.




Note: When you load a device information definition file after setting up options, all settings are reset to the default state.

(2) Setup

Select [Setup] from the [Tool] menu or click the [Setup] button to bring up the [Setup] dialog box. From this dialog box, select items and enter data.



[Setup] button



Date

Displays the current date. Change it as necessary.

Segment Option Document file

Specify the segment option document file name you want to create. The file name displayed by default can be modified. You can use the [Ref] button to look at other folders.

Segment Option HEX

Do you make hex file?

Select whether to create a segment option HEX file. You need to create one when you use the ICE to debug programs.

Segment Options HEX file

When you create a segment option HEX file, specify its file name here. The file name displayed by default can be modified. You can use the [Ref] button to look at other folders.

EPROM Type

This option is not available for S1C63 Family microcomputers.

User's Name

Enter your company name. Up to 40 characters can be entered. You can use English letters, numbers, symbols, and spaces. The content entered here is recorded in the USER'S NAME field of the segment option document file.

Comment

Enter a comment. Up to 50 characters can be entered in one line. You can enter up to 10 lines. You can use English letters, numbers, symbols, and spaces. Use the [Enter] key to create a new line. All comments should include the following information:

- Place of business, your department or section
- Address, telephone number, and facsimile number
- Other: Technical information, etc.

The content entered here is recorded in the COMMENT field of the segment option document file. When you have finished entering the above necessary items, click [OK]. The setup contents are saved, and the dialog box is closed. The setup contents take effect immediately. If you click [Cancel], current settings will not be changed and the dialog box is closed.

Notes: • *File name specification is subject to the following limitations:*

1. *The number of characters that can be used to specify a file name including the path is 2,048.*
2. *The file name itself (not including the extension) can be up to 15 characters, and the extension up to three characters.*
3. *The file name cannot begin with a hyphen (-), nor can the following symbols be used as part of directory names (folder names), file names, and extensions:*

*/ : , ; * ? " < > |*

- *The symbols shown below cannot be used in the User's Name and Comment:*

\$ \ | `

(3) Setting segment outputs

The LCD drive circuit of an S1C63 Family chip that has had segment options set normally allows selecting the segment output and DC output for every two pins (in certain types of microcomputers, individually for each pin). Segment output should be specified when using the pins for driving an LCD panel.

Segment output ports have a built-in segment decoder allowing any address and data bit in the display memory area to be assigned to any segment. When the segment memory bit is set to 1, the assigned segment lights up; when the bit is set to 0, the segment dims. Segments and display memory bits correspond individually, so that you cannot assign one display memory bit to multiple segments. Therefore, all segments must be assigned different addresses and data bits.

For details about the display memory map and segment assignment, refer to the Technical Manual for each type of microcomputer.

In the explanation below, the chip is assumed to have four common pins, COM0 to COM3.

Follow the procedure below to assign segments:

1. From the [Memory Address/Data bit] table, select the memory address/data bit you want to assign by clicking the appropriate cell. The cell changes color to blue.

If you select an incorrect cell, select a correct cell.

The horizontal rows of the table correspond to display memory addresses. The hexadecimal number shown to the right of the "Memory Address/Data bit" title is the base address of display memory, with only the lower byte of address being displayed in each row of the table. The vertical columns of the table correspond to data bits.

- From [SEGMENT DECODE TABLE], select the SEG pin/COM pin to which you want to assign the memory address/data bit selected in 1 by clicking the appropriate cell. A 3-digit numeric value is displayed in the cell, showing the selected address (2 high-order digits) and data bit (1 low-order digit), and the cell changes color to yellow.

Selection example:

	3	2	1	0			COM0	COM1	COM2	COM3	SPEC	
00							003					
01												
							SEG0					
							SEG1					

If you select an incorrect cell, click the [Delete] button to clear its assignment and reselect from 1. Two or more cells selected by dragging an area can also be deleted using the [Delete] button. Before selecting a cell in [SEGMENT DECODE TABLE], always select a cell in [Memory Address/Data bit].

- Click the SPEC cell for the segment selected in 2 and then the [Seg] button. The cell shows the letter S and changes color to red. This means that the segment has been set for a LCD segment output pin.

If your chip requires selecting segment output and DC output every two pins, the other pin that comprises a pair is set in the same way.

Selection example:

	3	2	1	0			COM0	COM1	COM2	COM3	SPEC	
00							003	002	001	000	S	
01												
							SEG0					
							SEG1	013	012	011	010	S

- Repeat steps 1 to 2 for all segments used for LCD output. Specification selection in 3 may be performed later.

If any COM cell in one SEG pin is unused, leave it blank.

Selection example:

08							SEG8	083	082	081		S
09							SEG9	093	092	091		S

(4) Setting DC outputs

When using SEG pins for general-purpose DC output, assign segments according to steps 1 and 2 described in Item (3), "Setting segment outputs". However, output control works in such a way that the display memory assigned to COM0 is enabled while the display memory assigned to COM1 through COM3 are disabled. Therefore, set a memory address/data bit for only COM0 cell and leave memory address/data bits for COM1 through COM3 cells blank.

For DC output, you may select an output mode between complementary output and Nch (or Pch) open-drain output. Select your desired output in SPEC cell using the buttons listed below:

[Comp] button: Complementary output (C)

[Nch-] button: N-channel open-drain output (N)

[Pch-] button: P-channel open-drain output (P)

If your chip requires selecting an output mode every two pins, the other pin that comprises a pair is set in the same way.

Selection example:

02							SEG2	023				C
03							SEG3	033				C
04							SEG4	043				N
05							SEG5	053				N

(5) Setting SEG/COM shared pins

Whether the SEG/COM shared pins output segment signals or common signals is determined by selecting the function option.

When using the shared pins as SEG pins, allocate display memory addresses/bits as shown above and leave unused COM cells blank.

When using the shared pins as COM pins, select segment/common shared output ([M] button) as the output specification and do not allocate memory.

Note: This setting is required only for microcomputers that have SEG/COM shared pins.

(6) Setting unused SEG pins

For SEG pins that are used for neither LCD output nor DC output, leave COM0 through COM3 cells in [SEGMENT DECODE TABLE] blank. However, SPEC cells cannot be left blank, so select segment output (S) for the corresponding SPEC cells.

Selection example:

SEG6					S
SEG7					S

(7) Creating files

After selecting options, select [Generate] from the [Tool] menu or click the [Generate] button to create the files.

 [Generate] button


The segment option document file you specified from the [Setup] dialog box and the segment option HEX file (if specified) are created. When winsog has finished creating the files normally, it displays the message "Making file(s) is completed" in the message area. If an error occurs, an error message is displayed.

(8) Saving uncompleted segment option data

You can save the segment option settings that have not been completed as a segment assignment data file. To save data, select [Record - Save] from the [File] menu or click the [Save] button.

 [Save] button

The dialog box shown below appears, so enter a file name including the path in the text box or select a file by clicking the [Ref] button.




Clicking [OK] saves the current assignment data to the specified file. To stop saving, click [Cancel].

You can read an existing segment option document file into winsog and correct it as necessary. To load a segment assignment data file, select [Record - Load] from the [File] menu or click the [Load] button.

 [Load] button

The dialog box shown below appears, so enter a file name including the path in the text box or select a file by clicking the [Ref] button.



Click [OK], and the file is loaded. If the specified file exists and there is no problem with its contents, the option setup area is updated according to the segment assignment data saved in the file. You can continue segment assignment from the previous set state. To stop loading the file, click [Cancel].


- Notes:
- The segment assignment data file can be read only when the device information definition file has been loaded.
 - Some models need a function option document file to be loaded at the start of winsog, and the contents of the file affect the segment option setup condition. Therefore, the segment assignment data file in which the settings do not match the function option cannot be read.

(9) Correcting an existing document file

You can read an existing segment option document file into winsog and correct it as necessary. To read a file, select [Open] from the [File] menu or click the [Open] button.

 [Open] button

The dialog box shown below appears, so enter a file name including the path in the text box or select a file by clicking the [Ref] button.



Click [OK], and the file is loaded. If the specified file exists and there is no problem with its contents, [Memory Address/Data bit] and [SEGMENT DECODE TABLE] are updated according to the contents of the file. To stop loading the file, click [Cancel].

If you want to change an assigned address, clear its cell assignment using the [Delete] button first and then reassign a new address. If you want to change a selected output mode too, select the corresponding SPEC cell and clear its selected output mode with the [Delete] button before reselecting a new output mode. Two or more cells selected by dragging an area can also be deleted using the [Delete] button.

If you select [Generate] without changing the file name, the dialog box asking you whether to overwrite the file is displayed. Click [Yes] to overwrite or [No] or [Cancel] to stop overwriting. Use the [Setup] dialog box to change the file name.

- Notes:
- The segment option document file can be read only when the device information definition file has been loaded.
 - Some models need a function option document file to be loaded at the start of winsog, and the contents of the file affect the segment option setup condition. Therefore, the segment option document file in which the settings do not match the function option cannot be read.

(10) Quitting

To terminate winsog, select [End] from the [File] menu.

10.4 Error Messages

The error messages of winsog are listed below. The "Dialog" in the Display column means that messages are displayed in the dialog box, and "Message" means that messages are displayed in the [SOG] window message area.

Table 10.4.1 List of winsog Error Messages

Message	Description	Display
File name error	Number of characters in the file name or extension exceeds the limit.	Dialog
Illegal character	Prohibited characters have been entered.	Dialog
Please input file name	File name has not been entered.	Dialog
Can't open File : xxxx	File (xxxx) cannot be opened.	Dialog
INI file is not found	Specified device information definition file (.ini) does not exist.	Dialog
INI file does not include SOG information	Specified device information definition file (.ini) does not contain segment option information.	Dialog
Function Option document file is not found	Specified function option document file does not exist.	Dialog
Function Option document file does not match INI file	Contents of the specified function option document file do not match device information definition file (.ini).	Dialog
Segment Option document file is not found	Specified segment option document file does not exist.	Dialog
Segment Option document file does not match INI file	Contents of the specified segment option document file do not match device information definition file (.ini).	Dialog
Segment assignment data file is not found	Specified segment assignment data file does not exist.	Dialog
Segment assignment data file does not match INI file	Contents of the specified segment assignment data file do not match device information definition file (.ini).	Dialog
Can't open File: xxxx Making file(s) is not completed	File (xxxx) cannot be opened when executing Generate.	Message
Can't write File: xxxx Making file(s) is not completed	File (xxxx) cannot be written when executing Generate.	Message
ERROR: SPEC is not set Making file(s) is not completed	One or more SPEC cells are left blank when executing Generate.	Message
ERROR: SEGMENT DECODE TABLE is not set. Making file(s) is not completed	Selected memory address/data bit has not been assigned to SEG/COM terminal cells when executing Generate.	Message

Table 10.4.2 winsog Warning Messages

Message	Description	Display
Are you file update? xxxx is already exist	Overwrite confirmation message (Specified file already exists.)	Dialog

10.5 Precautions

(1) winsog does not support Japanese (2-byte) characters. Do not use Japanese characters for path or file names.

For the restrictions, support functions and bug information of the latest version, refer to rel_windev_E.txt of S5U1C63000A.

For the models supported by the latest version, refer to Readme_E.txt of S5U1C63000A.

10.6 Example Output Files

Note: The display memory addresses, the number of SEG/COM pins, and output specification vary with each type of microcomputer.

Example of a segment option document file

```
* S1C63xxx SEGMENT OPTION DOCUMENT Vx.xx ← Version
*
* FILE NAME      zzzzzzzz.SDC           ← File name (specified by [Setup])
* USER'S NAME   SEIKO EPSON CORPORATION ← User name (specified by [Setup])
* INPUT DATE    yyyy/mm/dd             ← Date of creation (specified by [Setup])
* COMMENT       SAMPLE DATA           ← Comment (specified by [Setup])
*
*
* OPTION NO.xx                                     ← Option number (varies with type of microcomputer)
*
* < LCD SEGMENT DECODE TABLE >
*
* SEG COM0 COM1 COM2 COM3 SPEC
*
*  0  163  162  161  1F3  S           ← Segment decode table
*  1  170  172  171  160  S
*  2  143  142  141  1E1  S
*  3  150  152  151  140  S
*      :
*  xx 3B0  3B1  3B2  3B3  S
* EOF                                     ← End mark
```

Example of a segment assignment data file

```
* S1C63xxx SEGMENT OPTION DOCUMENT Vx.xx ← Version
*
* FILE NAME      zzzzzzzz.SAD           ← File name (specified by [Setup])
* USER'S NAME   SEIKO EPSON CORPORATION ← User name (specified by [Setup])
* INPUT DATE    yyyy/mm/dd             ← Date of creation (specified by [Setup])
* COMMENT       SAMPLE DATA           ← Comment (specified by [Setup])
*
*
* OPTION NO.xx                                     ← Option number (varies with type of microcomputer)
*
* < LCD SEGMENT DECODE TABLE >
*
* SEG COM0 COM1 COM2 COM3 SPEC
*
*  0  163  162  161  1F3  S           ← Segment data has been assigned
*  1  170  172  171  160  S
*  2  143  142  141  1E1  S
*      :
*  mm FRE  FRE  FRE  FRE  X           ← FRE: Segment address and data bit have not been assigned.
*  nn FRE  FRE  FRE  FRE  X           ← X: Output specification has not been set.
*  oo FRE  FRE  FRE  FRE  X
* EOF                                     ← End mark
```

Example of a segment option HEX file (Motorola S2 format)

```
S2240000001603160216011F03FFFFFFFFFFFFFFFF1700170217011600FFFFFFFFFFFFFFFF23
S2240000201403140214011E01FFFFFFFFFFFFFFFF1500150215011400FFFFFFFFFFFFFFFF14
S2240000400103120212011D03FFFFFFFFFFFFFFFF12031F0013021F01FFFFFFFFFFFFFFFF7
S2240000600303130013011200FFFFFFFFFFFFFFFF1003100210011E02FFFFFFFFFFFFFFFF6
:
S2240010E0FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF0B
S804000000FB
```

For details about the Motorola S2 format, refer to Section 6.5.2, "Motorola-S Format".

CHAPTER 11 MASK DATA CHECKER

11.1 Outline of the Mask Data Checker winmdc

The Mask Data Checker winmdc is the software tool for checking the format of each generated file and creating the files necessary to generate mask patterns. winmdc checks the HEX files of the code ROM and data ROM generated by the HEX converter hx63, the function option document file generated by the function option generator winfog, and the segment option document file generated by the segment option generator winsog. The winmdc also has a function for restoring the created mask data file into the original file format.

11.2 Input/Output Files

Figure 11.2.1 shows the input/output files of winmdc.




Fig. 11.2.1 Input/Output Files of winmdc

Device information definition file (s1c63xxx.ini)

This file contains option lists for various types of microcomputers and other information. Always be sure to use the files presented by Seiko Epson. This file is effective for only the type of microcomputer indicated by the file name. Do not modify the contents of the file or use the file in other types of microcomputers.

Code ROM HEX files (zzzzzzzz.hsa, zzzzzzzz.lsa)

Both these files are Motorola S2 format HEX files, with the 5 high-order bits of object code (13 bits) stored in ".hsa" and the 8 low-order bits of object code stored in ".lsa". These files are created from the object files output by the linker lk63 by converting them into HEX format using the HEX converter hx63. For details about hx63, refer to Chapter 6, "HEX Converter".

Data ROM HEX file (zzzzzzzz.csa)

This is a Motorola S2 format HEX file containing the 4-bit data to be written into the data ROM. This file is created simultaneously with the code ROM HEX files by hx63. This file is available for only microcomputers featuring built-in data ROM.

Function option document file (zzzzzzzz.fdc)

This is a text format file in which the contents of selected function options are stored. This file is created by the function option generator winfog.

Segment option document file (zzzzzzzz.sdc)

This is a text format file in which the contents of segment options set are stored. It is created by the segment option generator winsog. This file is available for only microcomputers with set segment options.

Pack file (c63xxx·yyy.paN, N = 0 and over)

This is a text format file which contains the above data files combined into one. We would like to have this file presented to Seiko Epson as the mask data file. Seiko Epson will create the mask patterns for the IC from this mask data file.

- * The "xxx·" in the file name denotes the model name of a microcomputer. The "yyy" part of the file name represents the custom code of each customer. Enter the code from Seiko Epson here. For the "zzzzzzzz" and "uzzzzzzz" parts, any given file name can be specified.

11.3 Using winmdc

11.3.1 Starting Up

Startup from Explorer



Winmdc.exe

Double-click on the winmdc.exe icon or select winmdc from the start menu.

If the device information definition file (s1c63xxx.ini) was loaded into your computer during a previous execution, winmdc automatically reads the same file as it starts.

Alternatively, drag the device information definition file icon into the winmdc.exe icon to start winmdc, which will then read the device information definition file.

Startup by command input


You can also start winmdc from the command prompt by entering the command shown below.

```
>winmdc [s1c63xxx.ini] ↵
```

↵ denotes entering the return key.

You can specify the device information definition file (s1c63xxx.ini) as a command option. (You can also specify a path.) When you specify the Device information definition file here, winmdc reads it as it starts. This specification can be omitted.

When winmdc starts, it displays the [MDC] window.



[MDC] Window (initial screen)

- * The microcomputer model name on the title bar is the file name (not including the path and extension) of the device information definition file that has been read.
- * The [Pack] and [Unpack] buttons on the tool bar are enabled when the device information definition file is read.

11.3.2 Menus and Toolbar Buttons

This section explains each menu item and toolbar button.

[File] menu

File(F)	End
End(X)	Terminates winmdc.

[Tool] menu

Tool(T)	Pack
Pack(P)	Packs the ROM data file and option document file to create a mask data file for presentation to Seiko Epson. The [Pack] button has the same function.
Unpack(U)	
Device INI Select	 [Pack] button

Unpack
Restores files in the original format from a packed file. The [Unpack] button has the same function.



Device INI Select
Loads the device information definition file (s1c63xxx.ini). The [Device INI Select] button has the same function. This file must be loaded first before performing any operation with winmdc.



[Help] menu

Help(H)	Version
Version(A)	Displays the version of winmdc. The [Help] button has the same function. [Help] button

The dialog box shown below appears. Click [OK] to close this dialog box.



11.3.3 Operation Procedure

The following shows the basic operation procedure.

(1) Loading the Device information definition file


First, select a device information definition file (s1c63xxx.ini) and load it.

Select [Device INI Select] from the [Tool] menu or click the [Device INI Select] button.



[Device INI Select] button

The dialog box shown below appears. Enter a file name including the path in the text box or select a file by clicking the [Ref] button.



Click [OK], and the file is loaded. If the specified file exists and there is no problem with its contents, the set-up items in winmdc are initialized with the loaded device information. To stop loading the file, click [Cancel].


Once a device information definition file is selected, the same file is automatically loaded the next time you start winmdc.

(2) Packing

1. Select [Pack] from the [Tool] menu or click the [Pack] button on the tool bar to bring up the [Pack] dialog box.




[Pack] button



2. Select the files to be entered.
[Pack Input Files] lists the files of the type specified in the device information definition file by their default file names. If the data files to be entered are represented by different names in this list, replace the file names following the procedure below.
 - a. Select a file name to be changed by clicking on it from the list box.
 - b. Click the [Ref] button and select the data file to be entered.Do this for all files listed.
When replacing files, take care not to mistake one file for another. If the input file is erroneous, an error will result during file packing.
3. Setting output file names
In the [Pack Output File] text box, specify a pack file name in which you want the mask data to be output. The file name displayed by default can be modified. You can use the [Ref] button to look at other folders.
Make sure the extension of the output file name is ".pa0". If after presenting data to Seiko Epson, you present new data due to program bugs or any other reason, increase the number in the last digit of the extension in increments of one. For example, the extension of the second file presented should be "c63xxx·yyy.pa1".
Note: File name specification is subject to the following limitations:
 1. The number of characters that can be used to specify a file name including the path is 2,048.
 2. The file name itself (not including the extension) can be up to 15 characters, and the extension up to three characters.
 3. The file name cannot begin with a hyphen (-), nor can the following symbols be used as part of directory names (folder names), file names, and extensions:
/ : ; * ? " < > |
4. Click the [Pack] button to execute packing.
When winmdc has completed packing, it displays a message "Packing completed!" in the [Pack message] text box. If an error has occurred, an error message is displayed.
5. Click the [Cancel] button to close the dialog box.
Alternatively, you can click the [Cancel] button to quit winmdc before it executes packing.

(3) Unpacking

1. Select [Unpack] from the [Tool] menu or click the [Unpack] button on the tool bar to bring up the [Unpack] dialog box.



2. Select the file you want to unpack.
In the [Packed Input File] text box, specify the pack file name you want to enter. Use the names displayed by default to specify this file name after changing one, or select another file using the [Ref] button.
3. Set the output file name.
[Unpack Output Files] lists the files of the type specified in the device information definition file by their default file names. Modify the file name displayed by the following procedure.
 - a. Click in the list box to select the file name to be modified.
 - b. Click the [Ref] button to select another folder, and then enter a file name. Modify all the listed file names. The extensions cannot be changed.
4. Click the [Unpack] button to execute unpacking.
When winmdc has completed unpacking, it displays a message "Unpacking completed!" in the [Unpack message] text box. If an error has occurred, an error message is displayed.
5. Click the [Cancel] button to close the dialog box.
Alternatively, you can click the [Cancel] button to quit winmdc before it executes unpacking.

(4) Quitting

To terminate winmdc, select [End] from the [File] menu.

11.4 Error Messages

The error messages of winmdc are listed below. The "Dialog" in the Display column means that messages are displayed in the dialog box, and "Message" means that messages are displayed in the message area of the [Pack] or [Unpack] dialog box.

Table 11.4.1 List of I/O Error Messages

Message	Description	Display
File name error	Number of characters in the file name or extension exceeds the limit.	Dialog
Illegal character	Prohibited characters have been entered.	Dialog
Please input file name	File name has not been entered.	Dialog
INI file is not found	Specified device information definition file (.ini) does not exist.	Dialog
INI file does not include MDC information	Specified device information definition file (.ini) does not contain MDC information.	Dialog
Can't open file : xxxx	File (xxxx) cannot be opened.	Dialog
Can't write file: xxxx	File (xxxx) cannot be written.	Dialog

Table 11.4.2 List of ROM Data Error Messages

Message	Description	Display
Hex data error: Not S record.	Data does not begin with "S."	Message
Hex data error: Data is not sequential.	Data is not listed in ascending order.	Message
Hex data error: Illegal data.	Invalid character is included.	Message
Hex data error: Too many data in one line.	Too many data entries exist in one line.	Message
Hex data error: Check sum error.	Checksum does not match.	Message
Hex data error: ROM capacity over.	Data is large. (Greater than ROM size)	Message
Hex data error: Not enough the ROM data.	Data is small. (Smaller than ROM size)	Message
Hex data error: Illegal start mark.	Start mark is incorrect.	Message
Hex data error: Illegal end mark.	End mark is incorrect.	Message
Hex data error: Illegal comment.	Model name shown at the beginning of data is incorrect.	Message

Table 11.4.3 List of Function Option Data Error Messages

Message	Description	Display
Option data error : Illegal model name.	Model name is incorrect.	Message
Option data error : Illegal version.	Version is incorrect.	Message
Option data error : Illegal option number.	Option No. is incorrect.	Message
Option data error : Illegal select number.	Selected option number is incorrect.	Message
Option data error : Mask data is not enough.	Mask data is insufficient.	Message
Option data error : Illegal start mark.	Start mark is incorrect.	Message
Option data error : Illegal end mark.	End mark is incorrect.	Message

Table 11.4.4 List of Segment Option Data Error Messages

Message	Description	Display
LCD segment data error : Illegal model name.	Model name is incorrect.	Message
LCD segment data error : Illegal version.	Version is incorrect.	Message
LCD segment data error : Illegal segment No.	Segment No. is incorrect.	Message
LCD segment data error : Illegal segment area.	Display memory address is out of range.	Message
LCD segment data error : Illegal segment output specification.	Specified output mode is incorrect.	Message
LCD segment data error : Illegal data in this line.	Data written here is not hexadecimal number or output mode.	Message
LCD segment data error : Data is not enough.	Segment data is insufficient.	Message
LCD segment data error : Illegal start mark.	Start mark is incorrect.	Message
LCD segment data error : Illegal end mark.	End mark is incorrect.	Message

11.5 Precautions

(1) winmdc does not support Japanese (2-byte) characters. Do not use Japanese characters for path or file names.

For the restrictions, support functions and bug information of the latest version, refer to rel_windev_E.txt of S5U1C63000A.

For the models supported by the latest version, refer to Readme_E.txt of S5U1C63000A.

11.6 Example Output File

Note: The configuration and contents of data vary with each type of microcomputer.

Example of a pack file (mask data file)

```

*
* S1C63xxx MASK DATA VER x.xx
*
\ PROM
S1C63xxxxyy PROGRAM ROM
S224000000.....
: : : : :
S804000000FB
S224000000.....
: : : : :
S804000000FB
\ END
\ CHROM
S1C63xxxxyy CHARACTER ROM
S224000000.....
S804000000FB
\ END
\ FOPTION
* S1C63xxx FUNCTION OPTION DOCUMENT Vx.xx
*
* FILE NAME zzzzzzzz.FDC
* USER'S NAME
* INPUT DATE 2000/06/27
* COMMENT
*
* *** OPTION NO.1 ***
* --- OSC1 SYSTEM CLOCK ---
* CR 60KHz (Special Reset) ---- Selected
OPT0101 03
: : : : :
OPTi01 02
* EOF
\ END
\ SEGMENT
* S1C63xxx SEGMENT OPTION DOCUMENT Vx.xx
*
* FILE NAME zzzzzzzz.SDC
* USER'S NAME
* INPUT DATE 2000/9/1
* COMMENT
*
* OPTION NO.mm
*
* < LCD SEGMENT DECODE TABLE >
*
* SEG COM0 COM1 COM2 COM3 SPEC
*
0 000 001 002 003 S
1 020 021 022 023 S
:
nn 760 761 762 763 N
* EOF
\ END

```

← Version

← Code ROM HEX data start mark
← Master slice model name

"zzzzzzz.hsa", "zzzzzzz.lsa"

← Code ROM HEX data end mark
← Data ROM HEX data start mark
← Master slice model name

"zzzzzzz.csa"

← Data ROM HEX data end mark
← Function option start mark
← Model name/version

"zzzzzzz.fdc"

← Function option end mark
← Segment option start mark
← Model name/version

"zzzzzzz.sdc"

← Segment option end mark

S1C63 Family Assembler Package

Quick Reference

EPSON


CMOS 4-bit Single Chip Microcomputer
S1C63 Family Assembler Package

Quick Reference for Development


Memory Map

S1C63000 Core CPU

Program Memory Map




Data Memory Map




Registers

S1C63000 Core CPU

Registers



Flags



Symbols in the Instruction List

Registers/Register Data

%A, A:	Data register A or the contents of the register (4 bits)
%B, B:	Data register B or the contents of the register (4 bits)
%BA, BA:	Data register BA or the contents of the register (8 bits, the B register is high-order 4 bits)
%X, X:	Index register X or the contents of the register (16 bits)
%XH, XH:	Index register XH or the contents of the register (high-order 8 bits of the X register)
%XL, XL:	Index register XL or the contents of the register (low-order 8 bits of the X register)
%Y, Y:	Index register Y or the contents of the register (16 bits)
%YH, YH:	Index register YH or the contents of the register (high-order 8 bits of the Y register)
%YL, YL:	Index register YL or the contents of the register (low-order 8 bits of the Y register)
%F, F:	Flag register F or the contents of the register (4 bits)
%EXT, EXT:	Extension register EXT or the contents of the register (8 bits)
%SP1, SP1:	Stack pointer SP1 or the contents of the stack pointer (16 bits, setting data = SP1(9:2))
%SP2, SP2:	Stack pointer SP2 or the contents of the stack pointer (16 bits, setting data = SP2(7:0))
PC:	Contents of the program counter PC (16 bits)

Memory/Addresses/Memory Data

[%X], [X]:	Register indirect addressing using X, or the contents of the specified memory
[%Y], [Y]:	Register indirect addressing using Y, or the contents of the specified memory
[00addr6]:	6-bit absolute addressing with addr6, or the contents of the specified memory (0x0000–0x003F)
[FFaddr6]:	6-bit absolute addressing with addr6, or the contents of the specified memory (0xFFC0–0xFFFF)
[00imm8]:	8-bit absolute addressing with imm8, or the contents of the specified memory (0x0000–0x00FF)
[FFimm8]:	8-bit absolute addressing with imm8, or the contents of the specified memory (0xFF00–0xFFFF)
[%SP1], [SP1]:	16-bit stack specification or the contents of the stack address
[%SP2], [SP2]:	4-bit stack specification or the contents of the stack address

Immediate Data

immN:	N-bit unsigned immediate data (N = 2, 4, 6 or 8)
i7–i0:	Bit data of immN
n4:	4-bit radix specification data
n3–n0:	Bit data of n4
sign8:	Signed 8-bit immediate data
s7–s0:	Bit data of sign8
addr6:	6-bit absolute address
a5–a0:	Bit data of addr6
00addr6:	An address (0x0000–0x003F) specified with addr6
FFaddr6:	An address (0xFFC0–0xFFFF) specified with addr6

Functions

←:	Indicates that the right item is loaded or set to the left item.
↔:	Indicates that data is exchanged between the right and left items.
+	Addition
-:	Subtraction
∧:	AND
∨:	OR
⊖:	XOR

Flags

Z:	Zero flag
C:	Carry flag
I:	Interrupt flag
E:	Extension flag
–:	Not changed
↔:	Set (1), reset (0) or not changed
1:	Set (1)
0:	Reset (0)

Cik

Indicates the number of execution cycles.

Symbol

○ Indicates that a symbol can be used for the operand instead of an 8-bit or 6-bit immediate data. However, the symbol value must be within the range that can be specified. If a symbol mask is listed, the instruction can use the symbol mask for the operand in addition to a symbol.

Symbol mask

@l:	Acquires the low-order 8 bits of an absolute address.
@h:	Acquires the high-order 8 bits of an absolute address.
@rl:	Acquires the low-order 8 bits of a relative address.
@rh:	Acquires the high-order 8 bits of a relative address.
@xh:	Acquires the inverted high-order 8 bits of an absolute address.

Note

The "Extended function" shows the operation of the instruction when "LDB %EXT, imm8" is executed prior to the instruction.

Instruction List (2)
S1C63000 Core CPU

Classification	Mnemonic		Basic function	Extended function (when "LDB %EXT, imm8" is executed)	Clk	Flags				Symbol		
	Opcode	Operand				E	I	C	Z			
4-bit data transfer	LD	%A,%A	$A \leftarrow A$	–	1	0	–	–	–	–		
		%A,%B	$A \leftarrow B$	–	1	0	–	–	–	–		
		%A,%F	$A \leftarrow F$	–	1	0	–	–	–	–		
		%A,imm4	$A \leftarrow \text{imm4}$	–	1	0	–	–	–	–		
		%A,[%X]	$A \leftarrow [X]$	$A \leftarrow [00\text{imm8}]$	1	0	–	–	–	–		
		%A,[%X]+	$A \leftarrow [X], X \leftarrow X+1$	–	1	0	–	–	–	–		
		%A,[%Y]	$A \leftarrow [Y]$	$A \leftarrow [\text{FFimm8}]$	1	0	–	–	–	–		
		%A,[%Y]+	$A \leftarrow [Y], Y \leftarrow Y+1$	–	1	0	–	–	–	–		
	LD	%B,%A	$B \leftarrow A$	–	1	0	–	–	–	–		
		%B,%B	$B \leftarrow B$	–	1	0	–	–	–	–		
		%B,imm4	$B \leftarrow \text{imm4}$	–	1	0	–	–	–	–		
		%B,[%X]	$B \leftarrow [X]$	$B \leftarrow [00\text{imm8}]$	1	0	–	–	–	–		
		%B,[%X]+	$B \leftarrow [X], X \leftarrow X+1$	–	1	0	–	–	–	–		
		%B,[%Y]	$B \leftarrow [Y]$	$B \leftarrow [\text{FFimm8}]$	1	0	–	–	–	–		
		%B,[%Y]+	$B \leftarrow [Y], Y \leftarrow Y+1$	–	1	0	–	–	–	–		
	LD	%F,%A	$F \leftarrow A$	–	1	↔	↔	↔	↔	–		
		%F,imm4	$F \leftarrow \text{imm4}$	–	1	↔	↔	↔	↔	–		
	LD	[%X],%A	$[X] \leftarrow A$	$[00\text{imm8}] \leftarrow A$	1	0	–	–	–	–		
		[%X],%B	$[X] \leftarrow B$	$[00\text{imm8}] \leftarrow B$	1	0	–	–	–	–		
		[%X],imm4	$[X] \leftarrow \text{imm4}$	$[00\text{imm8}] \leftarrow \text{imm4}$	1	0	–	–	–	–		
		[%X],[%Y]	$[X] \leftarrow [Y]$	–	2	0	–	–	–	–		
		[%X],[%Y]+	$[X] \leftarrow [Y], Y \leftarrow Y+1$	–	2	0	–	–	–	–		
		[%X]+,%A	$[X] \leftarrow A, X \leftarrow X+1$	–	1	0	–	–	–	–		
		[%X]+,%B	$[X] \leftarrow B, X \leftarrow X+1$	–	1	0	–	–	–	–		
		[%X]+,imm4	$[X] \leftarrow \text{imm4}, X \leftarrow X+1$	–	1	0	–	–	–	–		
		[%X]+,[%Y]	$[X] \leftarrow [Y], X \leftarrow X+1$	–	2	0	–	–	–	–		
		[%X]+,[%Y]+	$[X] \leftarrow [Y], X \leftarrow X+1, Y \leftarrow Y+1$	–	2	0	–	–	–	–		
	LD	[%Y],%A	$[Y] \leftarrow A$	$[\text{FFimm8}] \leftarrow A$	1	0	–	–	–	–		
		[%Y],%B	$[Y] \leftarrow B$	$[\text{FFimm8}] \leftarrow B$	1	0	–	–	–	–		
		[%Y],imm4	$[Y] \leftarrow \text{imm4}$	$[\text{FFimm8}] \leftarrow \text{imm4}$	1	0	–	–	–	–		
		[%Y],[%X]	$[Y] \leftarrow [X]$	–	2	0	–	–	–	–		
		[%Y],[%X]+	$[Y] \leftarrow [X], X \leftarrow X+1$	–	2	0	–	–	–	–		
		[%Y]+,%A	$[Y] \leftarrow A, Y \leftarrow Y+1$	–	1	0	–	–	–	–		
		[%Y]+,%B	$[Y] \leftarrow B, Y \leftarrow Y+1$	–	1	0	–	–	–	–		
		[%Y]+,imm4	$[Y] \leftarrow \text{imm4}, Y \leftarrow Y+1$	–	1	0	–	–	–	–		
		[%Y]+,[%X]	$[Y] \leftarrow [X], Y \leftarrow Y+1$	–	2	0	–	–	–	–		
		[%Y]+,[%X]+	$[Y] \leftarrow [X], Y \leftarrow Y+1, X \leftarrow X+1$	–	2	0	–	–	–	–		
		Remarks										

Instruction List (3)
S1C63000 Core CPU

Classification	Mnemonic		Basic function	Extended function (when "LDB %EXT, imm8" is executed)	Clk	Flags				Symbol		
	Opcode	Operand				E	I	C	Z			
4-bit data transfer	EX	%A,%B	A ↔ B	–	1	0	–	–	–	–		
	EX	%A,[%X]	A ↔ [X]	A ↔ [00imm8]	–	2	0	–	–	–	–	
		%A,[%X]+	A ↔ [X], X ← X+1	–	–	2	0	–	–	–	–	
		%A,[%Y]	A ↔ [Y]	A ↔ [FFimm8]	–	2	0	–	–	–	–	
		%A,[%Y]+	A ↔ [Y], Y ← Y+1	–	–	2	0	–	–	–	–	
		%B,[%X]	B ↔ [X]	B ↔ [00imm8]	–	2	0	–	–	–	–	
	EX	%B,[%X]+	B ↔ [X], X ← X+1	–	–	2	0	–	–	–	–	
		%B,[%Y]	B ↔ [Y]	B ↔ [FFimm8]	–	2	0	–	–	–	–	
		%B,[%Y]+	B ↔ [Y], Y ← Y+1	–	–	2	0	–	–	–	–	
		Arithmetic operation	ADD	%A,%A	A ← A+A	–	1	0	–	↔	↔	–
				%A,%B	A ← A+B	–	1	0	–	↔	↔	–
	%A,imm4			A ← A+imm4	–	1	0	–	↔	↔	–	
%A,[%X]	A ← A+[X]			A ← A+[00imm8]	–	1	0	–	↔	↔	–	
%A,[%X]+	A ← A+[X], X ← X+1			–	–	1	0	–	↔	↔	–	
%A,[%Y]	A ← A+[Y]			A ← A+[FFimm8]	–	1	0	–	↔	↔	–	
%A,[%Y]+	A ← A+[Y], Y ← Y+1			–	–	1	0	–	↔	↔	–	
ADD	%B,%A		B ← B+A	–	–	1	0	–	↔	↔	–	
	%B,%B		B ← B+B	–	–	1	0	–	↔	↔	–	
	%B,imm4		B ← B+imm4	–	–	1	0	–	↔	↔	–	
	%B,[%X]		B ← B+[X]	B ← B+[00imm8]	–	1	0	–	↔	↔	–	
	%B,[%X]+		B ← B+[X], X ← X+1	–	–	1	0	–	↔	↔	–	
	%B,[%Y]	B ← B+[Y]	B ← B+[FFimm8]	–	1	0	–	↔	↔	–		
	%B,[%Y]+	B ← B+[Y], Y ← Y+1	–	–	1	0	–	↔	↔	–		
ADD	[%X],%A	[X] ← [X]+A	[00imm8] ← [00imm8]+A	–	2	0	–	↔	↔	–		
	[%X],%B	[X] ← [X]+B	[00imm8] ← [00imm8]+B	–	2	0	–	↔	↔	–		
	[%X],imm4	[X] ← [X]+imm4	[00imm8] ← [00imm8]+imm4	–	2	0	–	↔	↔	–		
	[%X]+,%A	[X] ← [X]+A, X ← X+1	–	–	2	0	–	↔	↔	–		
	[%X]+,%B	[X] ← [X]+B, X ← X+1	–	–	2	0	–	↔	↔	–		
	[%X]+,imm4	[X] ← [X]+imm4, X ← X+1	–	–	2	0	–	↔	↔	–		
ADD	[%Y],%A	[Y] ← [Y]+A	[FFimm8] ← [FFimm8]+A	–	2	0	–	↔	↔	–		
	[%Y],%B	[Y] ← [Y]+B	[FFimm8] ← [FFimm8]+B	–	2	0	–	↔	↔	–		
	[%Y],imm4	[Y] ← [Y]+imm4	[FFimm8] ← [FFimm8]+imm4	–	2	0	–	↔	↔	–		
	[%Y]+,%A	[Y] ← [Y]+A, Y ← Y+1	–	–	2	0	–	↔	↔	–		
	[%Y]+,%B	[Y] ← [Y]+B, Y ← Y+1	–	–	2	0	–	↔	↔	–		
	[%Y]+,imm4	[Y] ← [Y]+imm4, Y ← Y+1	–	–	2	0	–	↔	↔	–		
Remarks												

Instruction List (4)
S1C63000 Core CPU

Classification	Mnemonic		Basic function	Extended function (when "LDB %EXT, imm8" is executed)	Clk	Flags				Symbol	
	Opcode	Operand				E	I	C	Z		
Arithmetic operation	ADC	%A,%A	$A \leftarrow A+A+C$	–	1	0	–	↔	↔	–	
		%A,%B	$A \leftarrow A+B+C$	–	1	0	–	↔	↔	–	
		%A,imm4	$A \leftarrow A+imm4+C$	–	1	0	–	↔	↔	–	
		%A,[%X]	$A \leftarrow A+[X]+C$	$A \leftarrow A+[00imm8]+C$	1	0	–	↔	↔	–	
		%A,[%X]+	$A \leftarrow A+[X]+C, X \leftarrow X+1$	–	1	0	–	↔	↔	–	
		%A,[%Y]	$A \leftarrow A+[Y]+C$	$A \leftarrow A+[FFimm8]+C$	1	0	–	↔	↔	–	
		%A,[%Y]+	$A \leftarrow A+[Y]+C, Y \leftarrow Y+1$	–	1	0	–	↔	↔	–	
	ADC	%B,%A	$B \leftarrow B+A+C$	–	1	0	–	↔	↔	–	
		%B,%B	$B \leftarrow B+B+C$	–	1	0	–	↔	↔	–	
		%B,imm4	$B \leftarrow B+imm4+C$	–	1	0	–	↔	↔	–	
		%B,[%X]	$B \leftarrow B+[X]+C$	$B \leftarrow B+[00imm8]+C$	1	0	–	↔	↔	–	
		%B,[%X]+	$B \leftarrow B+[X]+C, X \leftarrow X+1$	–	1	0	–	↔	↔	–	
		%B,[%Y]	$B \leftarrow B+[Y]+C$	$B \leftarrow B+[FFimm8]+C$	1	0	–	↔	↔	–	
		%B,[%Y]+	$B \leftarrow B+[Y]+C, Y \leftarrow Y+1$	–	1	0	–	↔	↔	–	
	ADC	[%X],%A	$[X] \leftarrow [X]+A+C$	$[00imm8] \leftarrow [00imm8]+A+C$	2	0	–	↔	↔	–	
		[%X],%B	$[X] \leftarrow [X]+B+C$	$[00imm8] \leftarrow [00imm8]+B+C$	2	0	–	↔	↔	–	
		[%X],imm4	$[X] \leftarrow [X]+imm4+C$	$[00imm8] \leftarrow [00imm8]+imm4+C$	2	0	–	↔	↔	–	
		[%X]+,%A	$[X] \leftarrow [X]+A+C, X \leftarrow X+1$	–	2	0	–	↔	↔	–	
		[%X]+,%B	$[X] \leftarrow [X]+B+C, X \leftarrow X+1$	–	2	0	–	↔	↔	–	
		[%X]+,imm4	$[X] \leftarrow [X]+imm4+C, X \leftarrow X+1$	–	2	0	–	↔	↔	–	
	ADC	[%Y],%A	$[Y] \leftarrow [Y]+A+C$	$[FFimm8] \leftarrow [FFimm8]+A+C$	2	0	–	↔	↔	–	
		[%Y],%B	$[Y] \leftarrow [Y]+B+C$	$[FFimm8] \leftarrow [FFimm8]+B+C$	2	0	–	↔	↔	–	
		[%Y],imm4	$[Y] \leftarrow [Y]+imm4+C$	$[FFimm8] \leftarrow [FFimm8]+imm4+C$	2	0	–	↔	↔	–	
		[%Y]+,%A	$[Y] \leftarrow [Y]+A+C, Y \leftarrow Y+1$	–	2	0	–	↔	↔	–	
		[%Y]+,%B	$[Y] \leftarrow [Y]+B+C, Y \leftarrow Y+1$	–	2	0	–	↔	↔	–	
		[%Y]+,imm4	$[Y] \leftarrow [Y]+imm4+C, Y \leftarrow Y+1$	–	2	0	–	↔	↔	–	
	SUB	%A,%A	$A \leftarrow A-A$	–	1	0	–	↔	↔	–	
		%A,%B	$A \leftarrow A-B$	–	1	0	–	↔	↔	–	
		%A,imm4	$A \leftarrow A-imm4$	–	1	0	–	↔	↔	–	
		%A,[%X]	$A \leftarrow A-[X]$	$A \leftarrow A-[00imm8]$	1	0	–	↔	↔	–	
		%A,[%X]+	$A \leftarrow A-[X], X \leftarrow X+1$	–	1	0	–	↔	↔	–	
		%A,[%Y]	$A \leftarrow A-[Y]$	$A \leftarrow A-[FFimm8]$	1	0	–	↔	↔	–	
		%A,[%Y]+	$A \leftarrow A-[Y], Y \leftarrow Y+1$	–	1	0	–	↔	↔	–	
		SUB	%B,%A	$B \leftarrow B-A$	–	1	0	–	↔	↔	–
	%B,%B	$B \leftarrow B-A$	–	1	0	–	↔	↔	–		
	%B,imm4	$B \leftarrow B-imm4$	–	1	0	–	↔	↔	–		
	Remarks										

Instruction List (5)
S1C63000 Core CPU

Classification	Mnemonic		Basic function	Extended function (when "LDB %EXT, imm8" is executed)	Clk	Flags				Symbol
	Opcode	Operand				E	I	C	Z	
Arithmetic operation	SUB	%B,[%X]	$B \leftarrow B-[X]$	$B \leftarrow B-[00imm8]$	1	0	-	↔	↔	-
		%B,[%X]+	$B \leftarrow B-[X], X \leftarrow X+1$	-	1	0	-	↔	↔	-
		%B,[%Y]	$B \leftarrow B-[Y]$	$B \leftarrow B-[FFimm8]$	1	0	-	↔	↔	-
		%B,[%Y]+	$B \leftarrow B-[Y], Y \leftarrow Y+1$	-	1	0	-	↔	↔	-
	SUB	[%X],%A	$[X] \leftarrow [X]-A$	$[00imm8] \leftarrow [00imm8]-A$	2	0	-	↔	↔	-
		[%X],%B	$[X] \leftarrow [X]-B$	$[00imm8] \leftarrow [00imm8]-B$	2	0	-	↔	↔	-
		[%X],imm4	$[X] \leftarrow [X]-imm4$	$[00imm8] \leftarrow [00imm8]-imm4$	2	0	-	↔	↔	-
		[%X]+,%A	$[X] \leftarrow [X]-A, X \leftarrow X+1$	-	2	0	-	↔	↔	-
		[%X]+,%B	$[X] \leftarrow [X]-B, X \leftarrow X+1$	-	2	0	-	↔	↔	-
		[%X]+,imm4	$[X] \leftarrow [X]-imm4, X \leftarrow X+1$	-	2	0	-	↔	↔	-
	SUB	[%Y],%A	$[Y] \leftarrow [Y]-A$	$[FFimm8] \leftarrow [FFimm8]-A$	2	0	-	↔	↔	-
		[%Y],%B	$[Y] \leftarrow [Y]-B$	$[FFimm8] \leftarrow [FFimm8]-B$	2	0	-	↔	↔	-
		[%Y],imm4	$[Y] \leftarrow [Y]-imm4$	$[FFimm8] \leftarrow [FFimm8]-imm4$	2	0	-	↔	↔	-
		[%Y]+,%A	$[Y] \leftarrow [Y]-A, Y \leftarrow Y+1$	-	2	0	-	↔	↔	-
		[%Y]+,%B	$[Y] \leftarrow [Y]-B, Y \leftarrow Y+1$	-	2	0	-	↔	↔	-
		[%Y]+,imm4	$[Y] \leftarrow [Y]-imm4, Y \leftarrow Y+1$	-	2	0	-	↔	↔	-
	SBC	%A,%A	$A \leftarrow A-A-C$	-	1	0	-	↔	↔	-
		%A,%B	$A \leftarrow A-B-C$	-	1	0	-	↔	↔	-
		%A,imm4	$A \leftarrow A-imm4-C$	-	1	0	-	↔	↔	-
		%A,[%X]	$A \leftarrow A-[X]-C$	$A \leftarrow A-[00imm8]-C$	1	0	-	↔	↔	-
		%A,[%X]+	$A \leftarrow A-[X]-C, X \leftarrow X+1$	-	1	0	-	↔	↔	-
		%A,[%Y]	$A \leftarrow A-[Y]-C$	$A \leftarrow A-[FFimm8]-C$	1	0	-	↔	↔	-
		%A,[%Y]+	$A \leftarrow A-[Y]-C, Y \leftarrow Y+1$	-	1	0	-	↔	↔	-
	SBC	%B,%A	$B \leftarrow B-A-C$	-	1	0	-	↔	↔	-
		%B,%B	$B \leftarrow B-B-C$	-	1	0	-	↔	↔	-
		%B,imm4	$B \leftarrow B-imm4-C$	-	1	0	-	↔	↔	-
		%B,[%X]	$B \leftarrow B-[X]-C$	$B \leftarrow B-[00imm8]-C$	1	0	-	↔	↔	-
		%B,[%X]+	$B \leftarrow B-[X]-C, X \leftarrow X+1$	-	1	0	-	↔	↔	-
		%B,[%Y]	$B \leftarrow B-[Y]-C$	$B \leftarrow B-[FFimm8]-C$	1	0	-	↔	↔	-
		%B,[%Y]+	$B \leftarrow B-[Y]-C, Y \leftarrow Y+1$	-	1	0	-	↔	↔	-
	SBC	[%X],%A	$[X] \leftarrow [X]-A-C$	$[00imm8] \leftarrow [00imm8]-A-C$	2	0	-	↔	↔	-
		[%X],%B	$[X] \leftarrow [X]-B-C$	$[00imm8] \leftarrow [00imm8]-B-C$	2	0	-	↔	↔	-
[%X],imm4		$[X] \leftarrow [X]-imm4-C$	$[00imm8] \leftarrow [00imm8]-imm4-C$	2	0	-	↔	↔	-	
[%X]+,%A		$[X] \leftarrow [X]-A-C, X \leftarrow X+1$	-	2	0	-	↔	↔	-	
[%X]+,%B		$[X] \leftarrow [X]-B-C, X \leftarrow X+1$	-	2	0	-	↔	↔	-	
[%X]+,imm4		$[X] \leftarrow [X]-imm4-C, X \leftarrow X+1$	-	2	0	-	↔	↔	-	
Remarks										

Instruction List (6)
S1C63000 Core CPU

Classification	Mnemonic		Basic function	Extended function (when "LDB %EXT, imm8" is executed)	Clk	Flags				Symbol	
	Opcode	Operand				E	I	C	Z		
Arithmetic operation	SBC	[%Y],%A	[Y] ← [Y]-A-C	[FFimm8] ← [FFimm8]-A-C	2	0	-	↔	↔	-	
		[%Y],%B	[Y] ← [Y]-B-C	[FFimm8] ← [FFimm8]-B-C	2	0	-	↔	↔	-	
		[%Y],imm4	[Y] ← [Y]-imm4-C	[FFimm8] ← [FFimm8]-imm4-C	2	0	-	↔	↔	-	
		[%Y]+,%A	[Y] ← [Y]-A-C, Y ← Y+1	-	2	0	-	↔	↔	-	
		[%Y]+,%B	[Y] ← [Y]-B-C, Y ← Y+1	-	2	0	-	↔	↔	-	
		[%Y]+,imm4	[Y] ← [Y]-imm4-C, Y ← Y+1	-	2	0	-	↔	↔	-	
	CMP	%A,%A	A-A	-	1	0	-	↔	↔	-	
		%A,%B	A-B	-	1	0	-	↔	↔	-	
		%A,imm4	A-imm4	-	1	0	-	↔	↔	-	
		%A,[%X]	A-[X]	A-[00imm8]	1	0	-	↔	↔	-	
		%A,[%X]+	A-[X], X ← X+1	-	1	0	-	↔	↔	-	
		%A,[%Y]	A-[Y]	A-[FFimm8]	1	0	-	↔	↔	-	
		%A,[%Y]+	A-[Y], Y ← Y+1	-	1	0	-	↔	↔	-	
		CMP	%B,%A	B-A	-	1	0	-	↔	↔	-
	%B,%B		B-B	-	1	0	-	↔	↔	-	
	%B,imm4		B-imm4	-	1	0	-	↔	↔	-	
	%B,[%X]		B-[X]	B-[00imm8]	1	0	-	↔	↔	-	
	%B,[%X]+		B-[X], X ← X+1	-	1	0	-	↔	↔	-	
	%B,[%Y]		B-[Y]	B-[FFimm8]	1	0	-	↔	↔	-	
	%B,[%Y]+		B-[Y], Y ← Y+1	-	1	0	-	↔	↔	-	
	CMP		[%X],%A	[X]-A	[00imm8]-A	2	0	-	↔	↔	-
		[%X],%B	[X]-B	[00imm8]-B	2	0	-	↔	↔	-	
		[%X],imm4	[X]-imm4	[00imm8]-imm4	2	0	-	↔	↔	-	
		[%X]+,%A	[X]-A, X ← X+1	-	2	0	-	↔	↔	-	
		[%X]+,%B	[X]-B, X ← X+1	-	2	0	-	↔	↔	-	
		[%X]+,imm4	[X]-imm4, X ← X+1	-	2	0	-	↔	↔	-	
	CMP	[%Y],%A	[Y]-A	[FFimm8]-A	2	0	-	↔	↔	-	
		[%Y],%B	[Y]-B	[FFimm8]-B	2	0	-	↔	↔	-	
		[%Y],imm4	[Y]-imm4	[FFimm8]-imm4	2	0	-	↔	↔	-	
		[%Y]+,%A	[Y]-A, Y ← Y+1	-	2	0	-	↔	↔	-	
		[%Y]+,%B	[Y]-B, Y ← Y+1	-	2	0	-	↔	↔	-	
		[%Y]+,imm4	[Y]-imm4, Y ← Y+1	-	2	0	-	↔	↔	-	
	INC	[00addr6]	[00addr6] ← [00addr6]+1	-	2	0	-	↔	↔	○	
	DEC	[00addr6]	[00addr6] ← [00addr6]-1	-	2	0	-	↔	↔	○	
	ADC	%B,%A,n4	B ← N's adjust (B+A+C)	-	2	0	-	↔	↔	-	
		%B,[%X],n4	B ← N's adjust (B+[X]+C)	B ← N's adjust (B+[00imm8]+C)	2	0	-	↔	↔	-	
	Remarks										

Instruction List (7)
S1C63000 Core CPU

Classification	Mnemonic		Basic function	Extended function (when "LDB %EXT, imm8" is executed)	Clk	Flags				Symbol
	Opcode	Operand				E	I	C	Z	
Arithmetic operation	ADC	%B,[%X],n4	$B \leftarrow N\text{'s adjust } (B+[X]+C), X \leftarrow X+1$	–	2	0	–	↔	↔	–
		%B,[%Y],n4	$B \leftarrow N\text{'s adjust } (B+[Y]+C)$	$B \leftarrow N\text{'s adjust } (B+[FFimm8]+C)$	2	0	–	↔	↔	–
		%B,[%Y],n4	$B \leftarrow N\text{'s adjust } (B+[Y]+C), Y \leftarrow Y+1$	–	2	0	–	↔	↔	–
	ADC	[%X],%B,n4	$[X] \leftarrow N\text{'s adjust } ([X]+B+C)$	$[00imm8] \leftarrow N\text{'s adjust } ([00imm8]+B+C)$	2	0	–	↔	↔	–
		[%X],0,n4	$[X] \leftarrow N\text{'s adjust } ([X]+0+C)$	$[00imm8] \leftarrow N\text{'s adjust } ([00imm8]+0+C)$	2	0	–	↔	↔	–
		[%X]+,%B,n4	$[X] \leftarrow N\text{'s adjust } ([X]+B+C), X \leftarrow X+1$	–	2	0	–	↔	↔	–
		[%X]+,0,n4	$[X] \leftarrow N\text{'s adjust } ([X]+0+C), X \leftarrow X+1$	–	2	0	–	↔	↔	–
	ADC	[%Y],%B,n4	$[Y] \leftarrow N\text{'s adjust } ([Y]+B+C)$	$[FFimm8] \leftarrow N\text{'s adjust } ([FFimm8]+B+C)$	2	0	–	↔	↔	–
		[%Y],0,n4	$[Y] \leftarrow N\text{'s adjust } ([Y]+0+C)$	$[FFimm8] \leftarrow N\text{'s adjust } ([FFimm8]+0+C)$	2	0	–	↔	↔	–
		[%Y]+,%B,n4	$[Y] \leftarrow N\text{'s adjust } ([Y]+B+C), Y \leftarrow Y+1$	–	2	0	–	↔	↔	–
		[%Y]+,0,n4	$[Y] \leftarrow N\text{'s adjust } ([Y]+0+C), Y \leftarrow Y+1$	–	2	0	–	↔	↔	–
	SBC	%B,%A,n4	$B \leftarrow N\text{'s adjust } (B-A-C)$	–	2	0	–	↔	↔	–
		%B,[%X],n4	$B \leftarrow N\text{'s adjust } (B-[X]-C)$	$B \leftarrow N\text{'s adjust } (B-[00imm8]-C)$	2	0	–	↔	↔	–
		%B,[%X],n4	$B \leftarrow N\text{'s adjust } (B-[X]-C), X \leftarrow X+1$	–	2	0	–	↔	↔	–
		%B,[%Y],n4	$B \leftarrow N\text{'s adjust } (B-[Y]-C)$	$B \leftarrow N\text{'s adjust } (B-[FFimm8]-C)$	2	0	–	↔	↔	–
		%B,[%Y],n4	$B \leftarrow N\text{'s adjust } (B-[Y]-C), Y \leftarrow Y+1$	–	2	0	–	↔	↔	–
	SBC	[%X],%B,n4	$[X] \leftarrow N\text{'s adjust } ([X]-B-C)$	$[00imm8] \leftarrow N\text{'s adjust } ([00imm8]-B-C)$	2	0	–	↔	↔	–
		[%X],0,n4	$[X] \leftarrow N\text{'s adjust } ([X]-0-C)$	$[00imm8] \leftarrow N\text{'s adjust } ([00imm8]-0-C)$	2	0	–	↔	↔	–
		[%X]+,%B,n4	$[X] \leftarrow N\text{'s adjust } ([X]-B-C), X \leftarrow X+1$	–	2	0	–	↔	↔	–
		[%X]+,0,n4	$[X] \leftarrow N\text{'s adjust } ([X]-0-C), X \leftarrow X+1$	–	2	0	–	↔	↔	–
	SBC	[%Y],%B,n4	$[Y] \leftarrow N\text{'s adjust } ([Y]-B-C)$	$[FFimm8] \leftarrow N\text{'s adjust } ([FFimm8]-B-C)$	2	0	–	↔	↔	–
		[%Y],0,n4	$[Y] \leftarrow N\text{'s adjust } ([Y]-0-C)$	$[FFimm8] \leftarrow N\text{'s adjust } ([FFimm8]-0-C)$	2	0	–	↔	↔	–
		[%Y]+,%B,n4	$[Y] \leftarrow N\text{'s adjust } ([Y]-B-C), Y \leftarrow Y+1$	–	2	0	–	↔	↔	–
		[%Y]+,0,n4	$[Y] \leftarrow N\text{'s adjust } ([Y]-0-C), Y \leftarrow Y+1$	–	2	0	–	↔	↔	–
	INC	[%X],n4	$[X] \leftarrow N\text{'s adjust } ([X]+1)$	$[00imm8] \leftarrow N\text{'s adjust } ([00imm8]+1)$	2	0	–	↔	↔	–
		[%X]+,n4	$[X] \leftarrow N\text{'s adjust } ([X]+1), X \leftarrow X+1$	–	2	0	–	↔	↔	–
	INC	[%Y],n4	$[Y] \leftarrow N\text{'s adjust } ([Y]+1)$	$[FFimm8] \leftarrow N\text{'s adjust } ([FFimm8]+1)$	2	0	–	↔	↔	–
		[%Y]+,n4	$[Y] \leftarrow N\text{'s adjust } ([Y]+1), Y \leftarrow Y+1$	–	2	0	–	↔	↔	–
	DEC	[%X],n4	$[X] \leftarrow N\text{'s adjust } ([X]-1)$	$[00imm8] \leftarrow N\text{'s adjust } ([00imm8]-1)$	2	0	–	↔	↔	–
		[%X]+,n4	$[X] \leftarrow N\text{'s adjust } ([X]-1), X \leftarrow X+1$	–	2	0	–	↔	↔	–
DEC	[%Y],n4	$[Y] \leftarrow N\text{'s adjust } ([Y]-1)$	$[FFimm8] \leftarrow N\text{'s adjust } ([FFimm8]-1)$	2	0	–	↔	↔	–	
	[%Y]+,n4	$[Y] \leftarrow N\text{'s adjust } ([Y]-1), Y \leftarrow Y+1$	–	2	0	–	↔	↔	–	

Remarks

Instruction List (8)
S1C63000 Core CPU

Classification	Mnemonic		Basic function	Extended function (when "LDB %EXT, imm8" is executed)	Clk	Flags				Symbol	
	Opcode	Operand				E	I	C	Z		
Logic operation	AND	%A,%A	$A \leftarrow A \wedge A$	–	1	0	–	–	↔	–	
		%A,%B	$A \leftarrow A \wedge B$	–	1	0	–	–	↔	–	
		%A,imm4	$A \leftarrow A \wedge \text{imm4}$	–	1	0	–	–	↔	–	
		%A,[%X]	$A \leftarrow A \wedge [X]$	$A \leftarrow A \wedge [00\text{imm8}]$	1	0	–	–	↔	–	
		%A,[%X]+	$A \leftarrow A \wedge [X], X \leftarrow X+1$	–	1	0	–	–	↔	–	
		%A,[%Y]	$A \leftarrow A \wedge [Y]$	$A \leftarrow A \wedge [\text{FFimm8}]$	1	0	–	–	↔	–	
		%A,[%Y]+	$A \leftarrow A \wedge [Y], Y \leftarrow Y+1$	–	1	0	–	–	↔	–	
	AND	%B,%A	$B \leftarrow B \wedge A$	–	1	0	–	–	↔	–	
		%B,%B	$B \leftarrow B \wedge B$	–	1	0	–	–	↔	–	
		%B,imm4	$B \leftarrow B \wedge \text{imm4}$	–	1	0	–	–	↔	–	
		%B,[%X]	$B \leftarrow B \wedge [X]$	$B \leftarrow B \wedge [00\text{imm8}]$	1	0	–	–	↔	–	
		%B,[%X]+	$B \leftarrow B \wedge [X], X \leftarrow X+1$	–	1	0	–	–	↔	–	
		%B,[%Y]	$B \leftarrow B \wedge [Y]$	$B \leftarrow B \wedge [\text{FFimm8}]$	1	0	–	–	↔	–	
		%B,[%Y]+	$B \leftarrow B \wedge [Y], Y \leftarrow Y+1$	–	1	0	–	–	↔	–	
	AND	%F,imm4	$F \leftarrow F \wedge \text{imm4}$	–	1	0	0	0	0	–	
	AND	[%X],%A	$[X] \leftarrow [X] \wedge A$	$[00\text{imm8}] \leftarrow [00\text{imm8}] \wedge A$	2	0	–	–	↔	–	
		[%X],%B	$[X] \leftarrow [X] \wedge B$	$[00\text{imm8}] \leftarrow [00\text{imm8}] \wedge B$	2	0	–	–	↔	–	
		[%X],imm4	$[X] \leftarrow [X] \wedge \text{imm4}$	$[00\text{imm8}] \leftarrow [00\text{imm8}] \wedge \text{imm4}$	2	0	–	–	↔	–	
		[%X]+,%A	$[X] \leftarrow [X] \wedge A, X \leftarrow X+1$	–	2	0	–	–	↔	–	
		[%X]+,%B	$[X] \leftarrow [X] \wedge B, X \leftarrow X+1$	–	2	0	–	–	↔	–	
		[%X]+,imm4	$[X] \leftarrow [X] \wedge \text{imm4}, X \leftarrow X+1$	–	2	0	–	–	↔	–	
	AND	[%Y],%A	$[Y] \leftarrow [Y] \wedge A$	$[\text{FFimm8}] \leftarrow [\text{FFimm8}] \wedge A$	2	0	–	–	↔	–	
		[%Y],%B	$[Y] \leftarrow [Y] \wedge B$	$[\text{FFimm8}] \leftarrow [\text{FFimm8}] \wedge B$	2	0	–	–	↔	–	
		[%Y],imm4	$[Y] \leftarrow [Y] \wedge \text{imm4}$	$[\text{FFimm8}] \leftarrow [\text{FFimm8}] \wedge \text{imm4}$	2	0	–	–	↔	–	
		[%Y]+,%A	$[Y] \leftarrow [Y] \wedge A, Y \leftarrow Y+1$	–	2	0	–	–	↔	–	
		[%Y]+,%B	$[Y] \leftarrow [Y] \wedge B, Y \leftarrow Y+1$	–	2	0	–	–	↔	–	
		[%Y]+,imm4	$[Y] \leftarrow [Y] \wedge \text{imm4}, Y \leftarrow Y+1$	–	2	0	–	–	↔	–	
	OR	%A,%A	$A \leftarrow A \vee A$	–	1	0	–	–	↔	–	
		%A,%B	$A \leftarrow A \vee B$	–	1	0	–	–	↔	–	
		%A,imm4	$A \leftarrow A \vee \text{imm4}$	–	1	0	–	–	↔	–	
		%A,[%X]	$A \leftarrow A \vee [X]$	$A \leftarrow A \vee [00\text{imm8}]$	1	0	–	–	↔	–	
		%A,[%X]+	$A \leftarrow A \vee [X], X \leftarrow X+1$	–	1	0	–	–	↔	–	
		%A,[%Y]	$A \leftarrow A \vee [Y]$	$A \leftarrow A \vee [\text{FFimm8}]$	1	0	–	–	↔	–	
		%A,[%Y]+	$A \leftarrow A \vee [Y], Y \leftarrow Y+1$	–	1	0	–	–	↔	–	
		OR	%B,%A	$B \leftarrow B \vee A$	–	1	0	–	–	↔	–
		%B,%B	$B \leftarrow B \vee B$	–	1	0	–	–	↔	–	
	Remarks										

Instruction List (9)
S1C63000 Core CPU

Classification	Mnemonic		Basic function	Extended function (when "LDB %EXT, imm8" is executed)	Clk	Flags				Symbol	
	Opcode	Operand				E	I	C	Z		
Logic operation	OR	%B,imm4	$B \leftarrow B \vee \text{imm4}$	–	1	0	–	–	↔	–	
		%B,[%X]	$B \leftarrow B \vee [X]$	$B \leftarrow B \vee [00\text{imm8}]$	1	0	–	–	↔	–	
		%B,[%X]+	$B \leftarrow B \vee [X], X \leftarrow X+1$	–	1	0	–	–	↔	–	
		%B,[%Y]	$B \leftarrow B \vee [Y]$	$B \leftarrow B \vee [\text{FFimm8}]$	1	0	–	–	↔	–	
		%B,[%Y]+	$B \leftarrow B \vee [Y], Y \leftarrow Y+1$	–	1	0	–	–	↔	–	
	OR	%F,imm4	$F \leftarrow F \vee \text{imm4}$	–	1	1	1	1	1	–	
	OR	[%X],%A	$[X] \leftarrow [X] \vee A$	$[00\text{imm8}] \leftarrow [00\text{imm8}] \vee A$	2	0	–	–	↔	–	
		[%X],%B	$[X] \leftarrow [X] \vee B$	$[00\text{imm8}] \leftarrow [00\text{imm8}] \vee B$	2	0	–	–	↔	–	
		[%X],imm4	$[X] \leftarrow [X] \vee \text{imm4}$	$[00\text{imm8}] \leftarrow [00\text{imm8}] \vee \text{imm4}$	2	0	–	–	↔	–	
		[%X]+,%A	$[X] \leftarrow [X] \vee A, X \leftarrow X+1$	–	2	0	–	–	↔	–	
		[%X]+,%B	$[X] \leftarrow [X] \vee B, X \leftarrow X+1$	–	2	0	–	–	↔	–	
		[%X]+,imm4	$[X] \leftarrow [X] \vee \text{imm4}, X \leftarrow X+1$	–	2	0	–	–	↔	–	
	OR	[%Y],%A	$[Y] \leftarrow [Y] \vee A$	$[\text{FFimm8}] \leftarrow [\text{FFimm8}] \vee A$	2	0	–	–	↔	–	
		[%Y],%B	$[Y] \leftarrow [Y] \vee B$	$[\text{FFimm8}] \leftarrow [\text{FFimm8}] \vee B$	2	0	–	–	↔	–	
		[%Y],imm4	$[Y] \leftarrow [Y] \vee \text{imm4}$	$[\text{FFimm8}] \leftarrow [\text{FFimm8}] \vee \text{imm4}$	2	0	–	–	↔	–	
		[%Y]+,%A	$[Y] \leftarrow [Y] \vee A, Y \leftarrow Y+1$	–	2	0	–	–	↔	–	
		[%Y]+,%B	$[Y] \leftarrow [Y] \vee B, Y \leftarrow Y+1$	–	2	0	–	–	↔	–	
		[%Y]+,imm4	$[Y] \leftarrow [Y] \vee \text{imm4}, Y \leftarrow Y+1$	–	2	0	–	–	↔	–	
	XOR	%A,%A	$A \leftarrow A \vee A$	–	1	0	–	–	↔	–	
		%A,%B	$A \leftarrow A \vee B$	–	1	0	–	–	↔	–	
		%A,imm4	$A \leftarrow A \vee \text{imm4}$	–	1	0	–	–	↔	–	
		%A,[%X]	$A \leftarrow A \vee [X]$	$A \leftarrow A \vee [00\text{imm8}]$	1	0	–	–	↔	–	
		%A,[%X]+	$A \leftarrow A \vee [X], X \leftarrow X+1$	–	1	0	–	–	↔	–	
		%A,[%Y]	$A \leftarrow A \vee [Y]$	$A \leftarrow A \vee [\text{FFimm8}]$	1	0	–	–	↔	–	
		%A,[%Y]+	$A \leftarrow A \vee [Y], Y \leftarrow Y+1$	–	1	0	–	–	↔	–	
		XOR	%B,%A	$B \leftarrow B \vee A$	–	1	0	–	–	↔	–
	XOR	%B,%B	$B \leftarrow B \vee B$	–	1	0	–	–	↔	–	
		%B,imm4	$B \leftarrow B \vee \text{imm4}$	–	1	0	–	–	↔	–	
		%B,[%X]	$B \leftarrow B \vee [X]$	$B \leftarrow B \vee [00\text{imm8}]$	1	0	–	–	↔	–	
		%B,[%X]+	$B \leftarrow B \vee [X], X \leftarrow X+1$	–	1	0	–	–	↔	–	
		%B,[%Y]	$B \leftarrow B \vee [Y]$	$B \leftarrow B \vee [\text{FFimm8}]$	1	0	–	–	↔	–	
		%B,[%Y]+	$B \leftarrow B \vee [Y], Y \leftarrow Y+1$	–	1	0	–	–	↔	–	
		XOR	%F,imm4	$F \leftarrow F \vee \text{imm4}$	–	1	↔	↔	↔	↔	–
		XOR	[%X],%A	$[X] \leftarrow [X] \vee A$	$[00\text{imm8}] \leftarrow [00\text{imm8}] \vee A$	2	0	–	–	↔	–
	[%X],%B		$[X] \leftarrow [X] \vee B$	$[00\text{imm8}] \leftarrow [00\text{imm8}] \vee B$	2	0	–	–	↔	–	
	[%X],imm4		$[X] \leftarrow [X] \vee \text{imm4}$	$[00\text{imm8}] \leftarrow [00\text{imm8}] \vee \text{imm4}$	2	0	–	–	↔	–	
	Remarks										

Instruction List (10)
S1C63000 Core CPU

Classification	Mnemonic		Basic function	Extended function (when "LDB %EXT, imm8" is executed)	Clk	Flags				Symbol
	Opcode	Operand				E	I	C	Z	
Logic operation	XOR	[%X]+,%A	$[X] \leftarrow [X] \vee A, X \leftarrow X+1$	–	2	0	–	–	↔	–
		[%X]+,%B	$[X] \leftarrow [X] \vee B, X \leftarrow X+1$	–	2	0	–	–	↔	–
		[%X]+,imm4	$[X] \leftarrow [X] \vee \text{imm4}, X \leftarrow X+1$	–	2	0	–	–	↔	–
	XOR	[%Y],%A	$[Y] \leftarrow [Y] \vee A$	$[\text{FFimm8}] \leftarrow [\text{FFimm8}] \vee A$	2	0	–	–	↔	–
		[%Y],%B	$[Y] \leftarrow [Y] \vee B$	$[\text{FFimm8}] \leftarrow [\text{FFimm8}] \vee B$	2	0	–	–	↔	–
		[%Y],imm4	$[Y] \leftarrow [Y] \vee \text{imm4}$	$[\text{FFimm8}] \leftarrow [\text{FFimm8}] \vee \text{imm4}$	2	0	–	–	↔	–
		[%Y]+,%A	$[Y] \leftarrow [Y] \vee A, Y \leftarrow Y+1$	–	2	0	–	–	↔	–
		[%Y]+,%B	$[Y] \leftarrow [Y] \vee B, Y \leftarrow Y+1$	–	2	0	–	–	↔	–
		[%Y]+,imm4	$[Y] \leftarrow [Y] \vee \text{imm4}, Y \leftarrow Y+1$	–	2	0	–	–	↔	–
	BIT	%A,%A	$A \wedge A$	–	1	0	–	–	↔	–
		%A,%B	$A \wedge B$	–	1	0	–	–	↔	–
		%A,imm4	$A \wedge \text{imm4}$	–	1	0	–	–	↔	–
		%A,[%X]	$A \wedge [X]$	$A \wedge [00\text{imm8}]$	1	0	–	–	↔	–
		%A,[%X]+	$A \wedge [X], X \leftarrow X+1$	–	1	0	–	–	↔	–
		%A,[%Y]	$A \wedge [Y]$	$A \wedge [\text{FFimm8}]$	1	0	–	–	↔	–
		%A,[%Y]+	$A \wedge [Y], Y \leftarrow Y+1$	–	1	0	–	–	↔	–
		BIT	%B,%A	$B \wedge A$	–	1	0	–	–	↔
	%B,%B		$B \wedge B$	–	1	0	–	–	↔	–
	%B,imm4		$B \wedge \text{imm4}$	–	1	0	–	–	↔	–
	%B,[%X]		$B \wedge [X]$	$B \wedge [00\text{imm8}]$	1	0	–	–	↔	–
	%B,[%X]+		$B \wedge [X], X \leftarrow X+1$	–	1	0	–	–	↔	–
	%B,[%Y]		$B \wedge [Y]$	$B \wedge [\text{FFimm8}]$	1	0	–	–	↔	–
	%B,[%Y]+		$B \wedge [Y], Y \leftarrow Y+1$	–	1	0	–	–	↔	–
	BIT		[%X],%A	$[X] \wedge A$	$[00\text{imm8}] \wedge A$	1	0	–	–	↔
		[%X],%B	$[X] \wedge B$	$[00\text{imm8}] \wedge B$	1	0	–	–	↔	–
		[%X],imm4	$[X] \wedge \text{imm4}$	$[00\text{imm8}] \wedge \text{imm4}$	1	0	–	–	↔	–
		[%X]+,%A	$[X] \wedge A, X \leftarrow X+1$	–	1	0	–	–	↔	–
		[%X]+,%B	$[X] \wedge B, X \leftarrow X+1$	–	1	0	–	–	↔	–
		[%X]+,imm4	$[X] \wedge \text{imm4}, X \leftarrow X+1$	–	1	0	–	–	↔	–
	BIT	[%Y],%A	$[Y] \wedge A$	$[\text{FFimm8}] \wedge A$	1	0	–	–	↔	–
[%Y],%B		$[Y] \wedge B$	$[\text{FFimm8}] \wedge B$	1	0	–	–	↔	–	
[%Y],imm4		$[Y] \wedge \text{imm4}$	$[\text{FFimm8}] \wedge \text{imm4}$	1	0	–	–	↔	–	
[%Y]+,%A		$[Y] \wedge A, Y \leftarrow Y+1$	–	1	0	–	–	↔	–	
[%Y]+,%B		$[Y] \wedge B, Y \leftarrow Y+1$	–	1	0	–	–	↔	–	
[%Y]+,imm4		$[Y] \wedge \text{imm4}, Y \leftarrow Y+1$	–	1	0	–	–	↔	–	

Remarks

Instruction List (11)
S1C63000 Core CPU

Classification	Mnemonic		Basic function	Extended function (when "LDB %EXT, imm8" is executed)	Clk	Flags				Symbol
	Opcode	Operand				E	I	C	Z	
Logic operation	CLR	[00addr6],imm2	[00addr6] ← [00addr6]∧not (2 ^{imm2})	–	2	0	–	–	↔	○
		[FFaddr6],imm2	[FFaddr6] ← [FFaddr6]∧not (2 ^{imm2})	–	2	0	–	–	↔	○
	SET	[00addr6],imm2	[00addr6] ← [00addr6]∨(2 ^{imm2})	–	2	0	–	–	↔	○
		[FFaddr6],imm2	[FFaddr6] ← [FFaddr6]∨(2 ^{imm2})	–	2	0	–	–	↔	○
	TST	[00addr6],imm2	[00addr6]∧(2 ^{imm2})	–	1	0	–	–	↔	○
		[FFaddr6],imm2	[FFaddr6]∧(2 ^{imm2})	–	1	0	–	–	↔	○
Shift and rotate	SLL	%A	A (C←D3←D2←D1←D0←0)	–	1	0	–	↔	↔	–
		%B	B (C←D3←D2←D1←D0←0)	–	1	0	–	↔	↔	–
		[%X]	[X] (C←D3←D2←D1←D0←0)	[00imm8] (C←D3←D2←D1←D0←0)	2	0	–	↔	↔	–
		[%X]+	[X] (C←D3←D2←D1←D0←0), X ← X+1	–	2	0	–	↔	↔	–
		[%Y]	[Y] (C←D3←D2←D1←D0←0)	[FFimm8] (C←D3←D2←D1←D0←0)	2	0	–	↔	↔	–
		[%Y]+	[Y] (C←D3←D2←D1←D0←0), Y ← Y+1	–	2	0	–	↔	↔	–
	SRL	%A	A (0→D3→D2→D1→D0→C)	–	1	0	–	↔	↔	–
		%B	B (0→D3→D2→D1→D0→C)	–	1	0	–	↔	↔	–
		[%X]	[X] (0→D3→D2→D1→D0→C)	[00imm8] (0→D3→D2→D1→D0→C)	2	0	–	↔	↔	–
		[%X]+	[X] (0→D3→D2→D1→D0→C), X ← X+1	–	2	0	–	↔	↔	–
		[%Y]	[Y] (0→D3→D2→D1→D0→C)	[FFimm8] (0→D3→D2→D1→D0→C)	2	0	–	↔	↔	–
		[%Y]+	[Y] (0→D3→D2→D1→D0→C), Y ← Y+1	–	2	0	–	↔	↔	–
	RL	%A	A (C←D3←D2←D1←D0←C)	–	1	0	–	↔	↔	–
		%B	B (C←D3←D2←D1←D0←C)	–	1	0	–	↔	↔	–
		[%X]	[X] (C←D3←D2←D1←D0←C)	[00imm8] (C←D3←D2←D1←D0←C)	2	0	–	↔	↔	–
		[%X]+	[X] (C←D3←D2←D1←D0←C), X ← X+1	–	2	0	–	↔	↔	–
		[%Y]	[Y] (C←D3←D2←D1←D0←C)	[FFimm8] (C←D3←D2←D1←D0←C)	2	0	–	↔	↔	–
		[%Y]+	[Y] (C←D3←D2←D1←D0←C), Y ← Y+1	–	2	0	–	↔	↔	–
	RR	%A	A (C→D3→D2→D1→D0→C)	–	1	0	–	↔	↔	–
		%B	B (C→D3→D2→D1→D0→C)	–	1	0	–	↔	↔	–
		[%X]	[X] (C→D3→D2→D1→D0→C)	[00imm8] (C→D3→D2→D1→D0→C)	2	0	–	↔	↔	–
		[%X]+	[X] (C→D3→D2→D1→D0→C), X ← X+1	–	2	0	–	↔	↔	–
		[%Y]	[Y] (C→D3→D2→D1→D0→C)	[FFimm8] (C→D3→D2→D1→D0→C)	2	0	–	↔	↔	–
		[%Y]+	[Y] (C→D3→D2→D1→D0→C), Y ← Y+1	–	2	0	–	↔	↔	–
8/16-bit transfer and operation	LDB	%BA,%XL	BA ← XL	–	1	0	–	–	–	–
		%BA,%XH	BA ← XH	–	1	0	–	–	–	–
		%BA,%YL	BA ← YL	–	1	0	–	–	–	–
		%BA,%YH	BA ← YH	–	1	0	–	–	–	–
		%BA,%EXT	BA ← EXT	–	1	0	–	–	–	–
		%BA,%SP1	BA ← SP1	–	1	0	–	–	–	–
		%BA,%SP2	BA ← SP2	–	1	0	–	–	–	–
		Remarks								

Instruction List (12)
S1C63000 Core CPU


Classification	Mnemonic		Basic function	Extended function (when "LDB %EXT, imm8" is executed)	Clk	Flags				Symbol
	Opcode	Operand				E	I	C	Z	
8/16-bit transfer and operation	LDB	%BA,imm8	BA ← imm8	–	1	0	–	–	–	○, @h
		%BA,[%X]+	A ← [X], B ← [X+1], X ← X+2	–	2	0	–	–	–	–
		%BA,[%Y]+	A ← [Y], B ← [Y+1], Y ← Y+2	–	2	0	–	–	–	–
	LDB	%XL,%BA	XL ← BA	–	1	0	–	–	–	–
		%XL,imm8	XL ← imm8	X ← imm16 (imm8 set in EXT is used as high-order 8 bits)	1	0	–	–	–	○, @l
		%XH,%BA	XH ← BA	–	1	0	–	–	–	–
	LDB	%YL,%BA	YL ← BA	–	1	0	–	–	–	–
		%YL,imm8	YL ← imm8	Y ← imm16 (imm8 set in EXT is used as high-order 8 bits)	1	0	–	–	–	○, @l
		%YH,%BA	YH ← BA	–	1	0	–	–	–	–
	LDB	%EXT,%BA	EXT ← BA	–	1	1	–	–	–	–
		%EXT,imm8	EXT ← imm8	–	1	1	–	–	–	○, @l, @h @rh, @xh
	LDB	%SP1,%BA	SP1 ← BA	–	1	0	–	–	–	–
		%SP2,%BA	SP2 ← BA	–	1	0	–	–	–	–
	LDB	[%X]+,%BA	[X] ← A, [X+1] ← B, X ← X+2	–	2	0	–	–	–	–
		[%X]+,imm8	[X] ← i3~0, [X+1] ← i7~4, X ← X+2	–	2	0	–	–	–	○, @l, @h
	LDB	[%Y]+,%BA	[Y] ← A, [Y+1] ← B, Y ← Y+2	–	2	0	–	–	–	–
	ADD	%X,%BA	X ← X+BA	–	1	0	–	–	↔	–
		%X,sign8	X ← X+sign8 (sign8=–128~127)	X ← X+imm16 (imm8 set in EXT is used as high-order 8 bits)	1	0	–	↔	↔	○, @l
		%Y,%BA	Y ← Y+BA	–	1	0	–	–	↔	–
		%Y,sign8	Y ← Y+sign8 (sign8=–128~127)	Y ← Y+imm16 (imm8 set in EXT is used as high-order 8 bits)	1	0	–	–	↔	○, @l
CMP	%X,imm8	X-imm8 (imm8=0~255)	X-imm16 (imm8 set in EXT is used as high-order 8 bits)	1	0	–	↔	↔	○, @l	
	%Y,imm8	Y-imm8 (imm8=0~255)	Y-imm16 (imm8 set in EXT is used as high-order 8 bits)	1	0	–	↔	↔	○, @l	
INC	%SP1	SP1 ← SP1+1	–	1	0	–	–	↔	–	
	%SP2	SP2 ← SP2+1	–	1	0	–	–	↔	–	
DEC	%SP1	SP1 ← SP1-1	–	1	0	–	–	↔	–	
	%SP2	SP2 ← SP2-1	–	1	0	–	–	–	–	
Stack operation	PUSH	%A	[SP2-1] ← A, SP2 ← SP2-1	–	1	0	–	–	–	–
		%B	[SP2-1] ← B, SP2 ← SP2-1	–	1	0	–	–	–	–
		%F	[SP2-1] ← F, SP2 ← SP2-1	–	1	0	–	–	–	–
		%X	(((SP1-1)*4+3)-((SP1-1)*4)) ← X, SP1 ← SP1-1	–	1	0	–	–	–	–
		%Y	(((SP1-1)*4+3)-((SP1-1)*4)) ← Y, SP1 ← SP1-1	–	1	0	–	–	–	–
	POP	%A	A ← [SP2], SP2 ← SP2+1	–	1	0	–	–	–	–
		%B	B ← [SP2], SP2 ← SP2+1	–	1	0	–	–	–	–
		%F	F ← [SP2], SP2 ← SP2+1	–	1	↔	↔	↔	↔	–
	%X	X ← (([SP1*4+3]-[SP1*4]), SP1 ← SP1+1	–	1	0	–	–	–	–	
	%Y	Y ← (([SP1*4+3]-[SP1*4]), SP1 ← SP1+1	–	1	0	–	–	–	–	
Remarks										

Instruction List (13)
S1C63000 Core CPU

Classification	Mnemonic		Basic function	Extended function (when "LDB %EXT, imm8" is executed)	Clk	Flags				Symbol
	Opcode	Operand				E	I	C	Z	
Branch control	JR	sign8	$PC \leftarrow PC + \text{sign8} + 1$ (sign8=-128~127)	$PC \leftarrow PC + \text{sign16} + 1$ (sign16=-32768~32767)*1	1	0	-	-	-	○, @rI
	JR	%A	$PC \leftarrow PC + A + 1$	-	1	0	-	-	-	-
		%BA	$PC \leftarrow PC + BA + 1$	-	1	0	-	-	-	-
	JR	[00addr6]	$PC \leftarrow PC + [00addr6] + 1$	-	2	0	-	-	-	○
	JRC	sign8	If C=1 then $PC \leftarrow PC + \text{sign8} + 1$ (sign8=-128~127)	If C=1 then $PC \leftarrow PC + \text{sign16} + 1$ (sign16=-32768~32767)*1	1	0	-	-	-	○, @rI
	JRNC	sign8	If C=0 then $PC \leftarrow PC + \text{sign8} + 1$ (sign8=-128~127)	If C=0 then $PC \leftarrow PC + \text{sign16} + 1$ (sign16=-32768~32767)*1	1	0	-	-	-	○, @rI
	JRZ	sign8	If Z=1 then $PC \leftarrow PC + \text{sign8} + 1$ (sign8=-128~127)	If Z=1 then $PC \leftarrow PC + \text{sign16} + 1$ (sign16=-32768~32767)*1	1	0	-	-	-	○, @rI
	JRNZ	sign8	If Z=0 then $PC \leftarrow PC + \text{sign8} + 1$ (sign8=-128~127)	If Z=0 then $PC \leftarrow PC + \text{sign16} + 1$ (sign16=-32768~32767)*1	1	0	-	-	-	○, @rI
	JP	%Y	$PC \leftarrow Y$	-	1	0	-	-	-	-
	CALZ	imm8	$([(SP1-1)*4+3] - [(SP1-1)*4]) \leftarrow PC + 1$, $SP1 \leftarrow SP1 - 1$, $PC \leftarrow \text{imm8}$	-	1	0	-	-	-	○
	CALR	sign8	$([(SP1-1)*4+3] - [(SP1-1)*4]) \leftarrow PC + 1$, $SP1 \leftarrow SP1 - 1$, $PC \leftarrow PC + \text{sign8} + 1$ (sign8=-128~127)	$([(SP1-1)*4+3] - [(SP1-1)*4]) \leftarrow PC + 1$, $SP1 \leftarrow SP1 - 1$, $PC \leftarrow PC + \text{sign16} + 1$ (sign16=-32768~32767)*1	1	0	-	-	-	○, @rI
	CALR	[00addr6]	$([(SP1-1)*4+3] - [(SP1-1)*4]) \leftarrow PC + 1$, $SP1 \leftarrow SP1 - 1$, $PC \leftarrow PC + [00addr6] + 1$	-	2	0	-	-	-	○
	INT	imm6	$[SP2-1] \leftarrow F$, $SP2 \leftarrow SP2 - 1$, $([(SP1-1)*4+3] - [(SP1-1)*4]) \leftarrow PC + 1$, $SP1 \leftarrow SP1 - 1$, $PC \leftarrow \text{imm6}$ (imm6=0100H~013FH)	-	3	0	-	-	-	-
	RET		$PC \leftarrow ([SP1*4+3] - [SP1*4])$, $SP1 \leftarrow SP1 + 1$	-	1	0	-	-	-	-
	RETS		$PC \leftarrow ([SP1*4+3] - [SP1*4])$, $SP1 \leftarrow SP1 + 1$, $PC \leftarrow PC + 1$	-	2	0	-	-	-	-
	RETD	imm8	$PC \leftarrow ([SP1*4+3] - [SP1*4])$, $SP1 \leftarrow SP1 + 1$ [X] ← i3~0, [X+1] ← i7~4, X ← X+2	-	3	0	-	-	-	○, @h, @I
RETI		$PC \leftarrow ([SP1*4+3] - [SP1*4])$, $SP1 \leftarrow SP1 + 1$ F ← [SP2], SP2 ← SP2+1	-	2	↔	↔	↔	↔	-	
System control	HALT		Halt	-	2	0	-	-	-	-
	SLP		Sleep	-	2	0	-	-	-	-
	NOP		No operation ($PC \leftarrow PC + 1$)	-	1	0	-	-	-	-

Remarks

*1: sign16(s15~s8) = imm8, sign16(s7~s0) = sign8



Note:

In some S1C63 models, other development software tools are provided for the part indicated as "S1C63xxx Development Tool" and "*" (Steps 3 and 5). For details, refer to the tool manual associated with each specific model.

1. Programming

Create assembly source files using the work bench or an editor.

2. Assembly and Linking

2-1) Start up the work bench.

2-2) Create a project file, then insert source files into the project.

2-3) Execute the build process.

The work bench executes the assembler and linker sequentially to generate an executable object file.

3. Option Data Creation *

Create the option HEX/document files (function option, segment option) using the option data creation tools.

4. Debugging

4-1) Start up the debugger from the work bench.

4-2) Load the executable object file and option HEX files, then debug the program using the debug commands.

5. Mask Data Creation *

When the program development has been completed, create a mask data file.

5-1) Create the program HEX files using the HEX converter.

5-2) Convert the program and option document files into a mask data file using the mask data checker.

5-3) Submit the mask data file to Seiko Epson.

Outline

The work bench provides an integrated development environment with Windows GUI. Creating/editing source files, selecting files and major startup options, and the startup of each tool can be made with simple Windows operations.


Windows

[Project] window

This window shows the currently opened work space folder and lists all the source files in the project, with a structure similar to Windows Explorer. Double-clicking a source file icon opens the source file in the [Edit] window.

[Output] window

This window displays the messages delivered from the executed tools in a build or assemble process. Double-clicking a syntax error message with a source line number displayed in this window activates or opens the [Edit] window of the corresponding source so that the source line in which the error has occurred can be viewed.



[Edit] window

This window is used for editing a source file. A standard text file can also be displayed in this window. Two or more windows can be opened in the edit window area.


Tool bars**[Standard] tool bar**

-  **[New] button**
Creates a new document (source, header or project).
-  **[Open] button**
Opens a document (source, header or project).
-  **[Save] button**
Saves the document in the active [Edit] window to the file. The file will be overwritten.
-  **[Save All] button**
Saves the documents of all [Edit] windows and the project information to the respective files.
-  **[Cut] button**
Cuts the selected text in the [Edit] window to the clipboard.
-  **[Copy] button**
Copies the selected text in the [Edit] window to the clipboard.
-  **[Paste] button**
Pastes the text copied on the clipboard to the current cursor position in the [Edit] window.
-  **[Find] button**
Finds the specified word in the active [Edit] window.
-  **[Find Next] button**
Finds next target word towards the end of the file.
-  **[Find Previous] button**
Finds next target word towards the beginning of the file.
-  **[Print] button**
Prints the document in the active [Edit] window.
-  **[Help] button**
Displays the help window.

[Build] tool bar

-  **[Assemble] button**
Assembles the assembly source in the active [Edit] window.
-  **[Build] button**
Builds the currently opened project using a general make process.
-  **[Rebuild All] button**
Rebuilds the currently opened project.
-  **[Stop Build] button**
Stops the build process being executed.

[Build] tool bar

-  **[HEX Convert] button**
Invokes the HEX converter.
-  **[Disassemble] button**
Invokes the disassembler.
-  **[Debug] button**
Invokes the debugger with the specified ICE parameter file.
-  **[ICE Parameter] pull-down list box**
Selects the ICE parameter file for the model being developed. In this box, all the ICE parameter files that exist in the "Dev63" directory are listed.
-  **[Output Format] pull-down list box**
Selects an executable object file format. The build process will generate an executable object in the format selected here.

[Window] tool bar

-  **[Cascade] button**
Cascades the opened [Edit] windows.
-  **[Tile Horizontally] button**
Tiles the opened [Edit] window horizontally.
-  **[Tile Vertically] button**
Tiles the opened [Edit] window vertically.

Controls on [Edit] window

-  **[Insert Into project] button**
Inserts the source file being edited into the current opened project.
-  **[Goto Label] pull-down list box**
Goes to the selected label position.

Menus

[File] menu

File	
New...	Ctrl+N
Open...	Ctrl+O
Close	
Open Workspace...	
Close Workspace	
Save	Ctrl+S
Save As...	
Save All	
Print...	Ctrl+P
Print Preview	
Page Setup...	
1 sub.s	
2 main.s	
5 test.epi	
Exit	

The file names listed in this menu are recently used source and project files.
Selecting one opens the file.

[Edit] menu

Edit	
Undo	Ctrl+Z
Cut	Ctrl+X
Copy	Ctrl+C
Paste	Ctrl+V
Select All	Ctrl+A
Find...	Ctrl+F
Replace	Ctrl+H
Go To	Ctrl+G

New... ([Ctrl]+[N])

Creates a new document (source, header or project).

Open... ([Ctrl]+[O])

Opens a document (source, header or project).

Close

Closes the active [Edit] window.

Open Workspace...

Opens a project.

Close Workspace

Closes the currently opened project.

Save ([Ctrl]+[S])

Saves the document in the active [Edit] window to the file.

Save As...

Saves the document in the active [Edit] window with another file name.

Save All

Saves the documents of all [Edit] windows and the project information to the respective files.

Print... ([Ctrl]+[P])

Prints the document in the active [Edit] window.

Print Preview

Displays a print image of the document in the active [Edit] window.

Page Setup...

Displays a dialog box for selecting paper and printer.

Exit

Terminates the work bench.

Undo ([Ctrl]+[Z])

Undoes the previous executed operation in the [Edit] window.

Cut ([Ctrl]+[X])

Cuts the selected text in the [Edit] window to the clipboard.

Copy ([Ctrl]+[C])

Copies the selected text in the [Edit] window to the clipboard.

Paste ([Ctrl]+[V])

Pastes the text copied to the [Edit] window.

Select All ([Ctrl]+[A])

Selects all text in the active [Edit] window.

Find... ([Ctrl]+[F])

Finds the specified word in the active [Edit] window.

Replace ([Ctrl]+[H])

Replaces the specified words in the active [Edit] window.

Go To ([Ctrl]+[G])

Jumps to the specified line or label in the active [Edit] window.

[View] menu

View	
Standard Bar	
Status Bar	
Output Window	
Project Window	
Build Bar	
Window Bar	
Full Screen	

Standard Bar

Shows or hides the standard toolbar.

Status Bar

Shows or hides the status bar.

Output Window

Opens or closes the [Output] window.

Project Window

Opens or closes the [Project] window.

Build Bar

Shows or hides the build toolbar.

Window Bar

Shows or hides the window toolbar.

Full Screen

Maximizes the [Edit] window area to the full screen size.

[Insert] menu

Insert	
File...	
Files into project...	

File...

Inserts the specified file to the text in the [Edit] window.

Files into project...

Adds the specified source file in the currently opened project.

[Build] menu

Build	
Assemble	Ctrl+F7
Build	F7
Rebuild All	
Stop Build	Ctrl+Break
Debug	F5
Settings...	Alt+F7
ICE parameter file...	
Output Format...	

Assemble ([Ctrl]+[F7])

Assembles the assembly source in the active [Edit] window.

Build ([F7])

Builds the currently opened project using a general make process.

Rebuild All

Rebuilds the currently opened project.

Stop Build ([Ctrl]+[Break])

Stops the build process being executed.

Debug ([F5])

Invokes the debugger with the specified ICE parameter file.

Settings... ([Alt]+[F7])

Displays a dialog box for selecting tool options.

ICE parameter file...

Displays a dialog box for selecting an ICE parameter file.

Output Format...

Displays a dialog box for selecting an executable object file format.

Menus

[Tools] menu

Hex Converter...	HEX Converter... Invokes the HEX converter.
Disassembler...	Disassembler... Invokes the disassembler.
WinFOG	WinFOG Invokes the function option generator.
WinSOG	WinSOG Invokes the segment option generator.
WinMDC	WinMDC Invokes the mask data checker.
OBPW63	OBPW63 Invokes the On Board Writer control software.
Options...	Options... Displays a dialog box for setting work bench options.

[Window] menu

Window	This menu appears when an [Edit] window is opened.
Cascade	Cascade Cascades the opened [Edit] windows.
Tile Horizontally	Tile Horizontally Tiles the opened [Edit] window horizontally.
Tile Vertically	Tile Vertically Tiles the opened [Edit] window vertically.
Arrange Icons	Arrange Icons Arranges the minimized [Edit] window icons.
Close All	Close All Closes all the [Edit] windows opened.

[Help] menu

About WB63...	About WB63... Displays a dialog box showing the version of the work bench.
---------------	--

Short-Cut Key List

Ctrl + N	Creates a new document
Ctrl + O	Opens an existing document
Ctrl + F12	Opens an existing document
Ctrl + S	Saves the document
Ctrl + P	Print the active document
Ctrl + Shift + F12	Print the active document
Ctrl + Z	Undoes the last action
Alt + BackSpace	Undoes the last action
Ctrl + X	Cuts the selection and puts it on the clipboard
Shift + Delete	Cuts the selection and puts it on the clipboard
Ctrl + C	Copies the selection to the clipboard
Ctrl + Insert	Copies the selection to the clipboard
Ctrl + V	Inserts the clipboard contents at the insertion point
Shift + Insert	Inserts the clipboard contents at the insertion point
Ctrl + A	Selects the entire document
Ctrl + F	Finds the specified text
F3	Finds next
Shift + F3	Finds previous
Ctrl + H	Replaces the specified text with different text
Ctrl + G	Moves to the specified location
Ctrl + F7	Assembles the file
F7	Builds the project
Ctrl + Break	Stops the build
F5	Debugs the project
Alt + F7	Edits the project build and debug settings
Ctrl + Tab	Next MDI Window
Short-cut-key	Opens the popup menu
Shift + F10	Opens the popup menu


Error Messages

<filename> is changed by another editor. Reopen this file?	The currently opened file is modified by another editor.
Cannot create file: <filename>	The file (linker command file, debugger command file, etc.) cannot be created.
Cannot find file: <filename>	The source file cannot be found.
Cannot find ICE parameter file	The ICE parameter file cannot be found.
Cannot open file: <filename>	The source file cannot be opened.
You cannot close workspace while a build is in progress. Select the Stop Build command before closing.	The project close command or work bench terminate command is specified while the build task is being processed.
Would you like to build it?	The debugger invoke command is specified when the build task has not already been completed.

Outline

Converts the mnemonic of the source files into object codes (machine language) of the S1C63000. The results are output in a relocatable object file. This assembler includes preprocessing functions such as macro definition/call, conditional assembly, and file-include functions.

Flowchart



Start-up Command Usage

Usage: as63 [options] <file name>
 Options: -d <symbol> Add preprocess definition
 -e Output error log file (.ERR)
 -g Add source debug information in object
 -l Output relocatable list file (.LST)
 -c Ignore character case of symbols
 -o <file name> Specify output file name
 File name: Source file name (.S or .MS)

Pseudo-instructions

#include	<file name>	Inserts other file in the source file.
#define	<define name> [<string>]	Defines a character string with a define name.
#defnum	<defnum name> <value>	Defines a value with a defnum name.
#macro	<macro name> [par] [,par] ... <statements>	Defines a statement string with a macro name. (par: Dummy parameters)
#endm		
#ifdef	<name> <statements 1>	Conditional assembling <name> defined: <statements 1> is assembled.
[#else	<statements 2>]	<name> undefined: <statements 2> is assembled.
#endif		
#ifndef	<name> <statements 1>	Conditional assembling <name> undefined: <statements 1> is assembled.
[#else	<statements 2>]	<name> defined: <statements 2> is assembled.
#endif		
.code		Declares the start of a CODE section.
.data		Declares the start of a DATA section.
.bss		Declares the start of a BSS section.
.abs		Specifies absolute assembling.
.org	<address>	Specifies an absolute address.
.align	<alignment number>	Specifies alignment of a section.
.comm	<global symbol> <size>	Defines a global symbol and secures memory area in a bss section.
.lcomm	<local symbol> <size>	Defines a local symbol and secures memory area in a bss section.
.set	<symbol> <address>	Defines an absolute address for a symbol.
.global	<symbol>	Declares the symbol as global.
.codeword	<data>[<data> ... <data>]	Defines codes in the CODE section.
.word	<data>[<data> ... <data>]	Defines data in the DATA section.
.list		Turns output ON(.list)/OFF(.nolist) in the assembly list file. (Effective only when the -l option is specified)
.nolist		
.stabs	"<file name>", FileName	Outputs source information for debugging.
.stabn	0, FileEnd	(Effective only when the -g option is specified)
.stabs	<line number>, LineInfo	

Operators

		Priority
()	Parenthesis	1
+	Plus sign	2
-	Minus sign	2
~	Negation	2
^H	Acquires 8 high-order bits	3
^L	Acquires 8 low-order bits	3
*	Multiplication	4
/	Division	4
% (%%)	Residue	4
+	Addition	5
-	Subtraction	5
<<	Shifting to left	6
>>	Shifting to right	6
==	Equal (relational operator)	7
!=	Not equal (relational operator)	7
<	Less than (relational operator)	7
<=	Less than or equal (relational operator)	7
>	Greater than (relational operator)	7
>=	Greater than or equal (relational operator)	7
&	Bit AND	8
^	Bit XOR	9
	Bit OR	10
&&	AND (relational operator)	11
	OR (relational operator)	12

Numbers and symbols can be used as terms in expressions.
The expression is calculated as a signed 16-bit data.
Do not put any space or TAB between operator and number.

Error Messages

Address out of range	The specified address is out of range.
Cannot open <file kind> file <FILE NAME>	The specified file cannot be opened.
Cannot read <file kind> file <FILE NAME>	The specified file cannot be read.
Cannot write <file kind> file <FILE NAME>	Data cannot be written to the file.
Directory path length limit <directory path length limit> exceeded	The path name length has exceeded the limit.
Division by zero	The divisor in the expression is 0.
File name length limit <file name length limit> exceeded	The file name length has exceeded the limit.
Illegal macro label <label>	The internal branch label in macro definition is incorrect.
Illegal macro parameter <parameter>	The macro parameter is illegal.
Illegal syntax	The statement has a syntax error.
Line length limit <line length limit> exceeded	The number of characters in one line has exceeded the limit.
Macro parameter range <macro parameter range> exceeded	The number of macro parameters has exceeded the limit.
Memory mapping conflict	The address is already used.
Multiple statements on the same line	Two or more statements were described on one line.
Nesting level limit <nesting level limit> exceeded	Nesting of #include has exceeded the limit.
Number of macro labels limit <number of macro label limit> exceeded	The number of internal branch labels has exceeded the limit.
Out of memory	Cannot secure memory space.
Second definition of label <label>	The label is already defined.
Second definition of symbol <symbol>	The symbol is already defined.
Symbol name length limit <symbol name length limit> exceeded	The symbol name length has exceeded the limit.
Token length limit <token length limit> exceeded	The token length has exceeded the limit.
Unexpected character <name>	An invalid character has been used.
Unknown label <label>	Reference was made to an undefined label.
Unknown mnemonic <name>	A nonexistent instruction was used.
Unknown register <name>	A nonexistent register name was used.
Unknown symbol <name>	A reference to an undefined symbol was made.
Unknown symbol mask <name>	The symbol mask has a description error.
Unsupported directive <directive>	A nonexistent pseudo-instruction was used.


Warning Message

Expression out of range	The result of the expression is out of the effective range.
Invalid symbol mask	The symbol mask is not defined correctly.
Second definition of define symbol <symbol>	The symbol is already defined.
Section activation expected, use <.code/.bss>	There is no section definition.
Missing Delimiter	A comma is necessary between operands.

Outline

Links the relocatable objects created by the assembler by fixing the memory locations, and creates executable absolute object codes. The linker also provides a branch optimization function that automatically inserts, deletes or corrects extension codes for branch instructions.

Flowchart



Start-up Command Usage

Usage: lk63 [options] <file names>
 Options:

- d Disable all branch optimization
- di Disable insertion of branch extension
- dr Disable removal branch optimization
- e Output error log file (.ERR)
- g Add source debug information
- l Output absolute list file (.ALS)
- m Output map file (.MAP)
- o <file name> Specify output file name
- s Output symbol file (.SYM)
- x Output cross reference file (.XRF)
- code <address> Specify CODE start address
- data <address> Specify DATA start address
- bss <address> Specify BSS start address
- rcode <file name>=<address> Specify CODE start address of the file
- rdata <file name>=<address> Specify DATA start address of the file
- rbss <file name>=<address> Specify BSS start address of the file
- defsym <symbol>=<address> Define symbol address

File names: Relocatable object file (.O)
 Command parameter file (.CM)
 ICE parameter file (.PAR)

Error Messages

Branch destination too far from <address>	The branch destination address is out of range.
CALZ for non zero page at <address>	The specified address is out of the range (0x0000–0x00ff).
Cannot create absolute object file <FILE NAME>	The absolute object file cannot be created.
Cannot open <file kind> file <FILE NAME>	The file cannot be opened.
Cannot read <file kind> file <FILE NAME>	The file cannot be read.
Cannot relocate <section kind> section of <FILE NAME>	The relocatable section cannot be allocated.
Cannot write <file kind> file <FILE NAME>	Data cannot be written to the file.
Illegal address range <address> for a code at <address>	The address specified by TST/SET/CLR is out of the range (0x0000–0x003f or 0xffC0–0xffff).
Illegal file name <FILE NAME>	The file name is incorrect.
Illegal file name <FILE NAME> specified with option <option>	The file name specified with the option is incorrect.
Illegal ICE parameter at line <line number> of <FILE NAME>	The ICE parameter file contains an illegal parameter setting.
Illegal object <FILE NAME>	The input file is not an object file in IEEE-695 format.
Illegal option <option>	An illegal option is specified.
No address specified with option <option>	Address is not specified with the option.
No code to locate	There is no valid code for mapping.
No ICE parameter file specified	ICE parameter file is not specified.
No name and address specified with option <option>	Name and address are not specified with the option.
No object file specified	Object files to be linked are not specified.
Out of memory	Cannot secure memory space.
<section kind> section <address>--<address> overlaps with <section kind> section <address>--<address>	The address range of the section overlaps with another section's address range.
<section kind> section <address>--<address> overlaps with the unavailable memory	The address range of the section overlaps with the unavailable memory.
Unresolved external <label> in <FILE NAME>	Reference was made to an undefined symbol.
Unusable instruction code <instruction code> in <FILE NAME>	The object contains an instruction invalid for the model.


Warning Messages

Cannot create <file kind> file <FILE NAME>	The file cannot be created.
Cannot open <file kind> file <FILE NAME>	The file cannot be opened.
No debug information in <FILE NAME>	Debugging information is not included in the file.
No symbols found	Symbols cannot be found.
Second definition of label <label> in <FILE NAME>	The label has already been defined.
Second ICE parameter file <FILE NAME> ignored	Two or more ICE parameter files are specified.

Outline

Converts an absolute object in IEEE-695 format output from the linker into ROM-image data in Intel-HEX format or Motorola-S format. This conversion is needed when making the ROM or when creating mask data using the development tools provided with each model.

Flowchart



Start-up Command Usage

```
Usage: hx63 [options] <file names>
Options: -b          Do not fill unused memory with 0xff
         -e          Output error log file (HX63.ERR)
         -i          Use Intel Hex format
         -o <file name> Specify output file name
File names: Absolute object file (.ABS)
            ICE parameter file (.PAR)
```

Error Messages


Cannot create <file kind> file <FILE NAME>	The file cannot be created.
Cannot open <file kind> file <FILE NAME>	The file cannot be opened.
Cannot read <file kind> file <FILE NAME>	The file cannot be read.
Cannot write <file kind> file <FILE NAME>	Data cannot be written to the file.
Illegal file name <FILE NAME> specified with option <option>	The specified hex file name is incorrect.
Illegal ICE parameter at line <line number> of <FILE NAME>	The ICE parameter file contains an illegal parameter setting.
Illegal file name <FILE NAME>	The specified input file name is incorrect.
Illegal option <option>	An illegal option is specified.
Illegal absolute object format	The input file is not an object file in IEEE-695 format.
No ICE parameter file specified	ICE parameter file is not specified.
Out of memory	Cannot secure memory space.

Warning Message

Input file name extension .XXX conflict	Two or more file names with the same extension have been specified. The last one is used.
---	---

Outline

Disassembles an absolute object file in IEEE-695 format or a hex file in Motorola-S format, and restores it to a source format file. The restored source file can be processed in the assembler/linker/hex converter to obtain the same object or hex file.

Flowchart**Start-up Command Usage**

Usage: ds63 [options] <file name>
 Options: -cl Use lower case characters
 -cu Use upper case characters
 -e Output error log file (DS63.ERR)
 -o <file name> Specify output file name
 File names: Absolute object file (.ABS or .CSA/.LSA/.HSA)

Error Messages

Cannot create <file kind> file <FILE NAME>	The file cannot be created.
Cannot open <file kind> file <FILE NAME>	The file cannot be opened.
Cannot read <file kind> file <FILE NAME>	The file cannot be read.
Cannot write <file kind> file <FILE NAME>	Data cannot be written to the file.
Illegal file name <FILE NAME> specified with option <option>	The specified output source file name is incorrect.
Illegal file name <FILE NAME>	The specified input file name is incorrect.
Illegal HEX data format	The input file is not a Motorola-S format file.
Illegal option <option>	An illegal option is specified.
Out of memory	Cannot secure memory space.

Warning Message

Input file name extension .XXX conflict	Two or more file names with the same extension have been specified. The last one is used.
Cannot open Hex file xxx.csa	The file cannot be opened. It is assumed there is no data memory.


Outline

This software performs debugging by controlling the ICE hardware tool. Commands that are used frequently, such as break and step, are registered on the tool bar, minimizing the necessary keyboard operations. Moreover, sources, registers, and command execution results can be displayed in multiple windows, with resultant increased efficiency in the debugging tasks.

Start-up Command Usage

- Usage -
 db63.exe <parameter_file> <startup options>
 Options:
 command_file: ... specifies a command file
 -comX(X:1-4) ... com port, default com1
 -b ... baud rate, 2400,9600 (default),19200,38400
 -usb ... specifies usb communication
 -sim ... specifies simulator mode

Windows



[Source] window

Displays programs with unassemble codes, source codes or disassemble and source codes.

[Register] window

Displays register values and monitor data.

[Trace] window

Displays traced data.

[Data] window

Displays the contents of the data memory.

[Command] window

Used to enter debug commands and display the execution results.

Buttons

Tool bar

-  **[Key Break] button**
Forcibly breaks execution of the target program.
-  **[Load File] button**
Reads an object file in the IEEE-695 into the debugger.
-  **[Load Option] button**
Reads a program or optional HEX file in Motorola-S into the debugger.
-  **[Source] button**
Switches the display of the [Source] window to the source mode.
-  **[Unassemble] button**
Switches the display of the [Source] window to the unassemble mode.
-  **[Mix] button**
Switches the display of the [Source] window to the mix mode.
-  **[Go] button**
Executes the target program from the address indicated by the current PC.
-  **[Go to Cursor] button**
Executes the target program from the address indicated by the current PC to the cursor position in the [Source] window (the address of that line).
-  **[Go from Reset] button**
Resets the CPU and then executes the target program from the program start address (0x110).
-  **[Step] button**
Executes one instruction step at the address indicated by the current PC.
-  **[Next] button**
Executes one instruction step at the address indicated by the current PC. The calr, calz and int instructions and their subroutines are executed as one step.
-  **[Reset] button**
Resets the CPU.
-  **[Break] Button**
Sets or clears a breakpoint at the address where the cursor is located in the [Source] window.
-  **[Help] Button**
Displays the help window.

Controls on [Source] window

 **[Find] button**
Searches the specified word and moves the source display to the found word location.


[Search Label] pull-down list box
Moves the source display to the selected label location.

Search Label:

BOOT:
INC_RAM_BLK1:
INIT_RAM_BLK1:
LOOP:
NMI:

Menus

[File] menu



Load File...

Reads an object file in the IEEE-695 into the debugger.

Load Option...

Reads a program or optional HEX file in Motorola-S into the debugger.


Flash Memory Operation... (Cannot be used for USB ICE.)

Reads/writes data from/to the Flash memory or erases the Flash memory.

Exit

Terminates the debugger.

[Run] menu



Go

Executes the target program from the address indicated by the current PC.

Go to Cursor

Executes the target program from the address indicated by the current PC to the cursor position in the [Source] window.

Go from Reset

This menu item resets the CPU and then executes the target program from the program start address (0x110).

Step

Executes one instruction step at the address indicated by the current PC.

Next

Executes one instruction step at the address indicated by the current PC. The calr, calz and int instructions and their subroutines are executed as one step.


Command File...

Reads a command file and executes the debug commands written in that file.

Reset CPU

Resets the CPU.

[Break] menu



Breakpoint Set...

Displays, sets or clears PC breakpoints.

Data Break...

Displays, sets or clears data break conditions.

Register Break...

Displays, sets or clears register break conditions.

Sequential Break...

Displays, sets or clears sequential break conditions.

Stack Break...

Sets stack area for break.

Break List


Displays all the break conditions that have been set.

Break All Clear

Clears all break conditions.

Menus

[Trace] menu




Trace

Trace Mode Set...
Sets a trace mode and conditions.

Trace Search...
Searches trace information from the trace memory.

Trace File...
Saves the specified range of the trace information displayed in the [Trace] window to a file.

[View] menu



Command
Activates the [Command] window.

Program (Unassemble, Source Display, Mix Mode)
Opens or activates the [Source] window and displays the program from the current PC address in the display mode selected from the sub menu items.

Data Dump
Opens or activates the [Data] window and displays the data memory contents from the memory start address.

Register
Opens or activates the [Register] window and displays the current values of the registers.

Trace
Opens or activates the [Trace] window and displays the trace data sampled in the ICE trace memory.

Toolbar
Shows or hides the toolbar.

Status Bar
Shows or hides the status bar.

[Option] menu




Log...
Starts or stops logging.

Record...
Starts or stops recording of commands executed.

Mode Setting...
Sets the debugger modes.

[Window] menu




Window

Cascade
Cascades the opened windows.

Tile
Tiles the opened windows.

This menu shows the currently opened window names. Selecting one activates the window.

[Help] menu



About Db63...
Displays an About dialog box for the debugger.

Debug Commands

Program memory operation

a (as) [<addr> <mnemonic> [<file name>]]	Assemble mnemonic
pe [<addr> <code1> [...<code8>]]	Input program code
pf [<addr1> <addr2> <code>]	Fill program area
pm [<addr1> <addr2> <addr3>]	Copy program memory

Data memory operation

dd [<addr1> [<addr2>]]	Dump data memory
de [<addr> <data1> [...<data16>]]	Input data
df [<addr1> <addr2> <data>]	Fill data area
dm [<addr1> <addr2> <addr3>]	Copy data area
dw [<addr1> [...<addr4>]]	Set data watch address

Option information

od [{fogs sog mla} [<addr1> [<addr2>]]]	Dump option data
--	------------------

Register operation

rd	Display register values
rs [<reg> <value> [...<reg> <value>]]	Modify register values reg={pclalblxlylffsp1sp2extlq}

Program execution

g [<addr1> [<addr2>]]	Execute successively
gr [<addr1> [<addr2>]]	Reset CPU and execute successively
s [<step>]	Step into
n [<step>]	Step over

CPU reset

rst	Reset CPU
------------	-----------

Break

bp [<addr1> [...<addr16>]]	Set PC breakpoint
bc (bpc) [<addr1> [...<addr16>]]	Clear PC breakpoint
bd [<data> {rlw *} <addr1> <addr2>]	Set data break
bdc	Clear data break
br [<reg> <value> [...<reg> <value>]]	Set register break reg={pclalblxlylffsp1sp2extlq}
brc	Clear register break
bs [<pass> <addr1> [<addr2> [<addr3>]]]	Set sequential break
bsc	Clear sequential break
bsp [<addr1> <addr2> <addr3> <addr4>]	Specify stack area
bl	Display all break conditions
bac	Clear all break conditions

Program display

u [<addr>]	Unassemble display
sc [<addr>]	Source display
m [<addr>]	Mix display

Symbol information

sy [{<\$<keyword> #<keyword>}] [/a]	List symbols
--	--------------

Load file

if [<file name>]	Load IEEE-695 format absolute object file
lo [<file name>]	Load Motorola-S format file

Flash memory/FPGA operation

ifl [{p d fl slm} [...{p d fl slm}]]	Load data from Flash memory (Cannot be used for USB ICE.)
sfl [{p d fl slm} [...{p d fl slm}]] [-p]	Save data to Flash memory (Cannot be used for USB ICE.)
efl	Erase Flash memory (Cannot be used for USB ICE.)
xfer(s)	Erase FPGA
xfwr(s) <file name> ;{HIS} ;[N]	Write to FPGA
xfcp(s) <file name> ;{HIS}	Compare FPGA data
xdp(s) <addr1> [<addr2>]	Dump FPGA data

Trace

tm [{-nl-sl-a} <trigger> [{almle} {ilo}] [<addr1> <addr2> [...<addr7> <addr8>]]	Set trace mode
td [<cycle>]	Display trace information
ts [{p cl rd dw} <addr>]	Search trace information
tf [{<cycle1> [<cycle2>]] <file name>]	Save trace information into file

Others

cv [<addr1> [<addr2>]]	Display coverage information
cvc	Clear coverage information
com [<file name> [<interval>]]	Load & execute command file
cmw [<file name>]	Load & execute command file with intervals
rec [<file name>]	Record commands to a command file
log [<file name>]	Turn log output on or off
ma	Display map information
md [<option> <num> [...<option> <num>]]	Set debugger modes option={-fl-ul-il-sl-cl-ill-cm}
q	Quit debugger
?	Displays command usage

A symbol can be used to specify an address as follows:
 @<global symbol> or @<local symbol>@<source file name>

Debugger Messages

ICE status

Break by PC break	Break caused by PC breakpoint
Break by data break	Break caused by data break condition
Break by register break	Break caused by register break condition
Break by sequential break	Break caused by sequential break condition
Key Break	Break caused by pressing [ESC] key or [Key break] button
Break by accessing no map program area	Break caused by accessing undefined program-memory area
Break by accessing no map data area	Break caused by accessing undefined data-memory area
Break by accessing ROM area	Break caused by writing to data ROM area
Out of SP1 area	Break caused by accessing outside SP1 stack area
Out of SP2 area	Break caused by accessing outside SP2 stack area
Break by external break	Break caused by signal input to ICE BRKIN pin

ICE errors

communication error	Communication error other than time-out (overrun, framing, or BCC error)
CPU is running	Target is running.
ICE is busy	ICE is busy processing a job.
ICE is free run mode	ICE is operating in free-run mode.
ICE is maintenance mode	ICE is placed in maintenance mode.
no map area, XXXX	No-map area is specified for accessing.
not defined ID, XXXX	ICE respond ID is invalid.
on tracing	System is tracing execution data.
reset time out	CPU cannot be reset (for more than 1 second).
target down	Peripheral Circuit Board does not operate correctly or remains reset.
Time Out!	Communication time-out

Flash memory errors

flash memory error, XXXX	Writing or erasing flash memory has failed at XXXX.
flash ROM is protected	Flash memory is protected against access.
format error	Flash memory is not mapped.
Map information is not the same	Map information loaded from parameter file does not match that in the parameter file.
verify error, XXXX	Verify error has occurred when data was written to flash memory.

Command errors

Address out of range, use 0-0xXXXX	The specified program memory address is out of range.
Address out of range, use 0-0xFFFF	The specified data memory address is out of range.

Command errors

Cannot load program/ROM data, check ABS file	Failed to load program/ROM data; some file other than IEEE-695 executable format was specified.
Cannot open file	The file cannot be opened.
Data out of range, use 0-0xF	The specified number is out of the data range.
Different chip type, cannot load this file	A different ICE parameter is used in the file.
end address < start address	The start address is larger than the end address.
error file type (extension should be CMD)	The specified file extension is invalid.
FO address out of range, use 0-0xEF	FO address is invalid.
illegal code	The input code is not available.
illegal mnemonic	The input mnemonic is invalid for S1C63000.
Incorrect number of parameters	The parameter number is incorrect.
Incorrect option, use -f/-u/-i/-s/-c/-il/-cm	An invalid mode setting option was specified.
Incorrect r/w option, use r/w/*	An illegal R/W option was specified.
Incorrect register name, use A/B/X/Y/F	An invalid register name was specified.
Incorrect register name, use PC/A/B/X/Y/F/SP1/SP2/EXT/Q	The specified register name is invalid.
Input address does not exist	Attempt is made to clear a break address that has not been set.
invalid command	This is an invalid command.
invalid data pattern	The input data pattern is invalid.
invalid file name	The file name (extension) is invalid.
invalid value	The input data, address or symbol is invalid.
Maximum nesting level(5) is exceeded, cannot open file	Nesting of the com/cmw command exceeds the limit.
MLA address out of range, use 0-0xFFFF	MLA address is invalid.
no such symbol	There is no such symbol.
no symbol information	No symbol information is available since the ".ABS" file has not been loaded.
Number of passes out of range, use 0-4095	The specified pass count for sequential break is out of range.
Number of steps out of range, use 0-65535	The specified step count is out of range.
SO address out of range, use 0-0x1FFF	SO address is invalid.
SP1 address out of range, use 0-0x3FFF	The specified SP1 address is out of range.
SP2 address out of range, use 0-0xFF	The specified SP2 address is out of range.
symbol type error	The specified symbol type (program/data) is incorrect.


Command warning

Break address already exists	Attempt is made to set an already-set break address.
Identical break address input	Input command contains identical address.
round down to multiple of 4	Watch data address is invalid.
User cancel	Command is aborted by the user.
Verify error	FPGA verify error.

Outline

The function option generator winfog is the software tool for creating the file necessary to generate mask patterns of several hardware specifications such as I/O port functions. In addition, simultaneously with this file, winfog can create a mask option setup file that are required when debugging programs with the ICE.

Windows



Option list area

Lists mask options set in the device information definition file (s1c63xxx.ini). Use the check boxes in this area to select each option. A selected option has its check box marked by ✓.

Function option document area

Displays the contents of selected options in the function option document format. The contents displayed in this area are output to the function option document file. When you change any selected item in the option list area, the display in this area is immediately updated.

Message area

When you create a file by selecting [Generate] from the [Tool] menu or clicking the [Generate] button, this area displays a message showing the result of the selected operation.

Buttons

Tool bar


[Open] button

Opens a function option document file.


[Generate] button

Creates a file according to the selected contents of the option list.


[Setup] button

Sets the date of creation, output file name and a comment included in the function option document file.


[Device INI Select] button

Loads the device information definition file (s1c63xxx.ini).


[Help] button

Displays the version of winfog.

Menus

[File] menu

File(F)

Open(O)

End(X)

Open

Opens a function option document file.

End

Terminates winfog.

[Tool] menu

Tool(T)

Generate(G)

Setup(S)

Device INI Select

Generate

Creates a file according to the selected contents of the option list.

Setup

Sets the date of creation, output file name and a comment included in the function option document file.

Device INI Select

Loads the device information definition file (s1c63xxx.ini).

[Help] menu

Help(H)

Version(A)

Version

Displays the version of winfog.

Error Messages

File name error	Number of characters in the file name or extension exceeds the limit.
Illegal character	Prohibited characters have been entered.
Please input file name	File name has not been entered.
Can't open File : xxxx	File (xxxx) cannot be opened.
INI file is not found	Specified device information definition file (.ini) does not exist.
INI file does not include FOG information	Specified device information definition file (.ini) does not contain function option information.
Function Option document file is not found	Specified function option document file does not exist.
Function Option document file does not match INI file	Contents of the specified function option document file do not match device information definition file (.ini).
A lot of parameter	Too many command line parameters are specified.
Making file(s) is completed [xxxx is no data exist]	Finished creating the file, but the created file (xxxx) does not contain any data.
Can't open File: xxxx	File (xxxx) cannot be opened when executing Generate.
Making file(s) is not completed	
Can't write File: xxxx	File (xxxx) cannot be written when executing Generate.
Making file(s) is not completed	

Warning Message

Are you file update? xxxx is already exist	Overwrite confirmation message (Specified file already exists.)
---	--

Outline

The segment option generator winsog is the software tool for creating the file necessary to generate mask patterns of LCD output specifications and LCD output pin assignments. In addition, simultaneously with this file, winsog can create a mask option setup file that are required when debugging programs with the ICE.

Windows

Option setup area

Comprised of a display memory map, a segment decode table, and buttons to select pin specifications. By clicking on cells in the display memory map and segment decode table, you can assign display memory addresses and bits.

-  Selects LCD segment output.
-  Selects DC-complementary output.
-  Selects DC-Pch open-drain output.
-  Selects DC-Nch open-drain output.
-  Selects segment/common shared output.
-  Clears selected segment assignments.

Message area

When you create a file by selecting [Generate] from the [Tool] menu or clicking the [Generate] button, this area displays a message showing the result of the selected operation.

Buttons

Tool bar


[Open] button

Opens a segment option document file.


[Save] button

Saves the current option settings to a file (segment assignment data file).


[Load] button

Loads a segment assignment data file.


[Generate] button

Creates a file according to the contents of segment options set.


[Setup] button

Sets the date of creation or output file name or a comment included in the segment option document file.


[Device INI Select] button

Loads the device information definition file (s1c63xxx.ini).


[Help] button

Displays the version of winsog.

Menus

[File] menu


Open

Opens a segment option document file.

Record - Save

Saves the current option settings to a file (segment assignment data file).

Record - Load

Loads a segment assignment data file.

End

Terminates winsog.

[Tool] menu


Generate

Creates a file according to the contents of segment options set.


Setup

Sets the date of creation or output file name or a comment included in the segment option document file.

Device INI Select

Loads the device information definition file (s1c63xxx.ini).

[Help] menu


Version

Displays the version of winsog.

Error Messages


File name error	Number of characters in the file name or extension exceeds the limit.
Illegal character	Prohibited characters have been entered.
Please input file name	File name has not been entered.
Can't open File : xxxx	File (xxxx) cannot be opened.
INI file is not found	Specified device information definition file (.ini) does not exist.
INI file does not include SOG information	Specified device information definition file (.ini) does not contain segment option information.
Function Option document file is not found	Specified function option document file does not exist.
Function Option document file does not match INI file	Contents of the specified function option document file do not match device information definition file (.ini).
Segment Option document file is not found	Specified segment option document file does not exist.
Segment Option document file does not match INI file	Contents of the specified segment option document file do not match device information definition file (.ini).
Segment assignment data file is not found	Specified segment assignment data file does not exist.
Segment assignment data file does not match INI file	Contents of the specified segment assignment data file do not match device information definition file (.ini).
Can't open File: xxxx	File (xxxx) cannot be opened when executing Generate.
Making file(s) is not completed	
Can't write File: xxxx	File (xxxx) cannot be written when executing Generate.
Making file(s) is not completed	
ERROR: SPEC is not set	One or more SPEC cells are left blank when executing Generate.
Making file(s) is not completed	
ERROR: SEGMENT DECODE TABLE is not set.	Selected memory address/data bit has not been assigned to SEG/COM terminal cells when executing Generate.
Making file(s) is not completed	

Warning Message


Are you file update? xxxx is already exist	Overwrite confirmation message (Specified file already exists.)
---	--

Outline

The Mask Data Checker winmdc checks the format of the code/data ROM HEX files generated by the HEX converter hx63 and the option document files generated by the function option generator winfog, segment option generator winsog and melody assembler winmla, and create a file necessary to generate mask patterns. winmdc also has a function for restoring the created mask data file into the original file format.



Flowchart



Buttons

Tool bar



[Pack] button

Packs the ROM data file and option document file to create a mask data file for presentation to Seiko Epson.



[Unpack] button

Restores files in the original format from a packed file.



[Device INI Select] button

Loads the device information definition file (s1c63xxx.ini).



[Help] button

Displays the version of winmdc.

Menus

[File] menu

File(F)

End(Alt)

End

Terminates winmdc.

[Tool] menu

Tool(T)

Pack(P)

Unpack(U)

Device INI Select

Pack

Packs the ROM data file and option document file to create a mask data file for presentation to Seiko Epson.

Unpack

Restores files in the original format from a packed file.

Device INI Select

Loads the device information definition file (s1c63xxx.ini).

[Help] menu

Help(H)

Version(Alt)

Version

Displays the version of winmdc.

I/O Error Messages

File name error	Number of characters in the file name or extension exceeds the limit.
Illegal character	Prohibited characters have been entered.
Please input file name	File name has not been entered.
INI file is not found	Specified device information definition file (.ini) does not exist.
INI file does not include MDC information	Specified device information definition file (.ini) does not contain MDC information.
Can't open file : xxxx	File (xxxx) cannot be opened.
Can't write file: xxxx	File (xxxx) cannot be written.

ROM Data Error Messages

Hex data error: Not S record.	Data does not begin with "S".
Hex data error: Data is not sequential.	Data is not listed in ascending order.
Hex data error: Illegal data.	Invalid character is included.
Hex data error: Too many data in one line.	Too many data entries exist in one line.
Hex data error: Check sum error.	Checksum does not match.
Hex data error: ROM capacity over.	Data is large. (Greater than ROM size)
Hex data error: Not enough the ROM data.	Data is small. (Smaller than ROM size)
Hex data error: Illegal start mark.	Start mark is incorrect.
Hex data error: Illegal end mark.	End mark is incorrect.
Hex data error: Illegal comment.	Model name shown at the beginning of data is incorrect.

Function Option Data Error Messages

Option data error : Illegal model name.	Model name is incorrect.
Option data error : Illegal version.	Version is incorrect.
Option data error : Illegal option number.	Option No. is incorrect.
Option data error : Illegal select number.	Selected option number is incorrect.
Option data error : Mask data is not enough.	Mask data is insufficient.
Option data error : Illegal start mark.	Start mark is incorrect.
Option data error : Illegal end mark.	End mark is incorrect.

Segment Option Data Error Messages

LCD segment data error : Illegal model name.	Model name is incorrect.
LCD segment data error : Illegal version.	Version is incorrect.
LCD segment data error : Illegal segment No.	Segment No. is incorrect.
LCD segment data error : Illegal segment area.	Display memory address is out of range.
LCD segment data error : Illegal segment	Specified output mode is incorrect.
output specification.	
LCD segment data error : Illegal data in this line.	Data is not hex number or output mode.
LCD segment data error : Data is not enough.	Segment data is insufficient.
LCD segment data error : Illegal start mark.	Start mark is incorrect.
LCD segment data error : Illegal end mark.	End mark is incorrect.

AMERICA

EPSON ELECTRONICS AMERICA, INC.

214 Devcon Drive,
San Jose, CA 95112, USA
Phone: +1-800-228-3964 FAX: +1-408-922-0238

EUROPE

EPSON EUROPE ELECTRONICS GmbH

Riesstrasse 15, 80992 Munich,
GERMANY
Phone: +49-89-14005-0 FAX: +49-89-14005-110

ASIA

EPSON (CHINA) CO., LTD.

7F, Jinbao Bldg., No.89 Jinbao St.,
Dongcheng District,
Beijing 100005, CHINA
Phone: +86-10-8522-1199 FAX: +86-10-8522-1125

SHANGHAI BRANCH

7F, Block B, Hi-Tech Bldg., 900 Yishan Road,
Shanghai 200233, CHINA
Phone: +86-21-5423-5577 FAX: +86-21-5423-4677

SHENZHEN BRANCH

12F, Dawning Mansion, Keji South 12th Road,
Hi-Tech Park, Shenzhen 518057, CHINA
Phone: +86-755-2699-3828 FAX: +86-755-2699-3838

EPSON HONG KONG LTD.

Unit 715-723, 7/F Trade Square, 681 Cheung Sha Wan Road,
Kowloon, Hong Kong.
Phone: +852-2585-4600 FAX: +852-2827-4346

EPSON TAIWAN TECHNOLOGY & TRADING LTD.

14F, No. 7, Song Ren Road,
Taipei 110, TAIWAN
Phone: +886-2-8786-6688 FAX: +886-2-8786-6660

EPSON SINGAPORE PTE., LTD.

1 HarbourFront Place,
#03-02 HarbourFront Tower One, Singapore 098633
Phone: +65-6586-5500 FAX: +65-6271-3182

SEIKO EPSON CORP.**KOREA OFFICE**

5F, KLI 63 Bldg., 60 Yoido-dong,
Youngdeungpo-Ku, Seoul 150-763, KOREA
Phone: +82-2-784-6027 FAX: +82-2-767-3677

SEIKO EPSON CORP.**MICRODEVICES OPERATIONS DIVISION****IC Sales & Marketing Department**

421-8, Hino, Hino-shi, Tokyo 191-8501, JAPAN
Phone: +81-42-587-5814 FAX: +81-42-587-5117