

Indirect mode		
Command	Code	Parameter
MWRITE	42	P1
		P2
		.
MREAD	43	P1
		P2
		.
SYSTEMSET	40	P1
		P2
		P3
		P4
		P5
		P6
		P7
		P8
SLEEP IN	53	-
DISP ON/OFF	58	-
	59	P1
SCROLL	44	P1
		P2
		P3
		P4
		P5
		P6
		P7
		P8
		P9
		P10
CSRFORM	5D	P1
		P2
CSRDIR	4C	-
	4D	-
	4E	-
	4F	-
OVLAY	5B	P1
CGRAM ADR	5C	P1
		P2
HDOT SCR	5A	P1
CSRW	46	P1
		P2
CSRR	47	P1
		P2
GRAY SCALE	60	P1

Direct mode
Address
0000h
~
7FFFh
8000h
8001h
8002h
8003h
8004h
8005h
8006h
8007h
8008h
8009h
800Ah
800Bh
800Ch
800Dh
800Eh
800Fh
8010h
8011h
8012h
8013h
8014h
8015h
8016h
8017h
8017h
8017h
8017h
8017h
8018h
8019h
801Ah
801Bh
801Ch
801Dh
801Eh
801Fh
8020h
8021h
~
802Fh
8030h
~
FFFFh

Contents							
7	6	5	4	3	2	1	0
Display RAM area							
0	0	IV	1	WS	M2	0	M0
WF	0	0	0	FX			
0	0	0	0	FY			
CR							
TCR							
LF							
APL							
APH							
0	0	0	0	0	0	0	Sleep
0	0	0	0	0	0	0	Display
FP5	FP4	FP3	FP2	FP1	FP0	FC1	FC0
SAD1L							
SAD1H							
SL1							
SAD2L							
SAD2H							
SL2							
SAD3L							
SAD3H							
SAD4L							
SAD4H							
0	0	0	0	CSRX			
CM	0	0	0	CSRY			
0	1	0	0	1	1	0	0
0	1	0	0	1	1	0	1
0	1	0	0	1	1	1	0
0	1	0	0	1	1	1	1
0	0	0	OV	DM	MX		
SAGL							
SAGH							
0	0	0	0	0	HSR		
CSRWR L							
CSRWR H							
CSRRD L							
CSRRD H							
0	0	0	0	0	0	GrayScale	
Reserved							
Not use							