



















How To Show A View Which Are Undisplayed

Please show views which are undisplayed as below.

1. Please select [Window]>[Show View] in [Debug]Perspective.
2. The displayed view can be moved any places by mouse.



How To Show A View Which Are Undisplayed

	Breakpoints	Showing and changing breakpoints of all projects in workspace
	Console	Console view
	Debug	Debug view
	Disassembly	Disassembly view of program
	Error Log	Error log
	Executables	Showing execution files of all projects in workspace
	Expressions	Showing value which registered any monitoring expressions (global symbol, register)
	Memory	Showing on big endian method and changing memory value
	Memory Browser	Showing and changing memory value
	Modules	Showing execution file which is being debugged
	Outline	Outline view
	Problems	List of problems
	Registers	Showing and changing registers of CPU core
	Signals	-- No support --
	Tasks	List of Task"@todo" in source code
	Trace Control	-- No support --
	Variables	Showing and changing local variables (They are displayed automatically by program execution state)
	Other...	Others ([EmbSys Registers]View can be opened from this.)