



CMOS 8-BIT SINGLE CHIP MICROCOMPUTER S5U1C88000P Manual


(S1C88 Family Peripheral Circuit Board)





New configuration of product number

Starting April 1, 2001, the product number has been changed as listed below. Please use the new product number when you place an order. For further information, please contact Epson sales representative.



S5U1C88000P Manual (S1C88 Family Peripheral Circuit Board)

This manual describes how to use the S1C88 Family Peripheral Circuit Board (S5U1C88000P). This circuit board is used to provide emulation functions when it is installed in the ICE (S5U1C88000H5), a debugging tool for the 8-bit Single Chip Microcomputer S1C88 Family.

This manual describes only the common specifications of the S1C88 Family Peripheral Circuit Board (S5U1C88000P), so refer to the S5U1C88000P manual (Peripheral Circuit Board for S1C88xxx) for the model dependent specifications. For details on ICE functions and how to operate the debugger, refer to the separately prepared manuals.

Contents

CHAPTER 1	Introduction	1
	1.1 Outline of S5U1C88000P	
	1.2 Components of S5U1C88000P	
	1.3 External View of S5U1C88000P	
CHAPTER 2	SETTING UP THE S5U1C88000P	2
	2.1 Installing the S5U1C88000P in the ICE (S5U1C88000H5)	
	2.2 Downloading Cricuit Data	
2	PRODUCT SPECIFICATIONS	,

CHAPTER 1 INTRODUCTION

1.1 Outline of S5U1C88000P

The S5U1C88000P provides on a board all the peripheral circuits of S1C88 Family microcomputers other than the core CPU. By installing this board in the ICE (S5U1C88000H5) you can use it to emulate each model in the S1C88 Family. This board contains a programmable gate array (FPGA) and supports each model by downloading the circuit data from the host PC to the FPGA via the ICE.

1.2 Components of S5U1C88000P

After unpacking your S5U1C88000P package, check to see that all of the following components are included.

(1) S5U1C88000P main unit	1 board
(2) I/O cable (80-pin/40-pin × 2 flat type)	2 pairs
(3) Connector for connecting to target system (40-pin)	4 pieces
(4) Warranty card	1 card
(5) User registration card	1 card
(6) Precautions on using the S5U1C88000P Peripheral Circuit Board	. 1 sheet
(7) S5U1C88000P Manual (S1C88 Family Peripheral Circuit Board)	. 1 copy

1.3 External View of S5U1C88000P



Fig. 1.3.1 External view of S5U1C88000P

CHAPTER 2 SETTING UP THE S5U1C88000P

2.1 Installing the S5U1C88000P in the ICE (S5U1C88000H5)

Insert this board along by the lower guide rail of the ICE (S5U1C88000H5). The system may fail to operate if this board is not adequately mounted, so be sure to mount it securely.




Fig. 2.1.1 Installing the S5U1C88000P

2.2 Downloading Circuit Data

This board (S5U1C88000P) comes with the FPGA that contains factory inspection data, therefore the circuit data for the model to be used should be downloaded. The following explains the downloading procedure.

- 1) Set the switch "SW1"*1 on this board to the "3" position.
- 2) Install this board to the ICE (S5U1C88000H5) as shown in Section 2.1.
- 3) Connect the ICE to the host PC. Then turn the host PC and ICE on.
- 4) Invoke the debugger included in the ICE or assembler package. For how to use the ICE and debugger, refer to the manuals supplied with the ICE and assembler package.
- 5) Download the circuit data file (.mot) corresponding to the model by entering the following commands in the command window.

>XFER (erase all)

>XFWR *<file name>* (download the specified file)*2

>XFCP <file name> (compare the specified file and downloaded data)

- 6) Terminate the debugger and then turn the ICE off.
- 7) Remove this board from the ICE and set the switch "SW1" on the board to the "1" position.
- 8) Install this board to the ICE again.
- 9) Turn the ICE on and invoke the debugger again. Debugging can be started here.
- *1 See Figure 1.3.1, "External view of S5U1C88000P", for the location of SW1.
- *2 The downloading takes about 5 minutes.

CHAPTER 3 PRODUCT SPECIFICATIONS

The specifications of the S5U1C88000P are listed below.

S5U1C88000P

Dimension: $247.5 \text{ mm (wide)} \times 165 \text{ mm (depth)} \times 44.6 \text{ mm (height)}$

Weight: Approx. 500 g

Power supply: DC 5 V \pm 5%, less than 1 A (supplied from ICE main unit)

I/O connection cable (80-pin)

Interface: CMOS interface (3.3 V) Length: Approx. 40 cm

Monitor signal cable

Accessories

40-pin connector for connecting to target system:

 $3M3432-6002LCSC \times 4$

EPSON

International Sales Operations

AMERICA

EPSON ELECTRONICS AMERICA, INC.

- HEADQUARTERS -

150 River Oaks Parkway San Jose, CA 95134, U.S.A.

Phone: +1-408-922-0200 Fax: +1-408-922-0238

- SALES OFFICES -

1960 E. Grand Avenue El Segundo, CA 90245, U.S.A.

Phone: +1-310-955-5300 Fax: +1-310-955-5400

101 Virginia Street, Suite 290 Crystal Lake, IL 60014, U.S.A.

Phone: +1-815-455-7630 Fax: +1-815-455-7633

Northeast

301 Edgewater Place, Suite 120 Wakefield, MA 01880, U.S.A.

Phone: +1-781-246-3600 Fax: +1-781-246-5443

Southeast

3010 Royal Blvd. South, Suite 170 Alpharetta, GA 30005, U.S.A.

Phone: +1-877-EEA-0020 Fax: +1-770-777-2637

EUROPE

EPSON EUROPE ELECTRONICS GmbH

- HEADQUARTERS -

Riesstrasse 15

80992 Munich, GERMANY

Phone: +49-(0)89-14005-0 Fax: +49-(0)89-14005-110

SALES OFFICE

Altstadtstrasse 176

51379 Leverkusen, GERMANY

Phone: +49-(0)2171-5045-0 Fax: +49-(0)2171-5045-10

UK BRANCH OFFICE

Unit 2.4, Doncastle House, Doncastle Road Bracknell, Berkshire RG12 8PE, ENGLAND

Phone: +44-(0)1344-381700 Fax: +44-(0)1344-381701

FRENCH BRANCH OFFICE

1 Avenue de l' Atlantique, LP 915 Les Conquerants Z.A. de Courtaboeuf 2, F-91976 Les Ulis Cedex, FRANCE Phone: +33-(0)1-64862350 Fax: +33-(0)1-64862355

BARCELONA BRANCH OFFICE

Barcelona Design Center

Edificio Prima Sant Cugat Avda. Alcalde Barrils num. 64-68 E-08190 Sant Cugat del Vallès, SPAIN

Phone: +34-93-544-2490 Fax: +34-93-544-2491

ASIA

EPSON (CHINA) CO., LTD.

28F, Beijing Silver Tower 2# North RD DongSanHuan

ChaoYang District, Beijing, CHINA

Phone: 64106655 Fax: 64107319

SHANGHAI BRANCH

4F, Bldg., 27, No. 69, Gui Jing Road Caohejing, Shanghai, CHINA

Phone: 21-6485-5552 Fax: 21-6485-0775

EPSON HONG KONG LTD.

20/F., Harbour Centre, 25 Harbour Road

Wanchai, Hong Kong

Phone: +852-2585-4600 Fax: +852-2827-4346

Telex: 65542 EPSCO HX

EPSON TAIWAN TECHNOLOGY & TRADING LTD.

10F. No. 287. Nanking East Road. Sec. 3

Taipei

Phone: 02-2717-7360 Fax: 02-2712-9164

Telex: 24444 EPSONTB

HSINCHU OFFICE

13F-3, No. 295, Kuang-Fu Road, Sec. 2

HsinChu 300

Phone: 03-573-9900 Fax: 03-573-9169

EPSON SINGAPORE PTE., LTD.

No. 1 Temasek Avenue, #36-00 Millenia Tower, SINGAPORE 039192

Phone: +65-337-7911 Fax: +65-334-2716

SEIKO EPSON CORPORATION KOREA OFFICE

50F, KLI 63 Bldg., 60 Yoido-dong

Youngdeungpo-Ku, Seoul, 150-763, KOREA Phone: 02-784-6027 Fax: 02-767-3677

SEIKO EPSON CORPORATION ELECTRONIC DEVICES MARKETING DIVISION

Electronic Device Marketing Department

IC Marketing & Engineering Group 421-8, Hino, Hino-shi, Tokyo 191-8501, JAPAN

Phone: +81-(0)42-587-5816 Fax: +81-(0)42-587-5624

ED International Marketing Department Europe & U.S.A.

421-8, Hino, Hino-shi, Tokyo 191-8501, JAPAN

Phone: +81-(0)42-587-5812 Fax: +81-(0)42-587-5564

ED International Marketing Department Asia

421-8, Hino, Hino-shi, Tokyo 191-8501, JAPAN

Phone: +81-(0)42-587-5814 Fax: +81-(0)42-587-5110

S5U1C88000P Manual (S1C88 Family Peripheral Circuit Board)

SEIKO EPSON CORPORATION ELECTRONIC DEVICES MARKETING DIVISION

■ EPSON Electronic Devices Website

http://www.epson.co.jp/device/